

R&S® EVSF1000

VHF/UHF Nav/Flight Analyzer

User Manual



1178641002
<https://mod-e.ru/>

This document describes the following R&S EVSF1000 models with firmware version 1.50 or later:

- R&S EVSF1000 VHF/UHF nav/drone analyzer (1330.0350K02)
- R&S EVSF1000 (1330.0008.02)

Furthermore, it covers the following options:

- R&S EVSF1-B4 (1330.1404.02)
- R&S EVSF1-Z1 (1330.1410.02)
- R&S EVSF1-Z2 (1330.1427.02)
- R&S EVSG-K1 ILS CRS/CLR analysis (1329.9005.02)
- R&S EVSG-K2 VOR analysis (1329.9011.02)
- R&S EVSG-K3 Marker beacon analysis (1329.9028.02)
- R&S EVSG-K4 GBAS analysis (1329.9034.02)
- R&S EVSG-K5 SCAT-I Analysis (1329.9040.02)
- R&S EVSG-K6 COM analysis (1329.9057.02)
- R&S EVSG1-K7 LF-Analysis (1329.9163.02)
- R&S EVSG-K10 RF spectrum analysis (1329.9063.02)
- R&S EVSG-K11 AF spectrum analysis (1329.9070.02)
- R&S EVSG1-K25 I/Q data streaming (1329.9157.02)

© 2023 Rohde & Schwarz GmbH & Co. KG
Muehldorfstr. 15, 81671 Muenchen, Germany
Phone: +49 89 41 29 - 0
Email: info@rohde-schwarz.com
Internet: www.rohde-schwarz.com

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

All other trademarks are the properties of their respective owners.

1178.6410.02 | Version 08 | R&S®EVSF1000

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol , e.g. R&S®EVSF1000 is indicated as R&S EVSF1000.

Contents

1	Getting started.....	5
2	Measurements and results.....	37
3	Configuring the input signal and measurement mode.....	40
4	Numeric measurement modes.....	42
5	Graphic measurement modes.....	125
6	GBAS/SCAT-I mode.....	154
7	Data management.....	198
8	Common instrument settings.....	209
9	Remote commands.....	228
10	Maintenance, storage and disposal.....	374
11	Transporting.....	375
12	Contacting customer support.....	376
	Annex.....	377
A	ILS channel frequency list.....	377
B	VOR channel frequency list.....	379
C	References.....	381
D	Format description of GBAS and SCAT-I data.....	382
	List of commands.....	388
	Index.....	401

1 Getting started

Note: the following chapters are identical to those in the printed R&S EVSF1000 Getting Started manual.

1.1 Safety information

The product documentation helps you use the product safely and efficiently. Follow the instructions provided here and in the following chapters.

Intended use

The R&S EVSF1000 is a level and modulation analyzer intended for installation in flight inspection aircraft. It performs measurements on instrument landing systems (ILS), ground-based augmentation systems (GBAS), very high frequency omnidirectional range (VOR) and marker beacon ground stations. It analyzes air traffic control communications (ATC COM) signals measured during startup, maintenance and servicing. The instrument's mechanical and electrical design and high sensitivity make it ideal for state-of-the-art flight inspection.

Use the product only for its designated purpose. Observe the operating conditions and performance limits stated in the data sheet.

Target audience

The R&S EVSF1000 and its documentation is targeted at air navigation service providers (ANSP), ground inspection service providers, national authorities for air traffic control, and manufacturers and airport technicians for ILS, GBAS and VOR ground equipment. Users require basic knowledge of ILS, GBAS and VOR ground equipment, as well as the International Civil Aviation Organization (ICAO) specifications in document 8071, annex 10.

Where do I find safety information?

Safety information is part of the product documentation. It warns you of potential dangers and gives instructions on how to prevent personal injury or damage caused by dangerous situations. Safety information is provided as follows:

- In [Chapter 1.1.1, "Safety instructions"](#), on page 5. The same information is provided in many languages as printed "Safety Instructions". The printed "Safety Instructions" are delivered with the product.
- Throughout the documentation, safety instructions are provided when you need to take care during setup or operation.

1.1.1 Safety instructions

Products from the Rohde & Schwarz group of companies are manufactured according to the highest technical standards. To use the products safely, follow the instructions

provided here and in the product documentation. Keep the product documentation nearby and offer it to other users.

Use the product only for its intended use and within its performance limits. Intended use and limits are described in the product documentation such as the data sheet, manuals and the printed "Safety Instructions". If you are unsure about the appropriate use, contact Rohde & Schwarz customer service.

Using the product requires specialists or specially trained personnel. These users also need sound knowledge of at least one of the languages in which the user interfaces and the product documentation are available.

Reconfigure or adjust the product only as described in the product documentation or the data sheet. Any other modifications can affect safety and are not permitted.

Never open the casing of the product. Only service personnel authorized by Rohde & Schwarz are allowed to repair the product. If any part of the product is damaged or broken, stop using the product. Contact Rohde & Schwarz customer service at <https://www.rohde-schwarz.com/support>.

Operating the product

The product is intended for mobile use. The maximum weight of the product is provided in the data sheet. If the product casing is not waterproof, use an adequate weather protection to carry the product outdoors with you.

When using the product in a vehicle or aircraft, make sure that the product is properly secured. If stacking is possible, secure the whole stack of products so that they cannot fall over and cause injury.

Observe the ambient conditions such as altitude, operating temperature and climatic loads; see the data sheet.

Due to their exposed location, mobile communications systems are at risk of damage from lightning. This also poses a risk to persons nearby. Vehicles carrying mobile communications systems require an electrically conductive body, a grounded antenna and also equipotential bonding that includes the cables routed into the vehicle.

Connecting to power

The product runs on DC voltage. For the specifications of the supply voltage for the product, refer to the data sheet. Under normal conditions, contact with DC voltage in this range poses a low risk of electric shock.

Take the following measures for your safety:

- If you connect the product to an external power supply, use one recommended in the product documentation.
- If you connect the product to a battery, observe the safety information delivered with the battery.
- Before switching on the product, ensure that the voltage and frequency indicated on the product match the available power source.
- Only use intact cables and route them carefully so that they cannot be damaged. Also ensure that nobody can trip over loose cables.

Using headphones

Take the following measures to prevent hearing damage. Before using headphones, check the volume and reduce it if necessary. If you monitor varying signal levels, take off the headphones and wait until the signal has settled. Then adjust the volume.

Meaning of safety labels

Safety labels on the product warn against potential hazards.

	Potential hazard Read the product documentation to avoid personal injury or product damage.
	DC - direct current Connect to a DC power supply of the specified voltage range.

1.1.2 Labels on the product

Labels on the casing inform about:

- Personal safety, see ["Meaning of safety labels"](#) on page 7
- Product and environment safety, see [Table 1-1](#)

Table 1-1: Labels regarding product and environment safety

	Labeling in line with EN 50419 for disposal of electrical and electronic equipment after the product has come to the end of its service life. For more information, see "Disposing electrical and electronic equipment" on page 374.
---	--

1.1.3 Warning messages in the documentation

A warning message points out a risk or danger that you need to be aware of. The signal word indicates the severity of the safety hazard and how likely it will occur if you do not follow the safety precautions.

CAUTION

Potentially hazardous situation. Could result in minor or moderate injury if not avoided.

NOTICE

Potential risks of damage. Could result in damage to the supported product or to other property.

1.2 Documentation overview

This section provides an overview of the R&S EVSF1000 user documentation. Unless specified otherwise, you find the documents at:

www.rohde-schwarz.com/manual/EVSF1000

Further documents are available at:

www.rohde-schwarz.com/product/EVSF1000

1.2.1 Getting started manual

Introduces the R&S EVSF1000 and describes how to set up and start working with the product. A printed version is delivered with the instrument.

1.2.2 User manuals and help

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the getting started manual.

The contents of the user manual are also available as online help on the R&S EVSF1000.

1.2.3 Service manual

Describes the performance test for checking compliance with rated specifications, firmware update, troubleshooting, adjustments, installing options and maintenance.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS):

1.2.4 Printed safety instructions

Provides safety information in many languages. The printed document is delivered with the product.

1.2.5 Data sheets and brochures

The data sheet contains the technical specifications of the R&S EVSF1000. It also lists the firmware applications and their order numbers, and optional accessories.

The brochure provides an overview of the instrument and deals with the specific characteristics.

See www.rohde-schwarz.com/brochure-datasheet/EVSF1000/

1.2.6 Release notes and open-source acknowledgment (OSA)

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation.

The software makes use of several valuable open source software packages. An open-source acknowledgment document provides verbatim license texts of the used open source software.

See www.rohde-schwarz.com/firmware/EVSF1000.

1.2.7 Calibration certificate

The document is available on <https://gloris.rohde-schwarz.com/calcert>. You need the device ID of your instrument, which you can find on a label on the rear panel.

1.3 Key features

The R&S EVSF1000 offers the following key features:

- Detailed analysis of ILS, VOR and Marker Beacon ground measurements (based on ICAO Doc. 8071 and ICAO Annex 10)
- Analysis of air traffic control (ATC) communications signals
- High measurement rate, at 100 data records/s
- Two identical signal processing units for parallel measurement of Localizer and Glidepath
- Compact, robust design (ARINC 404)
- Simple remote operation via standard interfaces
- Software options for specific use cases
- Integrated data recording

1.4 Preparing for use

Here, you can find basic information about setting up the product for the first time.

• Unpacking and checking	10
• Lifting and carrying	10
• Setting up the product	10
• Connecting to power	13
• Starting and shutting down the R&S EVSF1000	15
• Connecting devices for signal input and output	15
• Connecting to LAN	16
• Setting up a data link (Wi-Fi) connection	17
• Performing an autocalibration	18

1.4.1 Unpacking and checking

1. Unpack the R&S EVSF1000 carefully.
2. Retain the original packing material. Use it when transporting or shipping the product later.
3. Using the delivery notes, check the equipment for completeness.
The instrument comes with the following accessories:
 - Printed Getting Started manual
4. Check the equipment for damage.
If the delivery is incomplete or equipment is damaged, contact Rohde & Schwarz.

1.4.2 Lifting and carrying

The handle on the front of the R&S EVSF1000 is designed to move, lift or carry the instrument. Do not apply excessive external force to the handle.

1.4.3 Setting up the product

The R&S EVSF1000 was designed for installation in flight inspection aircraft. Even the movement caused by transportation or mobile use does not impair its functioning. You can also set up the R&S EVSF1000 on a benchtop, for example to prepare the R&S EVSF1000 for mobile use.

See also:

- ["Intended use"](#) on page 5

1.4.3.1 Mounting the R&S EVSF1000 in a rack

The R&S EVSF1000 is meant for use in a flight inspection plane. Make sure that the product is properly secured. For a stable setup, you can connect the R&S EVSF1000 to an optional installation tray that you insert in the flight inspection rack.

Using the connector plate, you can remove and replace the R&S EVSF1000 quickly and easily. While the tray remains connected to the aircraft permanently, you can remove the R&S EVSF1000 quickly and easily, without having to disconnect all cables from the instrument individually.

This setup requires an R&S EVSF1000 with the following options:

- Slide-in hardware (R&S EVSF1-B4)
- Installation tray with connector (R&S EVSF1-Z1)



The 60 mm perforations allow you to mount external fans to the tray.

To prepare the rack

- **NOTICE!** Insufficient airflow can cause overheating and damage the product.
Design and implement an efficient ventilation concept for the rack.

To mount the R&S EVSF1000 on an installation tray

1. Insert the installation tray into the flight inspection rack. Make sure it lies in the rack straight and securely.
2. Fasten the tray in the rack by inserting 5 mm flat-head screws from the top of the tray through the rack. Use only the indicated perforations for rack-mounting to ensure the mechanical strength of the tray.




Figure 1-1: Perforations for installation in the rack


- a) Fasten 3 screws through the perforations on the left as shown in [Figure 1-1](#).
 - b) Fasten 3 screws through one of the two rows on the right.
 - c) Tighten all screws with a tightening torque of 1.2 Nm to secure the tray in the rack.
3. Connect the ARINC connector of the tray to the board power supply and any other devices required for signal input or output, such as the receiving antenna, the GPS receiver, or the PPS signal.
For a description of the pin assignment, see [Table 1-2](#).
 4. Place the bottom of the R&S EVSF1000 on top of the installation tray.

5. Insert the ARINC connector of the tray to the female connector on the R&S EVSF1000.



Note: The R&S EVSF1000 does not have a power (On/Off) switch. When you apply voltage to the ARINC connector, the R&S EVSF1000 starts immediately.

6. Make sure the curved offsets of the metal plate on the instrument lay securely on the knobs at the front of the tray.




7. Fasten the knobs on the tray manually by twisting them clock-wise.

The instrument is ready for operation.

1.4.3.2 Placing the R&S EVSF1000 on a bench top

To place the R&S EVSF1000 on a bench top

1. Place the product on a stable, flat and level surface.
2. **CAUTION!** The top surface of the product is too small for stacking. If you stack another product on top of the product, the stack can fall over and cause injury. If you want to save space, mount several products in a rack.



1.4.4 Connecting to power

The R&S EVSF1000 is equipped with a DC power supply connector on the rear panel of the instrument that can be connected to the board power of an aircraft.

For use outside an aircraft, you can use an optional AC/DC power supply unit.

For safety information, see "[Connecting to power](#)" on page 6.

- [Connecting the R&S EVSF1000 to an external DC power source](#)..... 13
- [Connecting the R&S EVSF1000 to AC power](#)..... 14

1.4.4.1 Connecting the R&S EVSF1000 to an external DC power source

You can connect the R&S EVSF1000 to an external DC power source, such as the board power of the flight inspection plane or the drone. The power supply must provide a voltage of 11 V DC to 32 V DC.

The R&S EVSF1000 is inline with DO-160G, section 16, category A. For a minimum input of 20 V DC, the R&S EVSF1000 sustains a 200 ms DC power interruption without rebooting.

If the external power supply unit supplies safety extra-low DC voltage (SELV) to the instrument, be sure to meet the requirements for reinforced/double insulation in accordance with DIN/EN/IEC 61010 (UL 3111, CSA C22.2 No. 1010.1) or DIN/EN/IEC

60950 (UL 1950, CSA C22.2 No. 950). Provide current limitation in accordance with DIN EN 61010-1 appendix F2.1.

Connect the R&S EVSF1000 to an external DC power source as follows:

1. Connect a 3-pin XLR connection cable to the Power supply connector on the back of the instrument (see [Chapter 1.5.2.1, "Power supply"](#), on page 22).
2. Insert a 3 AT fuse to protect the connection between the instrument and the external DC power source against excessive current. A short-circuit can damage the instrument or power supply unit.
3. Connect the XLR connection cable to the DC power supply.
If you have to extend the cable, ensure that the entire cable has a cross-section of at least 1.5 mm².

The R&S EVSF1000 does not have a power (On/Off) switch. When you apply board power, the R&S EVSF1000 starts immediately.

Disconnecting from power

When you interrupt the supply voltage from a level of 20 V or more, the R&S EVSF1000 continues to work for approximately 300 ms. It is powered by internal backup capacitors, intended to bridge short power failures in an aircraft installation. During this time, the current measurement settings and the latest error log data are saved to the internal flash memory.

- To disconnect the R&S EVSF1000 from power, disconnect the XLR connection cable from the DC power supply.

1.4.4.2 Connecting the R&S EVSF1000 to AC power

If you need to operate the R&S EVSF1000 outside an aircraft, you can use an AC/DC power supply unit, available as an accessory. When connecting to an AC power supply, only use the R&S EVSG1-Z8 Power supply.

Connect the R&S EVSF1000 to AC power as follows:

1. Connect the DC connector on the AC/DC power supply unit to the Power Supply connector on the back of the R&S EVSF1000 (see [Chapter 1.5.2.1, "Power supply"](#), on page 22).
2. Plug the AC power cable into the AC/DC power supply connector. Only use the AC power cable delivered with the power supply unit.
The required ratings are indicated next to the AC power connector and in the power supply unit's data sheet.
3. Plug the AC power cable into a two-pin power outlet with ground contact.
The green operating LED of the AC/DC power supply connector lights up.

The R&S EVSF1000 does not have a power (On/Off) switch. When you apply voltage to the Power Supply connector, the R&S EVSF1000 starts immediately. The green Power LED on the front panel of the R&S EVSF1000 lights up.

Disconnecting from power

When you interrupt the supply voltage from a level of 20 V or more, the R&S EVSF1000 continues to work for approximately 300 ms. It is powered by internal backup capacitors, intended to bridge short power failures in an aircraft installation. During this time, the current measurement settings and the latest error log data are saved to the internal flash memory.

NOTICE

Risk of losing settings

If the power interruption occurs at a power level under 20 V, the R&S EVSF1000 does not save the settings.

In particular, if you operate the R&S EVSF1000 using an AC/DC power supply and the AC power supply is interrupted, the DC power decreases slowly. In this case, the R&S EVSF1000 detects the power failure too late and cannot save the settings.

To ensure a controlled shutdown:

1. Disconnect the R&S EVSF1000 from the DC power supply.
2. Disconnect the AC power supply.

1.4.5 Starting and shutting down the R&S EVSF1000

The R&S EVSF1000 does not have a power (On/Off) switch. When you apply voltage to the power supply connector, the R&S EVSF1000 starts immediately.

To shut down the R&S EVSF1000, disconnect it from the power supply. Note the information concerning power interruption provided in [Chapter 1.4.4, "Connecting to power"](#), on page 13.

1.4.6 Connecting devices for signal input and output

1. Connect the RF input connector (RX1 IN/RX2 IN) with the receiving antenna (see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23).
2. Connect any other required connectors for input or output, such as GPS or PPS signals (see [Chapter 1.5.2.4, "RS-232 GPS"](#), on page 23 and [Chapter 1.5.2.5, "PPS in"](#), on page 23).

1.4.7 Connecting to LAN

You can connect the instrument to a LAN for remote operation via a remote device. For details on the connector, see [Chapter 1.5.2.3, "LAN \(ethernet\)"](#), on page 23.

Provided the network administrator has assigned you the appropriate rights and adapted the Windows firewall configuration, you can use the interface, for example:

- To stream measurement data from the R&S EVSF1000 to a connected device
- To access or control the measurement from a remote computer using a VNC client
- To connect external network devices (e.g. printers)

NOTICE

Risk of network failure

Consult your network administrator before performing the following tasks:

- Connecting the instrument to the network
- Configuring the network
- Changing IP addresses
- Exchanging hardware

Errors can affect the entire network.

1. Connect the R&S EVSF1000 to the LAN via the LAN interface on the right panel of the instrument.
2. Start a VNC client on the connected remote device.
3. Enter the IP address of the R&S EVSF1000. The default address is the static IP address 10.255.255.98. Note that without a DHCP server, the network adapter on the remote device must use an IP address within the same TCP/IP netmask. (Usually, that means only the last number of the IP address differs.)

The used IP address is indicated in the "Setup" menu on the R&S EVSF1000 display.



When using DHCP, the IP address is assigned to the devices dynamically. In this case, if a dynamic name server (DNS) is available, you can use the permanent instrument name to access the R&S EVSF1000. The default instrument name is EVSF<serial_number>, for example, EVSF1000-123456. For information on determining the serial number, see [Chapter 1.5.2.12, "Device ID"](#), on page 26.

For more information on LAN configuration, see [Chapter 8.3, "LAN \(remote\) settings"](#), on page 211.

1.4.8 Setting up a data link (Wi-Fi) connection

The R&S EVSF1000 can be equipped with an optional data-link-module (Wi-Fi, R&S EVSD1-Z5 Data-link-module (Wi-Fi)). Thus, you can configure the R&S EVSF1000 as a Wi-Fi access point for wireless communication from a remote device.

To connect the optional data-link-module (Wi-Fi)

1. Plug the provided USB-A to USB-C adapter cable in one of the USB-A connectors on the R&S EVSF1000.
2. Connect the other end of the adapter cable in the USB-C connector on the data-link-module (Wi-Fi).
3. Connect the provided data-link antennas to the RP-SMA connectors on the data-link-module (Wi-Fi).

To set up a data link (Wi-Fi) connection

Before you start the R&S EVSF1000, connect the data-link-module (Wi-Fi) to the R&S EVSF1000. Otherwise, the R&S EVSF1000 does not determine the IP information automatically.

1. Switch on the R&S EVSF1000.

The R&S EVSF1000 is configured as a Wi-Fi access point using a DHCP server. By default, the following settings are defined.



Setup - Wi-Fi Access Point	
Wi-Fi	On
SSID	EVSD900252
WPA-PSK key	RS900252
Channel	1 (2.4 GHz Wi-Fi 4)
Wi-Fi Speed	Low
Country	DE
IP	192.168.1.1
Netmask	255.255.255.0
Gateway	192.168.1.2
DHCP Server	On
Status	ON CH:1 WIDTH:20MHz

2. Usually, you can access the R&S EVSF1000 using the default IP address and Wi-Fi password without further configuration. The default IP address is 192.168.1.1. The default Wi-Fi password is RS<serial_number>, e.g. RS123456. For information on determining the serial number, see [Chapter 1.5.2.12, "Device ID"](#), on page 26.
If necessary, configure the data link information for your network.
For details, see [Chapter 8.4, "Data link \(Wi-Fi\) settings"](#), on page 215.

1.4.9 Performing an autocalibration

After setting up the R&S EVSF1000, perform an autocalibration to ensure the accuracy of the measurements. After initial setup, it is recommended that you perform an autocalibration every 2 months or if the difference of the environment temperature changes by more than 10 °C.

If valid data for automatic calibration is not available, the message "UNCAL" is displayed in the status line of the R&S EVSF1000 display.

To perform an autocalibration, you require remote access to the instrument via LAN. For details see [Chapter 1.6, "Operating basics"](#), on page 27.

To perform an autocalibration

Before performing an autocalibration, make sure that the instrument has reached its operating temperature (after about 15 minutes of operation; for details, refer to the data sheet).

A message in the status bar ("Instrument warming up...") indicates that the operating temperature has not yet been reached.

During the autocalibration procedure, do not apply any input signal to the R&S EVSF1000.

1. Using the VNC viewer, select [n] > [F8] > [F1]
2. Select "Start Autocal".
3. Press [Enter].

The "Setup - CAL" display shows the status for each calibration step. When completed, after a few minutes, all entries must have the status "OK".

For more information on autocalibration, see ["Auto-Calibration \(Cal\)"](#) on page 220.

1.5 Instrument tour

1.5.1 Front panel

This chapter describes the front panel, including all function keys and connectors.




Figure 1-2: R&S EVSF1000 - Front panel view

- 1 = Display
- 2 = USB connectors
- 3 = AF Out
- 4 = Carrying handle

1.5.1.1 Display

The display shows a basic set of measurement and configuration settings, including the currently used IP address for remote access.

1.5.1.2 USB connectors

The front panel provides two female USB connectors (USB-A, 2.0 standard) to connect devices like a memory stick or a USB keyboard.

The memory stick is used to store and reload instrument settings, to perform software updates and to export measurement data.

A standard USB keyboard can be used to configure the basic TCP/IP parameters.

For details, see [Chapter 1.6.1, "Basic configuration and status display"](#), on page 27.

1.5.1.3 AF out

Connector for a headset with a 3.5 mm jack plug.

1.5.1.4 Carrying handle

The carrying handle is used to insert and remove the R&S EVSF1000 from the flight inspection rack. You can also lift and carry the instrument by the handle.

1.5.2 Rear panel



Figure 1-3: R&S EVSF1000 - Rear panel view (basic model, without R&S EVSF1-B4 option)

- 1 = Power Supply
- 2 = RX2 In
- 3 = LAN
- 4 = RS-232 GPS
- 5 = Device ID with serial number and other labels
- 6 = PPS In
- 7 = RX 1 In



If the R&S EVSF1000 is provided with the optional slide-in hardware R&S EVSF1-B4 installed, the rear panel has an ARINC connector instead of the individual connectors. See [Chapter 1.5.2.6, "Optional ARINC connector"](#), on page 23.



Figure 1-4: R&S EVSF1000 - Rear panel view with ARINC connector (slide-in option R&S EVSF1-B4)

For the specification of the following interfaces, see the R&S EVSF1000 data sheet.

• Power supply	22
• RX1 in / RX2 in	23
• LAN (ethernet)	23
• RS-232 GPS	23
• PPS in	23
• Optional ARINC connector	23
• LF in (baseband/low frequency input)	25
• Demod out (baseband output)	25
• AF out	26
• Trigger in	26
• IP-Address select	26
• Device ID	26

1.5.2.1 Power supply

XLR connector for an external DC power source (11 V DC to 32 V DC).

For details, refer to ["Connecting to power"](#) on page 6 and [Chapter 1.4.4, "Connecting to power"](#), on page 13.

1.5.2.2 RX1 in / RX2 in

The RX input connectors are 50 Ω N connectors. Use the RX inputs to connect a receiving antenna (max. +13 dBm) to the R&S EVSF1000 for RF signal input.

1.5.2.3 LAN (ethernet)

Operate the R&S EVSF1000 remotely using the LAN connection (Fast Ethernet). The LAN connection can also be used to stream measurement data (TCP port 8000; for I/Q data: 8001 (RX1) or 8002 (RX2)). The data transfer rate is 100 Mbit/s.

Using a VNC viewer, you can perform hardkey and softkey tasks on the R&S EVSF1000 in a LAN via shortcuts on a remote keyboard.

For details about remote control, see [Chapter 9, "Remote commands"](#), on page 228.

1.5.2.4 RS-232 GPS

2-port RS232, 9-pin D-Sub connector for a GPS receiver providing NMEA protocol data. The NMEA protocol data is displayed and stored with the recorded data.

If R&S EVSF1-B4 is installed, the RS-232 GPS interface is integrated in the ARINC connector (see [Chapter 1.5.2.6, "Optional ARINC connector"](#), on page 23).

1.5.2.5 PPS in

SMA connector with 1 M Ω impedance. Provides a PPS signal from an external GPS device for precise synchronization during data logging.

If R&S EVSF1-B4 is installed, the PPS In interface is integrated in the ARINC connector (see [Chapter 1.5.2.6, "Optional ARINC connector"](#), on page 23).

1.5.2.6 Optional ARINC connector

This connector is available with option R&S EVSF1-B4 only.

Optionally, the R&S EVSF1000 can be provided with an ARINC connector on the rear panel instead of the individual connectors in the standard model (see [Figure 1-4](#)). This connector allows you to slide the R&S EVSF1000 out of a flight inspection rack easily without having to disconnect all cables from the instrument individually.

The ARINC connector provides connections to all input and output provided by connectors on the standard R&S EVSF1000, and some additional signals.




Figure 1-5: Pin assignment of ARINC connector

Table 1-2: Pin assignment of ARINC connector

Pin	Signal	Description	Cable type
1	SPEAKER+/AUDIO	Speaker/Audio out (AF Out)	single, AWG 20-24
2	SPEAKER-/AUDIO_GND	Speaker/Audio GND (AF Out)	single, AWG 20-24
3	ADR_SEL_IN	IP-Address-Select	single, AWG 20-24
4	ETH_DO-	LAN (Ethernet)	4x2 twisted paired, AWG 20-24
5	ETH_DI-	LAN (Ethernet)	4x2 twisted paired, AWG 20-24
6	USB_VBUS	USB 5V	2x2 twisted paired, AWG 20-24
7	USB_D+	USB Data+	2x2 twisted paired, AWG 20-24
8	V_DCIN_GND	Power	single, AWG 16-20
9	V_DCIN_+28V	Power	single, AWG 16-20
10	GND	Signal GND	single, AWG 20-24
11	TRIGGER_IN	Trigger-Input	single, AWG 20-24
12	ETH_DO+	LAN (Ethernet)	4x2 twisted paired, AWG 20-24
13	ETH_DI+	LAN (Ethernet)	4x2 twisted paired, AWG 20-24
14	USB_GND	USB GND	2x2 twisted paired, AWG 20-24
15	USB_D-	USB Data-	2x2 twisted paired, AWG 20-24

Pin	Signal	Description	Cable type
16	BB-OUT	Baseband-Output (Demod Out)	RG 316, AWG 20-24
17	GND	Signal GND	single, AWG 20-24
18	PPS_IN	PPS-IN	RG 316, AWG 20-24
19	GPS_5V_SUPPLY	GPS RX/ANT-Supply	single, AWG 20-24
20	GPS_CTS	RS232-GPS	single, AWG 20-24
21	GPS_RTS	RS232-GPS	single, AWG 20-24
22	GPS_TXD	RS232-GPS	single, AWG 20-24
23	V_DCIN_GND	Power	single AWG 16-20
24	V_DCIN_+28V	Power	single AWG 16-20
25	BB-IN	Baseband-Input (LF-IN)	single, AWG 20-24
26	GPS_GND	RS232-GPS	single, AWG 20-24
27	GPS_PPS_IN	RS232-GPS PPS-IN	single, AWG 20-24
28	GPS_RXD	RS232-GPS	single, AWG 20-24
29	RX1 (coaxial inlay)	RX1 Antenna	RG 223/ RG 142/ RG 400, AWG 20-24
30	spare	spare	RG 223/ RG 142/ RG 400, AWG 20-24
31	spare	spare	RG 223/ RG 142/ RG 400, AWG 20-24
32	RX2 (coaxial inlay)	RX2 Antenna	RG 223/ RG 142/ RG 400, AWG 20-24

1.5.2.7 LF in (baseband/low frequency input)

This connector is available with option R&S EVSF1-B4 only.

Provides an AF signal or signals with a very low IF (<25 kHz) to the R&S EVSF1000 for further analysis of typical AF parameters. Furthermore, LF input allows for analysis of non-directional beacon (NDB) signals from 190 kHz to 1750 kHz.

When using the R&S EVSF1-Z2, use the BNC connector, 50 Ω /20k Ω .

Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.

1.5.2.8 Demod out (baseband output)

This connector is available with option R&S EVSF1-B4 only.

Outputs a demodulated (baseband) signal for connected devices, for example an oscilloscope.

When using the R&S EVSF1-Z2, use the BNC connector, 50 Ω /20k Ω .

1.5.2.9 AF out

This connector is available with option R&S EVSF1-B4 only.

Provides AF output to connected headphones or a loudspeaker (optimized for 8 Ω).
When using the R&S EVSF1-Z2, audio output is sent to the speaker.

1.5.2.10 Trigger in

This connector is available with option R&S EVSF1-B4 only.

Provides an external trigger for data recording. The voltage level is 3.3 V to 12 V. The typical input impedance is 1 M Ω .

When using the R&S EVSF1-Z2, use the BNC connector, 50 Ω /20k Ω .

1.5.2.11 IP-Address select

This connector is available with option R&S EVSF1-B4 only.

Determines which of two possible IP addresses is used, to distinguish between two instruments in a single rack.

(See "[TCP/IP Address](#)" on page 214).

If this pin is not connected, the address configured as "TCP/IP Address 1" is used.

If this pin is connected to ground, the address configured as "TCP/IP Address 2" is used.

1.5.2.12 Device ID

The unique device identifier is provided as a barcode sticker on the rear panel of the R&S EVSF1000.

It consists of the device order number and a serial number.



The serial number is used to define the **default instrument name**, which is:

<Type><variant>-<serial_number>

For example, EVSF1000-123456.

The instrument name is required to establish a connection to the instrument in a LAN.

1.5.3 Accessories

Following accessories are available for rack installation:

- Slide-in option (R&S EVSF1-B4)
Provides an ARINC connector on the rear panel of the R&S EVSF1000 which can be connected to the rack tray (R&S EVSF1-Z1 with connector).
While the tray remains connected to the aircraft permanently, you can remove the R&S EVSF1000 quickly and easily, without having to connect and disconnect the instrument from the power supply and other devices.
- Installation tray with connector plate (R&S EVSF1-Z1)
Allows you to mount the instrument in a flight inspection rack securely.
Using the connector plate, you can remove and replace the R&S EVSF1000 quickly and easily.
- Service adapter (R&S EVSF1-Z2)
The service adapter combines an ARINC connector with the common connectors provided on the rear panel of a conventional R&S EVSF1000. It allows you to connect a power supply and any other signal input and output devices to a R&S EVSF1000 with the slide-in hardware outside an aircraft.

1.6 Operating basics

The R&S EVSF1000 is designed for flight inspection and is thus optimized for remote operation, via predefined commands. It does not have a graphical user interface for manual interaction.

Nevertheless, the instrument can also be controlled manually, by simulating a user interface on a remotely connected device, and using a connected keyboard. Basic operation and status information is also available on a mini display directly on the R&S EVSF1000.

1.6.1 Basic configuration and status display

To connect to the R&S EVSF1000 from a remote device, you require connection information, such as the IP address. It is also helpful to obtain the operating status of the instrument before connecting to it. This basic information is displayed in the mini display directly on the R&S EVSF1000.




Figure 1-6: R&S EVSF1000 mini display

The following information is displayed in the mini display.

Measurement information for each receiver board (RX1/RX2)

In addition to the current measurement mode, measurement-specific information is provided.

For example, for "ILS LOC" mode (see [Chapter 4.1.3, "ILS localizer and glidepath measurements and results"](#), on page 44):

- "CH" : Receiver channel
- "F" : Receiver frequency
- "DDM" : ILS DDM
- "SDM" : ILS SDM
- "LEV" : Currently measured power level
- "ID" : Decoded ID of transmitter



For details on GBAS/SCAT-I measurement information in the status display, see [Chapter 6.2, "GBAS/SCAT-I status display"](#), on page 159.

Network settings (NET)

See [Chapter 8.3, "LAN \(remote\) settings"](#), on page 211

- **"DHCP"** : DHCP usage
- **"IP"** : IP address of the R&S EVSF1000
- **"CLIENT"** : IP address of connected client

Operating status of the R&S EVSF1000

See [Chapter 8.6, "Instrument configuration and operating status settings"](#), on page 220

- **"HW"** : Hardware status("OK"/"ERROR")
- **"GPS"** : Availability of GPS signal

Current date and time

1.6.2 Basic connection settings

To operate the R&S EVSF1000 from a remote device, you require connection information.

By default, the R&S EVSF1000 is set to use the static IP address 10.255.255.98. The assigned IP address and DHCP state of the R&S EVSF1000 is provided in the mini display on the front panel.

Use this IP address for the initial connection from a remote device to the R&S EVSF1000.

When using DHCP, the IP address is assigned to the devices dynamically. In this case, if a dynamic name server (DNS) is available, you can use the permanent instrument name to access the R&S EVSF1000. The default instrument name is EVSF<serial_number>, for example, EVSF1000-123456. For information on determining the serial number, see [Chapter 1.5.2.12, "Device ID"](#), on page 26.

To change the settings, see [Chapter 8.3, "LAN \(remote\) settings"](#), on page 211.

1.6.3 Manual operation from a VNC viewer

You can operate the R&S EVSF1000 manually from a connected PC using a keyboard.

You merely require a VNC viewer application, of which a variety is available on the Internet free of charge.

Using a VNC viewer application, you simply connect to the instrument, defined by its IP address. The display of the R&S EVSF1000 is shown on the control PC. The keys and other graphical user interface elements are operated using associated keyboard shortcuts on the connected keyboard.



Operation via VNC is not possible during remote control (indicated by "Remote" in the status bar). To switch from remote control to manual operation, press [ESC].

Access to the R&S EVSF1000 via VNC can be protected by a password. In this case, enter *instrument* as the password in the login window.

(See also [Chapter 8.3, "LAN \(remote\) settings"](#), on page 211.)

1.6.3.1 Understanding the display information

The following figure shows a typical screen display for the R&S EVSF1000. All different screen elements are labeled. They are explained in more detail in the following sections.




Figure 1-7: R&S EVSF1000 - GUI overview

1 = Measurement settings area (numeric modes only)

2 = Measurement result area

3 = Softkeys to edit settings and activate functions

4 = Status bar

Measurement settings and results area

During a measurement, the available settings are displayed at the top of the screen; the measurement results at the bottom. If a general instrument setting or data manage-

ment function is selected, the settings and information are displayed in the main part of the screen.

Which settings and results are displayed depends on the current measurement or instrument function. See the following chapters for details:

- [Chapter 2, "Measurements and results"](#), on page 37
- [Chapter 7, "Data management"](#), on page 198
- [Chapter 8, "Common instrument settings"](#), on page 209

Softkeys

Softkeys are virtual function keys whose actual function is defined by the software, depending on the currently selected measurement mode or key, or both.



Sometimes, more functions are available than softkeys can be displayed at the same time. In this case, a second menu of functions is available, indicated by "1/2" and "2/2" beneath the softkeys in the display.

To switch between the two menus of softkey functions, press the "More softkeys" key beneath the softkeys on the front panel of the R&S EVSF1000.

Softkeys can perform a function directly, or open a dialog or submenu with further settings and functions. Some softkeys are directly associated with an input field in the measurement settings area of the window. If the softkey shows a vertical blue line at the edge, you can edit the value of the corresponding setting directly in the measurement settings area of the window. If the blue line is not shown, the setting is read-only. To toggle between the edit mode and read-only mode, select the softkey again.



Figure 1-8: Softkey with an associated input field

Status bar


The status bar at the bottom of the screen contains information on the operating status of the instrument.

- Current list of data recording and size of this list
(See [Chapter 7.2, "Recording measurement data"](#), on page 200)
- Local or remote operation (see [Chapter 1.6.4, "Remote control"](#), on page 35)

1.6.3.2 Keyboard commands for operation via a VNC viewer

[Keyboard commands \(VNC viewer\)](#) shows the mapping between the keyboard shortcuts and the interface elements on the R&S EVSF1000.

Table 1-3: Keyboard commands (VNC viewer)


Keyboard	Usage
y	Preset
c	Audio
v	Display
b	Help
n	Setup
m	Mode
z	Undo
r	Redo
PAGE UP	Field right
PAGE DOWN	Field left
x	Screenshot
a	Meas
s	Config
F1	Softkey 1
F2	Softkey 2
F3	Softkey 3
F4	Softkey 4
F5	Softkey 5
F6	Softkey 6
F7	Softkey 7
F8	 Show additional softkeys
k	Trigger
l	Single
ESC	ESC
0	0
1	1
4	4
7	7
q	CH/FREQ
d	MTime

Keyboard	Usage
BACKSPACE	Back
ENTER	Enter
.	.
2	2
5	5
8	8
w	Ampt
F9	Hz
3	3
6	6
9	9
e	BW (Bandwidth)
F10	kHz
F11	MHz
F12	GHz
p	Record
i	Marker

1.6.3.3 Changing settings and activating functions

All functions available on the R&S EVSF1000 can be accessed using the keys on the external keyboard. Some keys provide a softkey menu on the display with further functions and settings.

1. Select a key as described in [Table 1-3](#) to activate a function directly, or to display a softkey menu.



2. Select the key for the setting or function as required.
If necessary, select [F8] to switch to the second softkey menu.

The function is activated, or a new window is displayed to view or change specific settings.

3. To set the focus on a specific setting in the displayed window, scroll through the individual settings by pressing the Up and Down arrow keys.

4. Enter a numeric or alphanumeric value as described in [Chapter 1.6.3.4, "Entering data"](#), on page 34.
5. Confirm the new setting and remove the focus by pressing [ENTER].

1.6.3.4 Entering data

You enter data in input fields using the external keyboard, as described in [Table 1-3](#).

Entering numeric parameters

If a field requires numeric input, the keypad provides only numbers.

1. Define the parameter value by doing one of the following:
 - Change the currently used parameter value by pressing the Up or Down arrow keys.
 - Enter the parameter value using the keypad.
2. To define the unit, press the corresponding unit key.
The unit is added to the entry.
3. If the parameter does not require a unit, confirm the entered value by pressing [ENTER] or any of the unit keys.

Entering numbers and (special) characters via the keypad

If a field requires alphanumeric input, use the keypad on the external keyboard. Every alphanumeric key represents several characters and one number. The decimal point key (.) represents special characters, and the sign key (-) toggles between capital and small letters. The assignment of keys to characters is provided in [Table 1-4](#).

1. Press the key once to enter the first possible value.
All characters available via this key are displayed.
2. To choose another value provided by this key, press the key again, until your desired value is displayed.
3. With every key stroke, the next possible value of this key is displayed. If all possible values have been displayed, the series starts with the first value again. For information on the series, refer to [Table 1-4](#).
4. To change from capital to small letters and vice versa, press the sign key (-).
5. After entering a value, wait for 2 seconds to use the same key again.

Entering a blank

- Press the "0" key for 2 seconds.

Correcting an entry

1. Using the arrow keys, move the cursor to the right of the entry you want to delete.
2. Press the [BACK] key.

The entry to the left of the cursor is deleted.

3. Enter your correction.

Completing the entry

- Press [ENTER].

For numeric values, the default unit is appended to the numeric input.

To enter a value using a different unit, select the corresponding key.

Aborting the entry

- Press the [ESC] key.

The previous entry is restored.

Table 1-4: Keys for alphanumeric parameters

Key name (upper inscription)	Series of (special) characters and number provided
7	7 μ Ω ° € ¥ \$ ¢
8	A B C 8 Å Æ Ä Ç
9	D E F 9 É
4	G H I 4
5	J K L 5
6	M N O 6 Ñ Ö
1	P Q R S 1
2	T U V 2 Ü
3	W X Y Z 3
0	<blank> 0 – @ + / \ < > = % &
.	. * : _ , ; " ' ? () #
–	<toggles between capital and small letters>

1.6.4 Remote control

You can control the R&S EVSF1000, including data transfer, remotely from another device using the LAN connection (Fast Ethernet).

See [Chapter 1.6.2, "Basic connection settings"](#), on page 29.

Remote control is performed using predefined remote commands which are sent from the control device to the R&S EVSF1000. The R&S EVSF1000 can also return queried data to the control device.

For details on the available remote commands, see [Chapter 9, "Remote commands"](#), on page 228.

While in remote control, the R&S EVSF1000 display indicates "Remote" in the status bar. During remote control, the instrument is locked for manual operation via VNC. To return to manual operation, press [ESC].

2 Measurements and results

The R&S EVSF1000 provides both numerical and graphical results, depending on the current measurement task.

Different measurement tasks are performed in individual measurement modes, some of which are optional. The individual measurement modes are described in detail in the subsequent chapters of this documentation.

If an optional second receiver board (R&S EVSG-B1 Second Signal Processing Unit) is installed, each receiver board can be configured to perform different measurement tasks. Thus, you can perform two different measurements on the same input signal simultaneously. Then you select the receiver board whose results are displayed in the display settings (see "RX Unit 1 / RX Unit 2" on page 210).




Figure 2-1: Measurement mode selection

Measurement modes with numerical results

The following measurement modes provide numerical results:

- ILS LOC mode - determines localizer signal parameters
- ILS GP mode - determines glidepath signal parameters
- ILS MB mode - determines marker beacon signal parameters
- VOR mode (R&S EVSG-K2 VOR analysis) - determines modulation and signal parameters, as well as voice identifier parameters

- COM (R&S EVSG-K6 COM analysis) - determines signal parameters from VHF/UHF communication channels
- NDB mode (R&S EVSG1-K7 LF-Analysis) - analyzes non-directional beacon signals

Measurement modes with graphical results

The following measurement modes provide graphical results:

- RF Spectrum mode (R&S EVSG-K10 RF spectrum analysis) - displays the power vs. frequency diagram (spectrum) for a variable frequency range of the input signal
- IF Spectrum mode (R&S EVSG-K10 RF spectrum analysis) - displays an enlarged view of the spectrum for a fixed frequency of the input signal
- AF Spectrum mode (R&S EVSG-K11 AF spectrum analysis) - displays the spectrum of a demodulated RF signal with AM components
- AF Time Domain mode (R&S EVSG-K12 Time domain analysis) - displays the frequency vs. time diagram of the input signal, similar to an oscilloscope



Generally, each mode is configured individually. When you switch modes, the most recently defined settings for that mode are applied.

However, graphical results can also be displayed directly from the measurement modes with numeric results. In this case, the settings for the current mode are applied to the graphical results.

If the original measurement mode analyzes multiple carriers, you must select the carrier for which you want to see the graphical results when you switch the mode.

Measurement modes with both numerical and graphical results

The following measurement modes provide both numerical and graphical results:

- R&S EVSG-K4 GBAS analysis - displays measured and decoded information from GBAS/SCAT-I sequences, frames, and slots, and graphical displays for individual slots

Remote commands to retrieve results:

[GETMDEF](#) on page 230

[GETMEAS](#) on page 229

[GBAS:GETMDEF](#) on page 326

[GBAS:GETMEAS](#) on page 327

Common Numerical Measurement Mode Settings

The following settings are displayed for most numerical measurement modes.

RX board (RX1 RX2)	39
Measurement mode	39
Channel (CH)	39
Frequency (FREQ)	39
RF attenuation (Att)	39

Channel definition (1F/2F) - ILS LOC and ILS GP mode only.....	39
Level correction (Lev Corr).....	39
Bandwidth (IF BW).....	39
Measurement time (MTime).....	39

RX board (RX1 | RX2)

The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.

Measurement mode

The currently active measurement mode on the active receiver board, e.g. "ILS LOC". See [Chapter 3.3, "Measurement mode"](#), on page 41.

Channel (CH)

The receiver frequency channel on the active receiver board according to the ICAO frequency list. See ["Channel frequency configuration \(CH FREQ\)"](#) on page 67.

Frequency (FREQ)

The measured frequency on the active receiver board. See ["Channel frequency configuration \(CH FREQ\)"](#) on page 67.

RF attenuation (Att)

The used attenuation mode; see also ["RF Mode"](#) on page 69.

Channel definition (1F/2F) - ILS LOC and ILS GP mode only

The ILS Localizer and Glidepath measurements can detect both course and clearance data simultaneously. Alternatively, the individual channels can be measured only, or any one or two user-defined frequencies. By default, a wideband measurement is performed. The displayed measurement results depend on the selected channel and frequency configuration.

See [Chapter 4.1.4.2, "Channel and frequency configuration"](#), on page 64.

Level correction (Lev Corr)

The applied level correction by a transducer. See ["Transducer Correction"](#) on page 69.

Bandwidth (IF BW)

Bandwidth on which the measurement is performed. Depends on the [Channel definition \(1F/2F\) - ILS LOC and ILS GP mode only](#). See [Chapter 4.1.4.4, "Bandwidth \(BW\)"](#), on page 69.

Measurement time (MTime)

The duration of a single measurement. See [Chapter 4.1.4.6, "Setting the measurement time \(MTime\)"](#), on page 74.

3 Configuring the input signal and measurement mode

The following settings are common to all measurement modes. They define which data is measured and how, and are indicated at the top of the measurement window.


- [Input signal settings](#)..... 40
- [Receiver board](#).....40
- [Measurement mode](#)..... 41

3.1 Input signal settings

Access VNC: [n] > [F1]

The following settings configure the receiver signal to be measured by the R&S EVSF1000.

For some measurement modes, you can switch the type of signal input. See the description of the individual modes.



[Correction RX 1 In/ Correction RX 2 In](#)..... 40

Correction RX 1 In/ Correction RX 2 In
Configures the correction of the RX 1/ RX 2 input signal, respectively (in dB).
This value is subtracted from all levels and compensates effects of upstream lines and attenuators.

3.2 Receiver board

If a second receiver board is installed (requires the R&S EVSG-B1 Second Signal Processing Unit option), each receiver board can be configured to perform different measurement tasks.

To select the receiver board via VNC

1. Press the [m] key on the remote keyboard.

2. Press the [PAGE UP] or [PAGE DOWN] keys to toggle between the "RX Unit 1" and "RX Unit 2".
3. Press [Enter] to confirm the selection.

Remote command:

[CH](#) on page 234

3.3 Measurement mode

The measurement mode determines the type of signal for which the measurement is performed (see [Chapter 2, "Measurements and results"](#), on page 37).

To select a measurement mode via VNC

1. Press the [m] key on the remote keyboard.
2. Select the required measurement mode using the arrow keys.
3. Press [Enter] to confirm the selection.

Remote commands:

[MODE_LOC](#) on page 260

[MODE_GP](#) on page 260

[MODE_MB](#) on page 293

[MODE_VOR](#) on page 300

[MODE_COM](#) on page 310

[MODE_FSCAN](#) on page 338

[MODE_IFSPECT](#) on page 343

[MODE_FFT](#) on page 348

[MODE_SCOPE](#) on page 355

[MODE_GBAS](#) on page 324

[MODE_NDB](#) on page 333

4 Numeric measurement modes

• ILS localizer and ILS glidepath (GP) modes.....	42
• R&S EVSG-K3 Marker beacon analysis.....	75
• R&S EVSG-K2 VOR analysis.....	85
• R&S EVSG-K6 COM analysis.....	105
• Non-directional beacon mode.....	115

4.1 ILS localizer and ILS glidepath (GP) modes

Access VNC: [m] > Down arrow key

The ILS Localizer and Glidepath measurements demodulate the AM components of the ILS signal and calculate characteristic parameters such as the modulation depth and frequency or phase for specific components. Furthermore, an FFT is performed on all components of the AF signal. The resulting AF spectrum allows you to measure the required components and their distortions (harmonics).

Using the option R&S EVSG1-K7 LF-Analysis, you can also analyze the AF components of the ILS signal to determine AF parameters of the carrier.

Furthermore, you can use the LF input to measure signals with a very low intermediate frequency (<25 kHz). Such signals are provided as output at test points of a transmitter, for example, for tuning purposes.

Remote command:

[MODE_LOC](#) on page 260

[MODE_GP](#) on page 260

• Localizer basics.....	42
• Glide slope basics.....	43
• ILS localizer and glidepath measurements and results.....	44
• ILS localizer and glidepath configuration.....	63

4.1.1 Localizer basics


The localizer transmitter is located near the end of the runway (nearest to the start of the aircraft approach). Typically, horizontally aligned antennas transmit two intersecting main beams beside one another at carrier frequencies between 108 MHz and 112 MHz. As seen from the approaching aircraft coming in for a landing, the left beam is usually modulated at 90 Hz and the right beam at 150 Hz.

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM).

$$DDM = m(x90) - m(x150)$$

The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too far to the left and must turn to the right
- Predominance of the 150 Hz beam: the aircraft is too far to the right and must turn to the left
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.



Course and clearance signals

The landing path is divided into the region further away from the runway, referred to as the course, and the runway itself, referred to as the clearance. Localizers are positioned in both areas, however they transmit their ILS signals using different frequencies, one that must travel farther, one for close-up. The frequencies differ only in a few kilohertz. The aircraft always receives both signals, and cannot (and need not) distinguish the two. However, for test purposes, it can be useful to measure the signals individually.

Morse code identification signal

The localizer not only allows the aircraft to determine its position, it also provides identification of the ILS transmitter. The localizer periodically transmits a Morse code at 1020 Hz which uniquely identifies the transmitter. The receiver thus knows that the ILS is operating correctly and that it is receiving the correct signal. The glide slope station does not transmit an identification signal.

4.1.2 Glide slope basics

The following description is taken from the Rohde & Schwarz Application Note [1MA193: "Aeronautical radio navigation measurement solutions"](#).

The glide slope transmitter is located near the end of the runway (nearest to the start of the aircraft approach).





Figure 4-1: Approach navigation using instrument landing system (ILS)

Typically, vertically aligned antennas transmit two intersecting main beams on top of one another at carrier frequencies between 329 MHz and 335 MHz. The top beam is usually modulated at 90 Hz and the beam below at 150 Hz.

The information on position is provided after demodulation of the beam signals by evaluating the difference in depth of modulation (DDM). The following scenarios are possible:

- Predominance of the 90 Hz beam: the aircraft is too high and must descend
- Predominance of the 150 Hz beam: the aircraft is too low and needs to climb
- The signal strength from both beams is equal: the aircraft is in the center, on the right course.

If there is a predominance of the 90 Hz beam, then the aircraft is too high and must descend. A predominant 150 Hz means that the aircraft is too low and needs to climb.



4.1.3 ILS localizer and glidepath measurements and results

A single receiver board in the R&S EVSF1000 can measure data at two different receiver frequencies at the same time. Therefore, the ILS Localizer and Glidepath measurements can detect both course and clearance data simultaneously, and display the individual results. Alternatively, the individual channels can be measured only, or any one or two user-defined frequencies. By default, a wideband measurement is per-

formed to obtain an initial overview of the input signal and determine the basic signal characteristics. The displayed measurement results depend on the selected channel and frequency configuration.

Autotune function

An autotune function is available to determine the precise frequencies of the signal components automatically. Thus, the demodulation bandwidth can be selected very precisely. Automatic mode is indicated by "Autotune" in the measurement settings area, followed by the current processing status.

The autotune process consists of the following steps:

1. "Search": the R&S EVSF1000 searches the input signal for peaks. You can define a power threshold that the carrier must exceed to be detected ("[Carrier Thresh](#)" on page 67).
2. "Check": the R&S EVSF1000 checks whether the detected peak is a valid ILS signal, based on the detected modulation and S/N ratio.

A valid signal is indicated by a green DDM measurement result, see "[DDM 90-150](#)" on page 55. In the recorded dataset, the STIOCPM status indicates a "V" for valid (see "[Status flags](#)" on page 63).

3.
 - "Auto Lock" option (default): "Lock": the R&S EVSF1000 remains tuned to the valid ILS signal frequency.
The frequency remains locked until:
 - You switch measurement modes
 - You change the channel or frequency settings
 - You select the [Find Carrier](#) function.
 In this case, a new search starts.
 - "Auto Retune" option: "Found": As long as the R&S EVSF1000 determines a valid ILS signal, it remains tuned to that frequency. If the signal becomes invalid at that frequency, the R&S EVSF1000 returns to the "Search" process.



Adapting the frequency in autotune mode

The autotune function sets the measurement filter position such that the detected frequency is in the center of the filter bandwidth. While the frequency is locked, the filter position remains unchanged. If the bandwidth is narrow and the signal frequency changes, e.g. due to changes of the transmitter, the signal may no longer be covered completely by the measurement filter. In this case, the measurement results are distorted. If you assume that the ILS signal frequency has possibly changed, we recommend performing a new search using the [Find Carrier](#) function.

Measurement result views


Due to the large number of different signal parameters, the ILS Localizer and Glidepath measurements provide multiple views for the measurement results.



Switching from numeric to graphical results

You can display graphical results directly from the ILS Localizer or Glidepath mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

The graphical results are only available for a single carrier. Thus, when you switch to a graphical measurement mode from an ILS mode, you must select the carrier for which you want to see the graphical results. When you select the softkey, a submenu is displayed to select the carrier.



To return from the graphical results to the ILS Localizer or Glidepath mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.1, "R&S EVSG-K10 RF spectrum analysis"](#), on page 125
- [Chapter 5.2, "IF spectrum analysis"](#), on page 130
- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143



Figure 4-2: ILS Localizer mode main results view

The following settings are displayed in the measurement settings area of the ILS Localizer/ ILS GS mode:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "ILS GP". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- "CH"
Receiver frequency channel, see ["Channel setup"](#) on page 64
- "Freq"
Nominal measurement frequency of the RF signal, see ["Freq"](#) on page 68.
- RF attenuation ("Att")
The used attenuation mode; see also ["RF Mode"](#) on page 69.
- Frequency selection "1F/2F"
See ["Carrier configuration \(1F/2F Config\)"](#) on page 65
- "Autotune"
Status of the automatic carrier selection, see ["Autotune function"](#) on page 45
- "Lev Corr"
Applied level correction, see ["Transducer Correction"](#) on page 69
- "IF BW"
Measurement bandwidth, see [Chapter 4.1.4.4, "Bandwidth \(BW\)"](#), on page 69
- Measurement time ("MTime")
See [Chapter 4.1.4.6, "Setting the measurement time \(MTime\)"](#), on page 74.

Low frequency (LF In) measurements for ILS signals

Using the option R&S EVSG1-K7 LF-Analysis, you can also analyze the AF components of the ILS signal to determine AF parameters of the carrier.

Furthermore, you can use the LF input to measure signals with a very low intermediate frequency (<25 kHz). Such signals are provided as output at test points of a transmitter, for example, for tuning purposes.




Figure 4-3: AF signal analysis in ILS GP mode

For LF input, the following settings are displayed:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "ILS GP". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- ("Range")
Sensitivity of the measurement. See ["Range"](#) on page 72.
- LF Input type ("LF In Mode")
See ["LF In Mode"](#) on page 71.
- "LF coupling"
AC or DC coupling for LF input, see ["Coupling"](#) on page 72
- Measurement Bandwidth ("AF In BW")
Measurement bandwidth for LF input. See ["AF In BW"](#) on page 139.
- Resolution bandwidth for LF input ("AF Res BW")
Resolution bandwidth with which the AF signal measurement is performed. See ["IF/AF Bandwidth \(Dist/ID\)"](#) on page 73.
- Measurement time ("MTime")
See [Chapter 4.1.4.6, "Setting the measurement time \(MTime\)"](#), on page 74.

Remote command:

VIEW_LLZ on page 270

• RF level and frequency display.....	49
• IF spectrum preview.....	50
• LF level, frequency, and spectrum display.....	51
• ILS localizer and glidepath main view.....	52
• ILS localizer distortion view.....	57
• ILS localizer ID analysis view.....	59
• ILS localizer recording view.....	62

4.1.3.1 RF level and frequency display

The measured RF power and frequency of the input signal are displayed both numerically and graphically.




Figure 4-4: RF level display

The following results are provided:

- Numeric power level in dBm ("Lev")
For measurements on two frequencies: individual and sum power levels
- Measured frequency offset to the nominal frequency in kHz
- Numeric frequency offset of measured power
- Bargraph indicating the power and a color-coded overload state, where:
 - **Red:** overload state, check message
 - **Yellow:** power approaching overload state
 - **Green:** power in a valid range
- If applicable: overload messages



Overload messages

The following messages indicate an overload:

- "RF Overload"
Overload of the input mixer or of the analog IF path.
- "IF Overload"
Overload of the IF signal.
- "ADC Overload"
The dynamic range of the AD-converter is exceeded (clipping).

A combination of these overloads is also possible.

In all cases, set the RF attenuation to normal or low distortion (for RF input), or reduce the input level.

In recorded data lists, overloads are indicated by an "O", see ["Status flags"](#) on page 63.

Remote commands to retrieve results:

[LA?](#) on page 231

[RF?](#) on page 231

ILS LOC/GS mode:

[FSINGLE](#) on page 284

[FCRS](#) on page 284

[FCLR](#) on page 284

[LCRS](#) on page 285

[LCLR](#) on page 285

4.1.3.2 IF spectrum preview

A preview of the measured spectrum (power level vs. frequency) for the IF (intermediate frequency) signal is provided. The center frequency is the nominal channel frequency. The frequency range shows the measured bandwidth. The power range is selected such that the noise level remains visible.




Figure 4-5: IF spectrum preview

This preview spectrum allows you to check if the current measurement settings are appropriate, such as the bandwidth or frequency offsets. For a larger, more detailed spectrum diagram, select one of the graphical Spectrum modes. If you switch to such a mode directly from a numeric measurement mode, the current measurement settings are applied to the spectrum automatically.

4.1.3.3 LF level, frequency, and spectrum display

For LF or low frequency input, the measured AF power and frequency of the input signal are displayed both numerically and graphically.



Figure 4-6: LF level display

The following results are provided:

Lev.....	51
DC.....	51
Vmax(pp).....	51
Low IF frequency.....	51
Power bargraph.....	52
IF spectrum preview.....	52

Lev

Numeric power level in Volt

Remote command:

[LLZ_BB_LEV_V](#) on page 287

DC

AF mode only: Numeric power level of the DC component in Volt

This value indicates the carrier power level (measured at 0 Hz).

Remote command:

[LLZ_BB_DC_V](#) on page 287

Vmax(pp)

Maximum peak-to-peak power level in Volt

Remote command:

[LLZ_BB_VMAXPP_V](#) on page 288

Low IF frequency

Low IF only: Measured frequency offset to the nominal frequency in kHz

Remote command:

[FSINGLE](#) on page 284

Power bargraph

Bargraph indicating the power (blue) and a color-coded overload state, where:

- **green:** power in a valid range
- **Yellow:** power approaching overload state
- **Red:** overload state, check message

IF spectrum preview

A preview of the measured IF spectrum (power level vs. frequency) for the AF signal is provided. The center frequency is 0 Hz (AF mode) or the IF offset (LF mode). The frequency range shows the measured bandwidth.




Figure 4-7: IF spectrum preview

Remote command:

[FFT_GETSPECT](#) on page 354

4.1.3.4 ILS localizer and glidepath main view

The ILS Localizer and Glidepath main view provides the following results:



Figure 4-8: ILS Localizer main view




Figure 4-9: ILS Glidepath main view



Figure 4-10: ILS LF Input main view

DDM 90-150.....	55
SDM 90,150.....	56
AM 90 Hz.....	56
Freq 90 Hz.....	56
AM 150 Hz.....	56
Freq 150 Hz.....	56
PHI 90/150.....	56
ID Code.....	56

DDM 90-150

Difference in depth of modulation (DDM) between 90 Hz and 150 Hz AM signal ($m_{90\text{ Hz}} - m_{150\text{ Hz}}$)

Note: The DDM value is also displayed graphically as a bargraph for quick evaluation. A green DDM value indicates that a valid ILS signal has been determined.

Remote command:

- DD0 on page 283
- DD1 on page 283
- DCLR on page 283
- DCRS on page 283

SDM 90,150

Sum in Depth of Modulation (SDM); arithmetic sum of the modulation depth of the 90 Hz and the 150 Hz components without any influence of the phase between the components.

Remote command:

[SD0](#) on page 287

[SD1](#) on page 287

[SCLR](#) on page 286

[SCRS](#) on page 286

AM 90 Hz

AM modulation depth of 90 Hz ILS component

Remote command:

[AM2](#) on page 281

[AM2CLR](#) on page 281

[AM2CRS](#) on page 281

Freq 90 Hz

AF frequency of 90 Hz ILS component

Remote command:

[AF2](#) on page 280

AM 150 Hz

AM modulation depth of 150 Hz ILS component

Remote command:

[AM3](#) on page 281

[AM3CLR](#) on page 281

[AM3CRS](#) on page 282

Freq 150 Hz

AF frequency of 150 Hz ILS component

Remote command:

[AF3](#) on page 280

PHI 90/150

Phase angle measurement between 90 Hz and 150 Hz AM signal (90 Hz = reference signal); measurement range: ± 60 degrees

Remote command:

[PH](#) on page 285

ID Code

Morse-decoded ID with three or four letters.

Remote command:

[AC8](#) on page 280

[AC8](#) on page 304

4.1.3.5 ILS localizer distortion view

The ILS Localizer Dist view comprises all measurement parameters for the determination of the distortion factors for the 90 Hz / 150 Hz signal components.




Figure 4-11: ILS Localizer Distortion view

AM 90 Hz.....	57
K2 90 Hz.....	58
K3 90 Hz.....	58
K4 90 Hz.....	58
THD 90 Hz.....	58
Res. FM 90.....	58
AM 150 Hz.....	58
K2 150 Hz.....	58
K3 150 Hz.....	59
K4 150 Hz.....	59
THD 150 Hz.....	59
Res. FM 150.....	59
AM (90+150).....	59

AM 90 Hz

AM modulation depth of 90 Hz ILS component

Remote command:

[AM2](#) on page 281

[AM2CLR](#) on page 281

[AM2CRS](#) on page 281

K2 90 Hz

Distortion 2nd order, 90 Hz signal

Remote command:

[K2_90](#) on page 284

K3 90 Hz

Distortion 3rd order, 90 Hz signal

Remote command:

[K3_90](#) on page 285

K4 90 Hz

Distortion 4th order, 90 Hz signal

Remote command:

[K4_90](#) on page 285

THD 90 Hz

Total Harmonic Distortion (THD), 90 Hz signal

Remote command:

[THD_90](#) on page 287

Res. FM 90

Residual frequency modulation for 90 Hz signal

Configure the filter using "[Res. FM Filt. \(ILS only\)](#)" on page 70.

Remote command:

[RESIDFM_90](#) on page 286

AM 150 Hz

AM modulation depth of 150 Hz ILS component

Remote command:

[AM3](#) on page 281

[AM3CLR](#) on page 281

[AM3CRS](#) on page 282

K2 150 Hz

Relative amplitude of an AF signal's second harmonic, calculated as:

<amplitude of second harmonic> / <amplitude of fundamental>

For 90 Hz + 150 Hz:

<mean amplitude of second harmonics> / <mean amplitude of fundamentals>

Remote command:

[K2_150](#) on page 284

K3 150 Hz

Relative amplitude of an AF signal's third harmonic, calculated as:

$\langle \text{amplitude of third harmonic} \rangle / \langle \text{amplitude of fundamental} \rangle$

For 90 Hz + 150 Hz:

$\langle \text{mean amplitude of third harmonics} \rangle / \langle \text{mean amplitude of fundamentals} \rangle$

Remote command:

[K3_150](#) on page 284

K4 150 Hz

Relative amplitude of the fourth harmonic for the 150 Hz signal component

Remote command:

[K4_150](#) on page 285

THD 150 Hz

Total Harmonic Distortion (THD) for the 150 Hz signal component

Remote command:

[THD_150](#) on page 287

Res. FM 150

Residual frequency modulation for 150 Hz signal

Remote command:

[RESIDFM_150](#) on page 286

AM (90+150)

Total AM modulation depth of the 90 Hz and the 150 Hz components, taking the phase between the components into account.

Remote command:

[AMMOD240](#) on page 282

4.1.3.6 ILS localizer ID analysis view

The ILS Localizer ID Analysis view provides the following results.



This view is not available for clearance (CLR) signals in two-frequency systems.




Figure 4-12: ID Analysis view

DDM 90-150.....	60
Last ID.....	61
ID Code.....	61
ID Period.....	61
Dot Length.....	61
Dash Length.....	61
Dot-Dash Gap.....	61
Letter Gap.....	61
ID AM.....	61
ID Freq.....	61

DDM 90-150

Difference in depth of modulation (DDM) between 90 Hz and 150 Hz AM signal ($m_{90 \text{ Hz}} - m_{150 \text{ Hz}}$)

Note: The DDM value is also displayed graphically as a bargraph for quick evaluation. A green DDM value indicates that a valid ILS signal has been determined.

Remote command:

[DD0](#) on page 283

[DD1](#) on page 283

[DCLR](#) on page 283

[DCRS](#) on page 283

Last ID

Time since last ID pulse was measured

Remote command:

[LASTID_TIME](#) on page 289

ID Code

Morse-decoded ID with three or four letters.

Remote command:

[AC8](#) on page 280

[AC8](#) on page 304

ID Period

Time between two measured ID pulses

Remote command:

[ID_PERIOD](#) on page 289

Dot Length

Length of time a dot is transmitted in the used Morse code in milliseconds.

Remote command:

[ID_DOT_LENGTH](#) on page 288

Dash Length

Length of time a dash is transmitted in the used Morse code in milliseconds.

Remote command:

[ID_DASH_LENGTH](#) on page 288

Dot-Dash Gap

Length of time that passes between a transmitted dot and a dash in the used Morse code in milliseconds.

Remote command:

[ID_DOTDASH_GAP](#) on page 289

Letter Gap

Length of time that passes between two transmitted letters in the used Morse code in milliseconds.

Remote command:

[ID_LETTER_GAP](#) on page 289

ID AM

AM Modulation depth of identifier signal (default: 1020 Hz).

Remote command:

[AM8](#) on page 282

[AM8](#) on page 305

ID Freq

Frequency of the morse signal.

Remote command:

[AF8](#) on page 281

[AF8](#) on page 305

4.1.3.7 ILS localizer recording view

The Recording view displays the recorded data for ILS Localizer measurements from the selected data list (see "[List](#)" on page 202). If available, the stored GNSS data from the GNSS receiver is also displayed.



Which measurement results are stored is described in the remote commands, see [GETDATADEF](#) on page 366.

The individual measurement results are described in the result views.

**Status flags**

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

For details on data logging, see [Chapter 7.2, "Recording measurement data"](#), on page 200.

Remote commands to retrieve data:

[GETDATADEF](#) on page 366

[GETDATASET](#) on page 366

4.1.4 ILS localizer and glidepath configuration

The following settings are available for the ILS Localizer and Glidepath measurements.



Settings for recording, including trigger settings, are described in [Chapter 7.2, "Recording measurement data"](#), on page 200.

• Configuring the input signal	63
• Channel and frequency configuration	64
• Ampt	68
• Bandwidth (BW)	69
• LF input configuration	71
• Setting the measurement time (MTime)	74
• DDM and SDM configuration	74

4.1.4.1 Configuring the input signal

The ILS modes can analyze RF or LF input. For details on configuring LF input measurements, see [Chapter 4.1.4.5, "LF input configuration"](#), on page 71.

Input RF/LF

Access VNC: [s]

Configures the input source for the receiver.

For details on the connectors see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23.

"RF In"	An RF signal is provided from the RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000. They are connected to a receiving antenna (max. +13 dBm). The antenna must correspond to the specified frequency range for the measurement.
"LF In"	An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000. If both receivers are used, only one of them can be set to analyze input from "LF In". The LF In connector is only available if R&S EVSF1-B4 is installed. Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.

Remote command:

[GS_RFLF_INPUT](#) on page 278

[LLZ_RFLF_INPUT](#) on page 268

[VOR_RFLF_INPUT](#) on page 303

[FFT_RFLF_INPUT](#) on page 353

[SCOPE_RFLF_INPUT](#) on page 358

[SETUP:INPUT](#) on page 234

4.1.4.2 Channel and frequency configuration

The ILS Localizer and Glidepath measurements can detect both course and clearance carriers simultaneously. As an alternative, the individual carriers can be measured only, or any one or two user-defined frequencies. By default, a wideband measurement is performed to obtain an initial overview of the input signal and determine the basic signal characteristics. An autotune function is available to determine the precise frequencies of the signal components automatically. Thus, the demodulation bandwidth can be selected very precisely. The available measurement settings depend on the selected channel and frequency configuration.

- [Channel setup](#).....64
- [Carrier configuration \(1F/2F Config\)](#)..... 65
- [Channel frequency configuration \(CH FREQ\)](#).....67

Channel setup

Access VNC: [m] > [F1]

1F/2F

Selects the number of frequencies or channels to be measured.

For all frequencies except the wideband measurement, the autotune function automatically determines the measurement frequency (see "[CRS/CLR Carr \(Autotune function\)](#)" on page 65).

"1F"	One frequency only is measured, namely the nominal frequency, which is also the center frequency. The nominal frequency is configured by the Channel frequency configuration (CH FREQ) settings.
------	--

"2F"	Two frequencies are measured at the same time. Which frequencies are measured is configured by the Channel frequency configuration (CH FREQ) settings. The numeric results are calculated as the sum of both frequencies. In the RF Level display, the individual carriers are also indicated. In the RF Spectrum preview, both carriers are displayed.
"2F CRS"	Both the course and clearance frequencies are measured simultaneously. The results for both frequencies, as well as the sum of both, are displayed in the RF Level display. Both frequencies are displayed in the RF Spectrum preview. The numeric results are displayed for the course frequency. To view the results for the clearance frequency, switch to "2F CLR"
	Note: Depending on the ILS system and the country, the course can be the upper or lower frequency (see "Upper Freq" on page 67).
"2F CLR"	Both the course and clearance frequencies are measured simultaneously. The results for both frequencies, as well as the sum of both, are displayed in the RF Level display. Both frequencies are displayed in the RF Spectrum preview. The numeric results are displayed for the course frequency. To view the results for the course frequency, switch to "2F CRS".
	Note: Depending on the ILS system and the country, the course can be the upper or lower frequency (see "Upper Freq" on page 67).
"Wide"	A wideband measurement is performed around the nominal frequency. The frequency range is defined by the IF BW .

Remote command:

[DEMODE_LLZ](#) on page 261

[DEMODE_GS](#) on page 271

Carrier configuration (1F/2F Config)

Access VNC: [s] > "F1"

Configures the carriers and frequencies for measurements on a single or two frequencies (not wideband). Which settings are available depends on the ["1F/2F"](#) on page 64.

CRS/CLR Carr (Autotune function)	65
Course	66
Clearance	66
1F Offset	66
Find Carrier	67
Carrier Thresh	67
Upper Freq	67

CRS/CLR Carr (Autotune function)

Defines whether the course and clearance carriers are determined automatically or manually.

"Man"	Specify the frequencies manually as offsets to either direction of the nominal frequency, see "Course" on page 66 and "Clearance" on page 66.
-------	---

- "Auto Lock" Both carriers are determined automatically at the beginning of the measurement. Once a valid signal has been found, the carrier frequencies remain fixed until you perform a manual change. Automatic mode is indicated by "Autotune" in the measurement settings area, followed by the current processing status, see ["Autotune function"](#) on page 45. For all carrier measurements (not the wideband measurement), the "Auto Lock" function is enabled by default (see ["1F/2F"](#) on page 64).
- "Auto Retune" Both carriers are determined automatically at the beginning of the measurement. If the carrier frequency changes, the R&S EVSF1000 starts a new search (retuning). Automatic mode is indicated by "Autotune" in the measurement settings area, followed by the current processing status, see ["Autotune function"](#) on page 45.

Note: Adapting the frequency in autotune mode.

The autotune function sets the measurement filter position such that the detected frequency is in the center of the filter bandwidth. While the frequency is locked, the filter position remains unchanged. If the bandwidth is narrow and the signal frequency changes, e.g. due to changes of the transmitter, the signal may no longer be covered completely by the measurement filter. In this case, the measurement results are distorted. If you assume that the ILS signal frequency has possibly changed, we recommend performing a new search using the [Find Carrier](#) function.

Remote command:

Mode:

[LLZ_DEMFREQS_OFFSET_AUTOMAN](#) on page 266

[GS_DEMFREQS_OFFSET_AUTOMAN](#) on page 276

Course

Defines the course carrier as a frequency offset from the nominal frequency.

Remote command:

[LLZ_DEMFREQS_OFFSET_UPPERFREQ](#) on page 267

[GS_DEMFREQS_OFFSET_UPPERFREQ](#) on page 277

Clearance

Defines the clearance carrier as a frequency offset from the nominal frequency in the opposite direction to the course carrier.

Remote command:

[LLZ_DEMFREQS_OFFSET_LOWERFREQ](#) on page 267

[GS_DEMFREQS_OFFSET_LOWERFREQ](#) on page 276

1F Offset

For single frequency measurements only:

Defines an offset of the measured frequency to the nominal frequency.

Remote command:

[LLZ_DEMFREQS_OFFSET_1F](#) on page 266

[GS_DEMFREQS_OFFSET_1F](#) on page 276

Find Carrier

For manual carrier determination ([CRS/CLR Carr \(Autotune function\)](#)): "MAN"):

Determines the carrier frequencies automatically, but only once. The frequencies do not change automatically if the input signal changes.

For automatic carrier determination ("Autotune"): a new search is performed, see ["CRS/CLR Carr \(Autotune function\)"](#) on page 65.

Note: Adapting the frequency in autotune mode.

The autotune function sets the measurement filter position such that the detected frequency is in the center of the filter bandwidth. While the frequency is locked, the filter position remains unchanged. If the bandwidth is narrow and the signal frequency changes, e.g. due to changes of the transmitter, the signal may no longer be covered completely by the measurement filter. In this case, the measurement results are distorted. If you assume that the ILS signal frequency has possibly changed, we recommend performing a new search using the [Find Carrier](#) function.

Remote command:

[LLZ_START_FINDCARRIER](#) on page 268

[GS_START_FINDCARRIER](#) on page 278

Carrier Thresh

Defines a threshold for automatic carrier determination. The measured power level must exceed this level before the carrier frequency is adapted.

Remote command:

[GS_CARRIER_THRESHOLD_DB](#) on page 274

[LLZ_CARRIER_THRESHOLD_DB](#) on page 264

Upper Freq

The course and clearance carriers are defined as offsets to either side of the center frequency. Which frequency is considered to be the course carrier - the upper or lower frequency - depends on the used standard and the country it is used in. Thus, you can swap the carrier definition if necessary.

Remote command:

[SETUP:UNIT:UPPERFREQ](#) on page 254

Channel frequency configuration (CH FREQ)**Access VNC:** [q]

The channel frequency determines the nominal frequency at which the measurement is performed. For some avionics standards, the channels are associated with specific frequencies. (See [Chapter A, "ILS channel frequency list"](#), on page 377 and [Chapter B, "VOR channel frequency list"](#), on page 379.)

CH	67
Freq	68
Step Size	68

CH

Sets the receiver frequency channel on the active receiver board according to the ICAO frequency list.

Remote command:
[RFCH](#) on page 231

Freq
Sets the nominal frequency for the measurement. By default, this frequency is also assumed to be the center frequency for spectrum displays, unless an offset is defined. For measurements on two frequencies, the frequencies are defined as offsets to this nominal frequency.
Remote command:
[RF](#) on page 231

Step Size
Defines the frequency step size for the rotary knob when setting the frequency.
In many avionics signals, channels are assigned to frequencies with a fixed offset. By setting the step size of the rotary knob to the fixed offset, you can easily scroll through the signal's channel frequencies using the rotary knob. Thus, for example, you can analyze the measurement results for one channel after the other simply by changing the selected channel frequency with the rotary knob.
The default step size for ILS/VOR mode is 50 kHz.
Remote command:
ILS mode:
[LLZ_DEFAULT_FREQSTEP](#) on page 264
[GS_DEFAULT_FREQSTEP](#) on page 274
VOR mode:
[VOR_DEFAULT_FREQSTEP](#) on page 301

4.1.4.3 **Ampt**

Access VNC: [w]
The following settings define the amplification for the input signal.

RF Att	68
RF Mode	69
Transducer Correction	69

RF Att
Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual"	The RF attenuation mode is specified manually (see " RF Mode " on page 69).
----------	---

"Auto" The RF attenuation mode is selected automatically.
The signal attenuation is selected automatically according to the signal strength.
This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable.
When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

4.1.4.4 Bandwidth (BW)

Access VNC: [e]

The bandwidth determines the frequency range for which the measurement is performed. Depending on the measurement mode, and whether a wideband or a specific frequency is measured, different settings are available.

IF BW

Specifies the measurement filter bandwidth.

Ensure that the entire input signal lies within the specified bandwidth, particularly for narrow bandwidths.

Note: Adapting the frequency in autotune mode.

The autotune function sets the measurement filter position such that the detected frequency is in the center of the filter bandwidth. While the frequency is locked, the filter position remains unchanged. If the bandwidth is narrow and the signal frequency changes, e.g. due to changes of the transmitter, the signal may no longer be covered completely by the measurement filter. In this case, the measurement results are distorted. If you assume that the ILS signal frequency has possibly changed, we recommend performing a new search using the [Find Carrier](#) function.

Remote command:

1F/2F measurements:

[LLZ_DEM_1F2F_BW](#) on page 266

[GS_DEM_1F2F_BW](#) on page 275

Wideband measurements:

[LLZ_DEM_WIDE_BW](#) on page 265

[GS_DEM_WIDE_BW](#) on page 275

IF BW Dist/ID

Specifies the demodulation filter bandwidth for distortion and ID measurements.

Remote command:

1F/2F measurements:

[LLZ_DEM_ID_BW](#) on page 265

[GS_DEM_ID_BW](#) on page 275

Wideband measurements:

[LLZ_DEM_ID_WIDE_BW](#) on page 265

[GS_DEM_ID_WIDE_BW](#) on page 275

Res. FM Filt. (ILS only)

Defines the filter type used to determine residual FM (see [Chapter 4.1.3.5, "ILS localizer distortion view"](#), on page 57).

"ICAO" Filter according to ICAO specification

"Narrow" Narrow filter; the DDM filters used to determine the 90 Hz/ 150 Hz modulation values are used to avoid interference between the signals

Remote command:

[FILTER_LLZ_RESIDFM](#) on page 267

4.1.4.5 LF input configuration

The ILS Localizer and Glidepath measurements can be performed on common RF or on LF input. LF input can only be analyzed if the R&S EVSG1-K7 LF-Analysis option is installed.

To measure LF input rather than RF input, the following settings are required.

Input RF/LF.....	71
LF In Mode.....	71
Low IF Offset.....	72
Range.....	72
Coupling.....	72
DC Reference.....	72
LF In Factor.....	73
Bandwidth (IF BW/AF In BW).....	73
IF/AF Bandwidth (Dist/ID).....	73
Res. FM Filt.....	73

Input RF/LF

Access VNC: [s]

Configures the input source for the receiver.

For details on the connectors see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23.

"RF In"	An RF signal is provided from the RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000. They are connected to a receiving antenna (max. +13 dBm). The antenna must correspond to the specified frequency range for the measurement.
"LF In"	An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000. If both receivers are used, only one of them can be set to analyze input from "LF In". The LF In connector is only available if R&S EVSF1-B4 is installed. Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.

Remote command:

[GS_RFLF_INPUT](#) on page 278
[LLZ_RFLF_INPUT](#) on page 268
[VOR_RFLF_INPUT](#) on page 303
[FFT_RFLF_INPUT](#) on page 353
[SCOPE_RFLF_INPUT](#) on page 358
[SETUP:INPUT](#) on page 234

LF In Mode

Access VNC: [s]

Determines the type of LF input. Depending on the type of input, the available settings and results can vary.

This setting is only available for LF input ([Input: LF](#)).

"AF"	Measures the AF signal at 0 Hz.
------	---------------------------------

"Low IF" Measures the ILS signal at a low intermediate frequency, for example from a test point at the transmitter.

Remote command:

[LLZ_BB_WIDE1F](#) on page 264

[GS_BB_WIDE1F](#) on page 274

Low IF Offset

Access VNC: [s]

Defines the frequency of the low IF input signal, that is: the offset from 0 Hz.

Only available for low IF mode (see "[LF In Mode](#)" on page 71).

Remote command:

[LLZ_BB_1F_OFFSETKHZ](#) on page 262

[GS_BB_1F_OFFSETKHZ](#) on page 272

Range

Access VNC: [w]

Defines the full-scale AF signal level. Define the correct level to avoid clipping and overload.

Switches the range between 1 V and 5 V.

Remote command:

[SETUP:BB_IN_RANGE](#) on page 236

Coupling

Access VNC: [w]

Specifies the handling of the DC component of the AF signal.

For low IF signals, AC coupling is always used.

"AC" The DC component of the AF signal is not forwarded.

"DC" The DC component of the AF signal is also forwarded and analyzed.

Remote command:

[SETUP:BB_IN_COUPL](#) on page 236

DC Reference

Access VNC: [w]

Defines the reference power in volt for LF input, available for AF signals with AC coupling only. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

For AC coupling, the DC power component of the AF signal is not forwarded. Thus, you must define the reference value manually.

Remote command:

[LLZ_BB_LFIN_DCOFFSETV](#) on page 263

[GS_BB_LFIN_DCOFFSETV](#) on page 273

[VOR_BB_LFIN_DCOFFSETV](#) on page 300

[FFT_BB_LFIN_DCOFFSETV](#) on page 349

[SCOPE_BB_LFIN_DCOFFSETV](#) on page 356

LF In Factor**Access VNC:** [w]

Applies a factor to the measured power levels, e.g. to compensate certain effects in the input system.

Remote command:

[SETUP:BB_IN_FACTOR](#) on page 236

Bandwidth (IF BW/AF In BW)**Access VNC:** [e]

Bandwidth with which the LF input is acquired. The default bandwidth is 3 kHz for Low IF measurements. For AF measurements, the default bandwidth is 1.5 kHz.

Remote command:

AF mode:

[LLZ_BB_BW_KHZ](#) on page 262

[GS_BB_BW_KHZ](#) on page 272

[VOR_BB_BW_KHZ](#) on page 300

Low IF mode:

[LLZ_BB_LOWIF_BW_KHZ](#) on page 263

[GS_BB_LOWIF_BW_KHZ](#) on page 273

IF/AF Bandwidth (Dist/ID)**Access VNC:** [e]

Bandwidth with which the ID analysis and distortion measurement is performed. The default bandwidth is 3 kHz for Low IF measurements. For AF measurements, the default bandwidth is 1.5 kHz.

Remote command:

AF mode:

[LLZ_BB_AF_BW_IDDIST_KHZ](#) on page 262

[GS_BB_AF_BW_IDDIST_KHZ](#) on page 272

Low IF mode:

[GS_BB_LOWIF_BW_IDDIST_KHZ](#) on page 273

[LLZ_BB_LOWIF_BW_IDDIST_KHZ](#) on page 263

Res. FM Filt.**Access VNC:** [e]

Defines the filter type used to determine residual FM (see [Chapter 4.1.3.5, "ILS localizer distortion view"](#), on page 57).

"ICAO" Filter according to ICAO specification

"Narrow" Narrow filter; the DDM filters used to determine the 90 Hz/ 150 Hz modulation values are used to avoid interference between the signals.

Remote command:

[FILTER_LLZ_RESIDFM](#) on page 267

4.1.4.6 Setting the measurement time (MTime)

Access VNC: [d]

The measurement time determines the interval at which new measurement results are displayed. Internally, values are captured every 10 ms, that is: 100 per second.

If the defined measurement time is longer, the values captured internally in that interval are averaged and only the average value is displayed.

Note that the measurement time determines the minimum interval for values to be stored during recording (see "Time" on page 203).

Enter the time in milliseconds.

Remote command:

[MEASTIME](#) on page 231

4.1.4.7 DDM and SDM configuration

The following settings configure the DDM and SDM measurement results.

DDM Unit	74
SDM Unit	74
ILS Phase	74
DDM Polarity	74
DDM Bargr	75

DDM Unit

Specifies the unit of the DDM display.

1 (dimensionless value) | % | μA

Remote command:

[SETUP:UNIT:DDM](#) on page 252

SDM Unit

Specifies the unit of the SDM display.

1 (dimensionless value) | % | μA

Remote command:

[SETUP:UNIT:SDM](#) on page 253

ILS Phase

Specifies the value range in the ILS phase.

Bipolar: -60 ... +60° | Unipolar: 0 ... 120°

Remote command:

[SETUP:UNIT:ILSPHASE](#) on page 253

DDM Polarity

Specifies the DDM polarity.

90–150 | 150–90

Remote command:
[SETUP:UNIT:POLARITYDDM](#) on page 253

DDM Bargr
Configures the scaling of the DDM bargraph.
0.075 | 0.150 | 0.400 (dimensionless)
Remote command:
[SETUP:UNIT:BARGRAPH](#) on page 252

4.2 R&S EVSG-K3 Marker beacon analysis

Access VNC: [m] > Down arrow key

Remote command:
[MODE_MB](#) on page 293

- [Basics on marker beacons](#).....75
- [ILS marker beacon measurements and results](#)..... 76
- [Configuring ILS marker beacon measurements](#).....82

4.2.1 Basics on marker beacons

Marker beacon (MB) receivers are used for a rough distance measurement. They are available only for some ILS installations.




Figure 4-13: Marker beacon placement with respect to runway

Marker beacon receivers decode audio and provide signaling output to identify one of three marker beacons installed near the runway. They transmit a narrow beam width at 75 MHz carrier frequency in a vertical direction. Each of them has a different distinct modulation code to allow the receiver to identify which one it is flying over.

Both visual (color of the marker beacon) and audio tone identification is supported for determining which marker has been flown over. The audio/visual pairing of marker beacons is as follows:

- Outer marker flashes BLUE in the cockpit at 400 Hz ("relaxed" tone).
- Middle marker flashes AMBER in the cockpit at 1300 Hz ("hurried" tone).
- Inner marker flashes WHITE in the cockpit at 3000 Hz ("urgent" tone).

4.2.2 ILS marker beacon measurements and results

The ILS Marker Beacon measurement provides multiple views for the measurement results.



You can display graphical results directly from the ILS Marker Beacon mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

To return from the graphical results to the ILS Marker Beacon mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.1, "R&S EVSG-K10 RF spectrum analysis"](#), on page 125
- [Chapter 5.2, "IF spectrum analysis"](#), on page 130
- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143

Remote command:

[VIEW_MB](#) on page 294

• RF level and frequency display	77
• IF spectrum preview	78
• ILS marker beacon main view	79
• ILS marker beacon ID analysis	80
• ILS marker beacon recording view	81

4.2.2.1 RF level and frequency display

The measured RF power and frequency of the input signal are displayed both numerically and graphically.




Figure 4-14: RF level display

The following results are provided:

- Numeric power level in dBm ("Lev")
For measurements on two frequencies: individual and sum power levels
- Measured frequency offset to the nominal frequency in kHz
- Numeric frequency offset of measured power
- Bargraph indicating the power and a color-coded overload state, where:
 - **Red:** overload state, check message
 - **Yellow:** power approaching overload state
 - **Green:** power in a valid range

- If applicable: overload messages



Overload messages

The following messages indicate an overload:

- "RF Overload"
Overload of the input mixer or of the analog IF path.
- "IF Overload"
Overload of the IF signal.
- "ADC Overload"
The dynamic range of the AD-converter is exceeded (clipping).

A combination of these overloads is also possible.

In all cases, set the RF attenuation to normal or low distortion (for RF input), or reduce the input level.

In recorded data lists, overloads are indicated by an "O", see ["Status flags"](#) on page 63.

Remote commands to retrieve results:

[LA?](#) on page 231

[RF?](#) on page 231

[FMEAS](#) on page 295

4.2.2.2 IF spectrum preview

A preview of the measured spectrum (power level vs. frequency) for the IF (intermediate frequency) signal is provided. The center frequency is the nominal channel frequency. The frequency range shows the measured bandwidth. The power range is selected such that the noise level remains visible.





Figure 4-15: IF spectrum preview

This preview spectrum allows you to check if the current measurement settings are appropriate, such as the bandwidth or frequency offsets. For a larger, more detailed spectrum diagram, select one of the graphical Spectrum modes. If you switch to such a mode directly from a numeric measurement mode, the current measurement settings are applied to the spectrum automatically.

4.2.2.3 ILS marker beacon main view

The ILS Marker Beacon Main view provides the following results:



AM 400 Hz	79
Freq 400 Hz	79
AM 1300 Hz	79
Freq 1300 Hz	80
AM 3000 Hz	80
Freq 3000 Hz	80

AM 400 Hz

AM modulation depth of the 400-Hz component

Remote command:

[AM6](#) on page 296

Freq 400 Hz

Measured frequency of the 400-Hz component

Remote command:

[AF6](#) on page 295

AM 1300 Hz

AM modulation depth of the 1300-Hz component

Remote command:

[AM5](#) on page 296

Freq 1300 Hz

Measured frequency of the 1300-Hz component

Remote command:

[AF5](#) on page 295

AM 3000 Hz

AM modulation depth of the 3000-Hz component

Remote command:

[AM4](#) on page 295

Freq 3000 Hz


Measured frequency of the 3000-Hz component

Remote command:

[AF4](#) on page 295

4.2.2.4 ILS marker beacon ID analysis

Displays the results of the marker beacon signal id analysis.



400 Hz Dash.....	81
400 Hz Gap.....	81
1300 Hz Dash.....	81
1300 Hz Dot.....	81

1300 Hz Gap.....	81
3000 Hz Dot.....	81
3000 Hz Gap.....	81

400 Hz Dash

Displays the length of a dash for the outer marker (in ms).

Remote command:

[ID_F400_DASHLEN](#) on page 296

400 Hz Gap

Displays the gap between two dashes for the outer marker (in ms).

Remote command:

[ID_F400_GAP](#) on page 297

1300 Hz Dash

Displays the length of a dash for the middle marker (in ms).

Remote command:

[ID_F1300_DASHLEN](#) on page 297

1300 Hz Dot

Displays the length of a dot for the middle marker (in ms).

Remote command:

[ID_F1300_DOTLEN](#) on page 297

1300 Hz Gap

Displays the gap between dot and dash for the middle marker (in ms).

Remote command:

[ID_F1300_GAP](#) on page 297

3000 Hz Dot

Displays the length of a dot for the inner marker (in ms).

Remote command:

[ID_F3000_DOTLEN](#) on page 297

3000 Hz Gap


Displays the gap between two dashes for the inner marker (in ms).

Remote command:

[ID_F3000_GAP](#) on page 298

4.2.2.5 ILS marker beacon recording view

The Recording view displays the recorded data for ILS Localizer measurements from the selected data list (see "[List](#)" on page 202). If available, the stored GNSS data from the GNSS receiver is also displayed.



Which measurement results are stored is described in the remote commands, see [GETDATADEF](#) on page 366.

The individual measurement results are described in the other ILS Marker Beacon result views.

For details on data logging, see [Chapter 7.2, "Recording measurement data"](#), on page 200.



Status flags

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

4.2.3 Configuring ILS marker beacon measurements

The following settings are available for the ILS Marker Beacon measurement.



Settings for recording, including trigger settings, are described in [Chapter 7.2, "Recording measurement data"](#), on page 200.



For the mapping of hard- and softkey commands to keyboard commands using VNC, see [Table 1-3](#).

- [Setting the receiver frequency](#)..... 83
- [Ampt](#).....83
- [Setting the measurement time \(MTime\)](#).....84

4.2.3.1 Setting the receiver frequency

Access VNC: [q]

The receiver frequency determines the nominal frequency at which the measurement is performed.

Freq	83
Step Size	83

Freq

Sets the nominal frequency for the measurement.

Remote command:

[RF](#) on page 231

Step Size

Defines the frequency step size for the rotary knob when setting the frequency.

The default step size for ILS MB mode is 50 kHz.

4.2.3.2 Ampt

Access VNC: [w]

The following settings define the amplification for the input signal.

RF Att	83
RF Mode	84
Transducer Correction	84

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual" The RF attenuation mode is specified manually (see ["RF Mode"](#) on page 69).

"Auto" The RF attenuation mode is selected automatically.
The signal attenuation is selected automatically according to the signal strength.
This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable.
When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise" 15 dB pre-amplification
Provides a high sensitivity. Suitable when scanning the area for distant signals.

"Norm" 0 dB
Provides a normal sensitivity.

"Low Dist" 15 dB attenuation
Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

4.2.3.3 Setting the measurement time (MTime)

Access VNC: [d]

The measurement time determines the interval at which new measurement results are displayed. Internally, values are captured every 10 ms, that is: 100 per second.

If the defined measurement time is longer, the values captured internally in that interval are averaged and only the average value is displayed.

Note that the measurement time determines the minimum interval for values to be stored during recording (see "Time" on page 203).

Enter the time in milliseconds.

Remote command:

[MEASTIME](#) on page 231

4.3 R&S EVSG-K2 VOR analysis

Access VNC: [m] > Down arrow key

If the optional R&S EVSG-K2 VOR analysis is installed, signals from VOR systems can be analyzed with the R&S EVSF1000.

Remote command:

[MODE_VOR](#) on page 300

4.3.1 VOR basics

Some background knowledge on basic terms and principles used in VOR measurements is provided here for a better understanding of the required configuration settings.

4.3.1.1 VHF omnidirectional radio range (VOR)

Very high frequency (VHF) omnidirectional radio range (VOR) is a radio navigation system for short and medium distance navigation. The VOR radio navigation aid supplies the aircraft with directional information, angle information relative to the magnetic north from the site of the beacon. Thus, it helps aircraft to determine their position and stay on course. The range covered by a VOR station is ideally a circle around the VOR station with a radius depending on the flight altitude.

A VOR system consists of a ground transmission station and a VOR receiver on board the aircraft.

Ground transmitter

The transmitter stations operate at VHF frequencies of 108 MHz to 118 MHz, with the code identification (COM/ID) transmitting on a modulation tone of 1.020 kHz. It emits two types of signals:

- An omnidirectional reference signal (REF) that can consist of two parts:
 - 30 Hz frequency modulated (FM) sine wave on subcarrier 9.96 kHz from amplitude modulation (AM) carrier

- 1020 Hz AM modulated sine wave Morse code
- A directional positioning signal, variable (VAR): 30 Hz AM modulated sine waves with variable phase shift

VOR receiver

The VOR receiver obtains the directional information by measuring the phase difference of two 30 Hz signals transmitted by the beacon. A conventional VOR station (CVOR) transmits with a rotating antenna. From the rotation, a sine wave AM signal arises in the receiver, whose phase position depends on the present angle of rotation. The rotation frequency of the antenna sets the modulation frequency at 30 Hz.

Instead of using a rotating antenna, DVOR stations (Doppler) divide the circumference of the antenna into 48 or 50 segments, covering each segment by its own antenna. Each antenna transmits the unmodulated subcarrier from one antenna to the next, so that the signal completes the round trip 30 times per second.

To determine the radial, the phase difference to a reference phase must be measured. This reference phase must be independent of the rotation of the antenna. Thus, it is modulated with a frequency deviation of 480 Hz in FM onto a secondary carrier with 9.96 kHz. It is then emitted over a separate antenna with a round characteristic.




Figure 4-16: Basics of the VOR phase angles (Φ) depending on the azimuth angle (Θ)

The frequency modulated secondary carrier for the reference phase is itself again modulated in AM on the RF carrier of the VOR station. In addition to the signals necessary for navigation, a Morse code with 1020 Hz can be transmitted on the VOR carrier. Also, speech in the usual AF from 300 Hz to 3.3 kHz can be transmitted. Often the voice channel of a VOR station is used for the transmission of ATIS (Automatic Terminal Information Service) messages. The Morse code can be used to identify the VOR station, similar to the "Morse code identification signal" on page 43 in the ILS signal.

The spectrum of a VOR signal is therefore composed of the carrier and three modulated components.




Figure 4-17: Example of the VOR Spectrum

The identical modulation degree $m = 0.3$ for all three components was selected in ICAO annex-10 [63] such that the total signal still contains 10% modulation reserve. The carrier is therefore not suppressed at any time. The 9960 Hz reference carrier is FM modulated with 480 Hz deviation. The VOR signal generation as under ICAO is shown below.




Figure 4-18: Basics of the VOR signal generation

4.3.1.2 VOR demodulator




Figure 4-19: Block diagram of the VOR software demodulator

The VOR signal contains three AM modulated components that must be separated in a first step:

- Rotational signal (30 Hz)
- Identification/voice part (300 Hz to 4 kHz)
- FM modulated carrier (9960 Hz $\pm$ 700 Hz)

To obtain the AM depth, a lowpass filter must calculate the mean carrier power, while suppressing all other signal components. The mean carrier power is then used to normalize the instantaneous magnitude of the I/Q signal. The result is the AM modulation depth signal vs. time. The three AM components are separated using bandpass filters covering the individual frequency ranges.

A Morse decoder detects and decodes the ON and OFF periods in the identifier signal.

The separated FM modulated carrier is passed through an FM demodulator. The FM carrier frequency (nominal 9960 Hz) is calculated as the average output value of the FM demodulator. To obtain the 30 Hz reference signal, the FM demodulator output is filtered by the same narrow 30 Hz bandpass as the 30 Hz AM rotational component. FM deviation is calculated using the estimated magnitude of the 30 Hz reference signal.

The azimuth is calculated as the phase difference of the 30 Hz reference signal and the 30 Hz rotational signal.

VOR distortion

In the VOR software demodulator two kinds of signals are analyzed regarding distortions:

- AM Distortion: The AM modulation depth vs time signal is processed by an FFT, with a user-defined resolution bandwidth. The trace is displayed in the "Modulation Spectrum" display. The K2, K3 and THD results of the AM components are calculated based on the FFT trace and the estimated modulation frequencies.
- FM Distortion: The FM modulation depth vs time signal is processed by an FFT, using a resolution bandwidth automatically set by the application. You cannot view the resulting trace. The K2, K3 and THD results of the FM components are calculated based on the FFT trace and the estimated modulation frequencies.

AM modulation depth

To obtain the AM depth, a lowpass filter must calculate the mean carrier power, while suppressing all other signal components. The mean carrier power is then used to normalize the instantaneous magnitude of the I/Q signal. The result is the AM modulation depth signal versus time. It is then used to calculate the following AM modulation depths:

- Depth₉₉₆₀: AM modulation depth of the FM carrier, typically at 9960 Hz
- Depth_{AM30}: AM modulation depth of the 30 Hz rotational signal
- Depth_{ID}: AM modulation depth of the identification/voice signal

FM modulation depth

The FM deviation $\text{Devia}_{\text{FM30}}$ (typically 480 Hz) is calculated by estimating the magnitude of the FM demodulated 30 Hz reference signal.

Azimuth (phase difference at 30 hz)

The phases of both the 30 Hz FM and 30 Hz AM signal are estimated at exactly the same time instant. The azimuth (Phase FM-AM) is calculated as the phase difference between the two.

AF frequencies

In the VOR demodulator the AF frequencies are calculated:

- $\text{Freq}_{\text{AM30}}$: 30 Hz Rotational-signal (AM)
- $\text{Freq}_{\text{FM30}}$: 30 Hz Reference-signal (FM)
- Freq_{ID} : voice / identification; From 300 Hz to 4 kHz, typically 1020 Hz
- Freq_{9960} : The carrier frequency of the FM carrier, typically 9960 Hz; Calculated as mean value of the FM demodulator output

4.3.1.3 Phase notation in VOR measurements

In VOR measurements, the phase can be provided using two different notations, indicated in the following illustration:




Figure 4-20: Phase notation in VOR measurements

Phase is always counted counter-clockwise, starting at the reference.

The reference depends on the selected notation:

- **FROM:** North direction at the VOR beacon

- **TO:** North direction at the receiver/ aircraft

To convert one notation to the other, use the following equation:

$$Phase_{TO} = Phase_{FROM} + 180 \text{ deg}$$

4.3.2 VOR measurements and results

The VOR measurement provides multiple views for the measurement results.



Switching from numeric to graphical results

You can display graphical results directly from the VOR mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

The graphical results are only available for a single carrier. Thus, when you switch to a graphical measurement mode from VOR mode, you must select the carrier for which you want to see the graphical results. When you select the softkey, a submenu is displayed to select the carrier.



You can select one of the following carriers:

- Main carrier, AM demodulated
- Subcarrier, AM demodulated (AM component)
- Subcarrier, FM demodulated (FM component)

To return from the graphical results to the VOR mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.1, "R&S EVSG-K10 RF spectrum analysis"](#), on page 125
- [Chapter 5.2, "IF spectrum analysis"](#), on page 130
- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143

Remote command:

[VIEW_VOR](#) on page 300

• RF level and frequency display	92
• IF spectrum preview	93
• VOR main view	93
• VOR distortion view	95
• VOR ID analysis view	97
• VOR recording view	99

4.3.2.1 RF level and frequency display

The measured RF power and frequency of the input signal are displayed both numerically and graphically.




Figure 4-21: RF level display

The following results are provided:

- Numeric power level in dBm ("Lev")
For measurements on two frequencies: individual and sum power levels
- Measured frequency offset to the nominal frequency in kHz
- Numeric frequency offset of measured power
- Bargraph indicating the power and a color-coded overload state, where:
 - **Red:** overload state, check message
 - **Yellow:** power approaching overload state
 - **Green:** power in a valid range
- If applicable: overload messages



Overload messages

The following messages indicate an overload:

- "RF Overload"
Overload of the input mixer or of the analog IF path.
- "IF Overload"
Overload of the IF signal.
- "ADC Overload"
The dynamic range of the AD-converter is exceeded (clipping).

A combination of these overloads is also possible.

In all cases, set the RF attenuation to normal or low distortion (for RF input), or reduce the input level.

In recorded data lists, overloads are indicated by an "O", see ["Status flags"](#) on page 63.

Remote commands to retrieve results:

[LA?](#) on page 231

[RF?](#) on page 231

[FMEAS](#) on page 307

4.3.2.2 IF spectrum preview

A preview of the measured spectrum (power level vs. frequency) for the IF (intermediate frequency) signal is provided. The center frequency is the nominal channel frequency. The frequency range shows the measured bandwidth. The power range is selected such that the noise level remains visible.





Figure 4-22: IF spectrum preview

This preview spectrum allows you to check if the current measurement settings are appropriate, such as the bandwidth or frequency offsets. For a larger, more detailed spectrum diagram, select one of the graphical Spectrum modes. If you switch to such a mode directly from a numeric measurement mode, the current measurement settings are applied to the spectrum automatically.

4.3.2.3 VOR main view

Displays the main measurement results.



Bearing (from).....	94
AM 30 Hz.....	94
AM 9960 Hz.....	94
FM-Deviation.....	95
ID Code.....	95
Voice AM.....	95
Freq 30 Hz.....	95
Freq 9960 Hz.....	95
Freq FM30.....	95
FM Index.....	95

Bearing (from)

Phase between both 30-Hz signals (direction of the R&S EVSF1000 in relation to the ground station).

A green bearing value indicates that a valid VOR signal has been determined.

Remote command:

[BE](#) on page 306

AM 30 Hz

AM modulation depth of 30 Hz AM rotational signal

Remote command:

[AM0](#) on page 305

AM 9960 Hz

AM modulation depth of 9.96 kHz subcarrier

Remote command:

[AM1](#) on page 305

FM-Deviation

FM frequency deviation of 30 Hz subcarrier

Remote command:

[FM0](#) on page 306

ID Code

Morse-decoded ID with three or four letters.

Remote command:

[AC8](#) on page 280

[AC8](#) on page 304

Voice AM

AM-Modulation depth of the voice signal (in the range 300 Hz to 3000 Hz, identifier notched).

Remote command:

[AM9](#) on page 306

Freq 30 Hz

AF frequency of 30 Hz AM rotational signal

Remote command:

[AF0](#) on page 304

Freq 9960 Hz

Mean carrier frequency of the FM modulated subcarrier, typically at 9.96 kHz

Remote command:

[AF1](#) on page 305

Freq FM30

AF frequency of the 30 Hz reference signal

Remote command:

[AF2](#) on page 305

FM Index


FM frequency deviation of 30 Hz subcarrier

Remote command:

[FM1](#) on page 306

4.3.2.4 VOR distortion view

This view comprises all measurement parameters for the determination of the distortion factors in the VOR mode.



Subcarrier Harmonics.....	96
Subcarrier AM Distortion.....	96

Subcarrier Harmonics

Measures the distortions (up to 5th order) of the subcarrier harmonics.

"K2"	Distortion 2 nd order
"K3"	Distortion 3 rd order
"K4"	Distortion 4 th order
"K5"	Distortion 5 th order

Remote command:

[SUBCARR_K2](#) on page 307

[SUBCARR_K3](#) on page 307

[SUBCARR_K4](#) on page 308

[SUBCARR_K5](#) on page 308

Subcarrier AM Distortion

Measures the AM distortion of the subcarrier. During signal generation, different unwanted AM components appear. Depending on the number of segments used by the antenna, different results are displayed in the "Distortion" view (see ["No. of Segm"](#) on page 101). Note that in the data recording, all results are included, not only those displayed in the "Distortion" view.

"AM 60 Hz" Displays the AM distortion at a modulation frequency of 60 Hz

"AM 1k44(48)" Displays the AM distortion at 1440 Hz (48 segments * 30 Hz).

"AM 1k50(50)" Displays the AM distortion at 1500 Hz (50 segments * 30 Hz).

Remote command:


SUBCARR_AM1K44 on page 307

SUBCARR_AM1K50 on page 307

SUBCARR_AM60HZ on page 307

4.3.2.5 VOR ID analysis view

Displays the results of a morse signal analysis (optional).



Bearing (from)	97
Last ID	98
ID Code	98
ID Period	98
Dot Length	98
Dash Length	98
Dot-Dash Gap	98
Letter Gap	98
ID AM	98
ID Freq	99

Bearing (from)

Phase between both 30-Hz signals (direction of the R&S EVSF1000 in relation to the ground station).

A green bearing value indicates that a valid VOR signal has been determined.

Remote command:

[BE](#) on page 306

Last ID

Time since last ID pulse was measured

Remote command:

[LASTID_TIME](#) on page 289

ID Code

Morse-decoded ID with three or four letters.

Remote command:

[AC8](#) on page 280

[AC8](#) on page 304

ID Period

Time between two measured ID pulses

Remote command:

[ID_PERIOD](#) on page 289

Dot Length

Length of time a dot is transmitted in the used Morse code in milliseconds.

Remote command:

[ID_DOT_LENGTH](#) on page 288

Dash Length

Length of time a dash is transmitted in the used Morse cod in milliseconds.

Remote command:

[ID_DASH_LENGTH](#) on page 288

Dot-Dash Gap

Length of time that passes between a transmitted dot and a dash in the used Morse code in milliseconds.

Remote command:

[ID_DOTDASH_GAP](#) on page 289

Letter Gap

Length of time that passes between two transmitted letters in the used Morse code in milliseconds.

Remote command:

[ID_LETTER_GAP](#) on page 289

ID AM

AM Modulation depth of identifier signal (default: 1020 Hz).

Remote command:

[AM8](#) on page 282

[AM8](#) on page 305

ID Freq

Frequency of the morse signal.


Remote command:

[AF8](#) on page 281

[AF8](#) on page 305

4.3.2.6 VOR recording view

The Recording view displays the recorded data for VOR measurements from the selected data list (see ["List"](#) on page 202). If available, the stored GNSS data from the GNSS receiver is also displayed.



Which measurement results are stored is described in the remote commands, see [GETDATADEF](#) on page 366.

The individual measurement results are described in the other result views.

For details on data logging, see [Chapter 7.2, "Recording measurement data"](#), on page 200.



Status flags

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

Remote commands for retrieving results:

[GETDATADEF](#) on page 366

[GETDATASET](#) on page 366

4.3.3 Configuring VOR measurements

The following settings are available for VOR measurements.



Settings for recording, including trigger settings, are described in [Chapter 7.2, "Recording measurement data"](#), on page 200.



VOR measurements on LF input

Using the option R&S EVSG1-K7 LF-Analysis, you can also analyze the AF components of the VOR signal to determine AF parameters of the carrier.

Furthermore, you can use the LF input to measure signals with a very low intermediate frequency (<25 kHz). Such signals are provided as output at test points of a transmitter, for example, for tuning purposes.

For details on configuring a VOR measurement on LF input, see [Chapter 4.1.4.5, "LF input configuration"](#), on page 71.



For the mapping of hard- and softkey commands to keyboard commands using VNC, see [Table 1-3](#).

- [General measurement configuration](#)..... 101
- [Channel frequency configuration \(CH FREQ\)](#)..... 102
- [Ampt](#)..... 103
- [Bandwidth \(BW\)](#)..... 104
- [Setting the measurement time \(MTime\)](#)..... 104

4.3.3.1 General measurement configuration

Access VNC: [s]

Input RF/LF.....	101
Signal Direction.....	101
No. of Segm.....	101
Freq Offset.....	102

Input RF/LF

Access VNC: [s]

Configures the input source for the receiver.

For details on the connectors see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23.

"RF In"	An RF signal is provided from the RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000. They are connected to a receiving antenna (max. +13 dBm). The antenna must correspond to the specified frequency range for the measurement.
"LF In"	An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000. If both receivers are used, only one of them can be set to analyze input from "LF In". The LF In connector is only available if R&S EVSF1-B4 is installed. Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.

Remote command:

[GS_RFLF_INPUT](#) on page 278
[LLZ_RFLF_INPUT](#) on page 268
[VOR_RFLF_INPUT](#) on page 303
[FFT_RFLF_INPUT](#) on page 353
[SCOPE_RFLF_INPUT](#) on page 358
[SETUP:INPUT](#) on page 234

Signal Direction

Defines the reference for phase notation (see [Chapter 4.3.1.3, "Phase notation in VOR measurements"](#), on page 90).

"From"	North direction at the VOR beacon
"To"	North direction at the receiver/ aircraft

Remote command:

[SETUP:UNIT:VORDIRECTION](#) on page 254

No. of Segm

Selects the number of used antenna segments for which the AM distortion results are displayed. See also ["VOR receiver"](#) on page 86. Note that the data recording always includes all results.

48	The antenna contains 48 segments, the subcarrier has a modulation frequency of 1440 Hz. (Result: "AM1k44 (48)")
50	The antenna contains 50 segments, the subcarrier has a modulation frequency of 1500 Hz. (Result: "AM 1k50(50)")

Freq Offset

Defines a fixed frequency offset from the carrier.

Remote command:

[VOR_DEMFREQS_OFFSET](#) on page 302

4.3.3.2 Channel frequency configuration (CH FREQ)

Access VNC: [q]

The channel frequency determines the nominal frequency at which the measurement is performed. For some avionics standards, the channels are associated with specific frequencies. (See [Chapter A, "ILS channel frequency list"](#), on page 377 and [Chapter B, "VOR channel frequency list"](#), on page 379.)

CH	102
Freq	102
Step Size	102

CH

Sets the receiver frequency channel on the active receiver board according to the ICAO frequency list.

Remote command:

[RFCH](#) on page 231

Freq

Sets the nominal frequency for the measurement. By default, this frequency is also assumed to be the center frequency for spectrum displays, unless an offset is defined.

For measurements on two frequencies, the frequencies are defined as offsets to this nominal frequency.

Remote command:

[RF](#) on page 231

Step Size

Defines the frequency step size for the rotary knob when setting the frequency.

In many avionics signals, channels are assigned to frequencies with a fixed offset. By setting the step size of the rotary knob to the fixed offset, you can easily scroll through the signal's channel frequencies using the rotary knob. Thus, for example, you can analyze the measurement results for one channel after the other simply by changing the selected channel frequency with the rotary knob.

The default step size for ILS/VOR mode is 50 kHz.

Remote command:

ILS mode:

[LLZ_DEFAULT_FREQSTEP](#) on page 264

[GS_DEFAULT_FREQSTEP](#) on page 274

VOR mode:

[VOR_DEFAULT_FREQSTEP](#) on page 301

4.3.3.3 Ampt

Access VNC: [w]

The following settings define the amplification for the input signal.

RF Att.....	103
RF Mode.....	103
Transducer Correction.....	104

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual"	The RF attenuation mode is specified manually (see "RF Mode" on page 69).
"Auto"	The RF attenuation mode is selected automatically. The signal attenuation is selected automatically according to the signal strength. This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable. When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

4.3.3.4 Bandwidth (BW)

Access VNC: [e]

IF BW

Determines the frequency range for which the measurement is performed on the IF signal.

Ensure that the entire input signal lies within the specified bandwidth, particularly for narrow bandwidths.

Remote command:

[VOR_DEM_BW](#) on page 301

AM30 BW

Defines the filter bandwidth with which the 30 Hz AM rotational signal is demodulated.

Remote command:

[VOR_DEM_AM_BW](#) on page 301

FM BW

Defines the filter bandwidth with which the 30 Hz reference signal is demodulated.

Remote command:

[VOR_DEM_FM_BW](#) on page 302

Bear.Filt.

Defines the filter type used to determine the bearing angle.

"Narrow" For small input levels

"Wide" Faster; used in previous software releases

Remote command:

[VOR_DEM_BEARFILTER](#) on page 301

4.3.3.5 Setting the measurement time (MTime)

Access VNC: [d]

The measurement time determines the interval at which new measurement results are displayed. Internally, values are captured every 10 ms, that is: 100 per second.

If the defined measurement time is longer, the values captured internally in that interval are averaged and only the average value is displayed.

Note that the measurement time determines the minimum interval for values to be stored during recording (see ["Time"](#) on page 203).

Enter the time in milliseconds.

Remote command:

[MEASTIME](#) on page 231

4.4 R&S EVSG-K6 COM analysis

Access VNC: [m] > Down arrow key

If the R&S EVSG-K6 COM analysis option is installed, signals from VHF/UHF communication channels can be analyzed with the R&S EVSF1000. Very high frequency (VHF) and ultrahigh frequency (UHF) communication is used for air traffic control (ATC COM), for example.

The COM mode can be used to analyze both the civil aircraft band and military frequencies, with channels spaced at 25 kHz or 8.33 kHz.

The R&S EVSF1000 can perform COM measurements on signals containing one or two carriers (see [Chapter 4.1.4.2, "Channel and frequency configuration"](#), on page 64). It assumes a 1000 Hz test tone is being sent.

Remote command:

[MODE_COM](#) on page 310

4.4.1 COM measurement results

The COM measurement provides the following results. For measurements on two frequencies, the results for the individual frequencies and the sum of both are displayed.



You can display graphical results directly from the COM mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

To return from the graphical results to the COM mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.1, "R&S EVSG-K10 RF spectrum analysis"](#), on page 125
- [Chapter 5.2, "IF spectrum analysis"](#), on page 130
- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143

Remote command:

[MODE_COM](#) on page 310

- [RF level and frequency display](#)..... 106
- [IF spectrum preview](#)..... 107
- [COM main view](#)..... 108
- [COM recording view](#)..... 110

4.4.1.1 RF level and frequency display

The measured RF power and frequency of the input signal are displayed both numerically and graphically.




Figure 4-23: RF level display

The following results are provided:

- Numeric power level in dBm ("Lev")
For measurements on two frequencies: individual and sum power levels
- Measured frequency offset to the nominal frequency in kHz
- Numeric frequency offset of measured power
- Bargraph indicating the power and a color-coded overload state, where:
 - **Red:** overload state, check message
 - **Yellow:** power approaching overload state
 - **Green:** power in a valid range
- If applicable: overload messages



Overflow messages

The following messages indicate an overload:

- "RF Overload"
Overload of the input mixer or of the analog IF path.
- "IF Overload"
Overload of the IF signal.
- "ADC Overload"
The dynamic range of the AD-converter is exceeded (clipping).

A combination of these overloads is also possible.

In all cases, set the RF attenuation to normal or low distortion (for RF input), or reduce the input level.

In recorded data lists, overloads are indicated by an "O", see ["Status flags"](#) on page 63.

Remote commands to retrieve results:

[LA?](#) on page 231

[RF?](#) on page 231

COM mode:

[GET_MEASFREQ](#) on page 315

[GET_TX1_MEASFREQ](#) on page 318

[GET_TX2_MEASFREQ](#) on page 320

[GET_TX1_LEVEL](#) on page 318

[GET_TX2_LEVEL](#) on page 319

4.4.1.2 IF spectrum preview

A preview of the measured spectrum (power level vs. frequency) for the IF (intermediate frequency) signal is provided. The center frequency is the nominal channel frequency. The frequency range shows the measured bandwidth. The power range is selected such that the noise level remains visible.




Figure 4-24: IF spectrum preview

This preview spectrum allows you to check if the current measurement settings are appropriate, such as the bandwidth or frequency offsets. For a larger, more detailed spectrum diagram, select one of the graphical Spectrum modes. If you switch to such a mode directly from a numeric measurement mode, the current measurement settings are applied to the spectrum automatically.

4.4.1.3 COM main view

The COM Main view provides the following measurement results for the 1 kHz/1.2 kHz test tone (see "Tone Freq." on page 112):




Figure 4-25: COM Main view



You can display graphical results directly from the COM mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

To return from the graphical results to the COM mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.1, "R&S EVSG-K10 RF spectrum analysis"](#), on page 125
- [Chapter 5.2, "IF spectrum analysis"](#), on page 130
- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143

Remote command:

[VIEW_COM](#) on page 310

AM 1.0 kHz/ 1.2 kHz	109
Freq 1.0 kHz/ 1.2 kHz	109
K2 1.0 kHz/ 1.2 kHz	109
K3 1.0 kHz/ 1.2 kHz	109
K4 1.0 kHz/ 1.2 kHz	109
THD 1.0 kHz/ 1.2 kHz	110

AM 1.0 kHz/ 1.2 kHz

Displays the AM modulation of a 1 kHz/ 1.2 kHz test tone at the individual carrier frequencies and for both carriers together.

Remote command:

[GET_ONE_AMMOD_1_0](#) on page 315

[GET_TX1_AMMOD_1_0](#) on page 317

[GET_TX2_AMMOD_1_0](#) on page 319

[GET_ONE_AMMOD_1_2](#) on page 315

[GET_TX1_AMMOD_1_2](#) on page 317

[GET_TX2_AMMOD_1_2](#) on page 319

Freq 1.0 kHz/ 1.2 kHz

Displays the demodulated frequency of the 1 kHz/ 1.2 kHz AM test tone at the individual carrier frequencies and for both carriers together.

Remote command:

[GET_ONE_AMFREQ_1_0](#) on page 315

[GET_TX1_AMFREQ_1_0](#) on page 317

[GET_TX2_AMFREQ_1_0](#) on page 319

[GET_ONE_AMFREQ_1_2](#) on page 315

[GET_TX1_AMFREQ_1_2](#) on page 317

[GET_TX2_AMFREQ_1_2](#) on page 319

K2 1.0 kHz/ 1.2 kHz

Distortion 2nd order, 1.0 kHz/ 1.2 kHz signal

Remote command:

[GET_K2_1K0](#) on page 314

[GET_K2_1K2](#) on page 314

K3 1.0 kHz/ 1.2 kHz

Distortion 3rd order, 1.0 kHz/ 1.2 kHz signal

Remote command:

[GET_K3_1K0](#) on page 314

[GET_K3_1K2](#) on page 314

K4 1.0 kHz/ 1.2 kHz

Distortion 4th order, 1.0 kHz/ 1.2 kHz signal

Remote command:

[GET_K4_1K0](#) on page 314

[GET_K4_1K2](#) on page 315

THD 1.0 kHz/ 1.2 kHz

Total Harmonic Distortion (THD), 1.0 kHz/ 1.2 kHz signal

Remote command:

[GET_THD_1K0](#) on page 316

[GET_THD_1K2](#) on page 317

4.4.1.4 COM recording view

The Recording view displays the recorded data for COM measurements from the selected data list (see ["List"](#) on page 202). If available, the stored GNSS data from the GNSS receiver is also displayed.



Which measurement results are stored is described in the remote commands, see [GETDATADEF](#) on page 366.

The individual measurement results are described in [Chapter 4.4.1.3, "COM main view"](#), on page 108.

For details on data logging see [Chapter 7.2, "Recording measurement data"](#), on page 200.



Status flags

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

4.4.2 COM configuration

In this view, the measurements settings available for the currently active mode, can be configured.

- [Channel and frequency configuration](#)..... 111
- [Ampt](#)..... 113
- [Bandwidth \(BW\)](#)..... 114
- [Setting the measurement time \(MTime\)](#)..... 114

4.4.2.1 Channel and frequency configuration

The ILS Localizer and Glidepath measurements can detect both course and clearance carriers simultaneously. Alternatively, the individual carriers can be measured only, or any one or two user-defined frequencies. By default, a wideband measurement is performed. The available measurement settings depend on the selected channel and frequency configuration.

- [Channel setup](#)..... 111
- [Carrier configuration](#)..... 112
- [Channel frequency configuration \(CH FREQ\)](#)..... 112

Channel setup

Access VNC: [a] > [F1]

1F/2F

Selects the number of frequencies or channels to be measured.

- "1F" One frequency only is measured, namely the nominal frequency, which is also the center frequency.
 The nominal frequency is configured by the [Freq](#) settings.

"2F" Two frequencies are measured at the same time. Which frequencies are measured is configured by the [Freq](#) settings. The numeric results are calculated as the sum of both frequencies. In the RF Level display, the individual carriers are also indicated. In the RF Spectrum preview, both carriers are displayed.

Remote command:

[COM_1F2F_MEASMODE](#) on page 311

Carrier configuration

Access VNC: [s] > "F1"

Configures the carriers and frequencies for measurements on a single or two frequencies. Which settings are available depends on the measurements on the ["1F/2F"](#) on page 111.

TX1 Offset/TX2 Offset	112
Tone Freq	112

TX1 Offset/TX2 Offset

The two carriers are defined as offsets to either side of the nominal tone frequency. "TX1 Offset" defines the upper carrier with a positive offset to the tone frequency. "TX2 Offset" defines the lower carrier with a negative offset to the tone frequency.

Remote command:

[AMFREQ_OFFSET_TX1](#) on page 310

[AMFREQ_OFFSET_TX2](#) on page 310

Tone Freq.

The nominal tone frequency used to measure all results for both carriers.

Remote command:

[COM_TONEFREQ_1K01K2](#) on page 312

Channel frequency configuration (CH FREQ)

Access VNC: [q]

The carrier frequency determines the nominal frequency at which the measurement is performed.

Freq	112
Step Size	113

Freq

Sets the nominal frequency for the measurement. By default, this frequency is also assumed to be the center frequency for spectrum displays, unless an offset is defined.

For measurements on two frequencies, the frequencies are defined as offsets to this nominal frequency.

Remote command:

[RF](#) on page 231

Step Size

Defines the frequency step size for the rotary knob when setting the frequency.

The default step size for COM mode is 8.33 kHz.

4.4.2.2 Ampt**Access VNC:** [w]

The following settings define the amplification for the input signal.

RF Att.....	113
RF Mode.....	113
Transducer Correction.....	114

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual"	The RF attenuation mode is specified manually (see "RF Mode" on page 69).
"Auto"	The RF attenuation mode is selected automatically. The signal attenuation is selected automatically according to the signal strength. This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable. When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

4.4.2.3 Bandwidth (BW)

Access VNC: [e]

The bandwidth determines the filter width with which the measurement is performed. The wider the filter, the less measurement time is required, but also the less sensitive the frequency results.

BW 1F BW 2F

Specifies the filter bandwidth for the single or both carriers.

Remote command:

[COM_DEMOD_BW_1F](#) on page 311

[COM_DEMOD_BW_2F](#) on page 311

4.4.2.4 Setting the measurement time (MTime)

Access VNC: [d]

The measurement time determines the interval at which new measurement results are displayed. Internally, values are captured every 10 ms, that is: 100 per second.

If the defined measurement time is longer, the values captured internally in that interval are averaged and only the average value is displayed.

Note that the measurement time determines the minimum interval for values to be stored during recording (see "[Time](#)" on page 203).

Enter the time in milliseconds.

Remote command:

[MEASTIME](#) on page 231

4.5 Non-directional beacon mode

Access VNC: [m] > Down arrow key

Using the LF IN connector and the R&S EVSG1-K7 LF-Analysis option, the R&S EVSF1000 can analyze non-directional beacon signals.

Remote command:

[MODE_NDB](#) on page 333

- [Basics on Non-Directional beacons](#)..... 115
- [NDB measurement and results](#)..... 115
- [Configuring NDB measurements](#)..... 121

4.5.1 Basics on Non-Directional beacons

Non-directional beacons (NDBs) transmit a signal at a specific carrier frequency, but without a specific direction. NDBs used for aviation transmit signals at frequencies between 190 kHz and 1750 kHz, according to ICAO annex 10 (see [3]). Each beacon is identified by a morse code, which is transmitted at either 400 Hz or 1020 Hz. Due to the low transmission frequency, NDBs are useful particularly for middle distance navigation.

4.5.2 NDB measurement and results

Due to the large number of different signal parameters, the NDB measurement provides multiple views for the measurement results.



You can display graphical results directly from the NDB mode by selecting the softkey in the "Meas" menu. In this case, the settings for the current measurement are applied to the graphical results.

To return from the graphical results to the NDB mode, select "Return" ([F7]).

For details on the graphical results, see:

- [Chapter 5.3, "R&S EVSG-K11 AF spectrum analysis"](#), on page 134
- [Chapter 5.4, "R&S EVSG-K12 Time domain analysis"](#), on page 143

Remote command:

[VIEW_NDB](#) on page 335

- [RF level, frequency and IF spectrum display](#)..... 116
- [NDB ID analysis](#)..... 117
- [NDB distortion view](#)..... 118
- [NDB recording view](#)..... 120

4.5.2.1 RF level, frequency and IF spectrum display

The measured RF power and frequency of the LF input signal is displayed both numerically and graphically.




Figure 4-26: RF level display

The following results are provided:

- Numeric power level in dBµV or dBm ("Lev")
- Measured frequency offset to the tuned carrier frequency in kHz
- Bargraph indicating the power (blue) and a color-coded overload state, where:
 - **red**: overload state, check message
 - **yellow**: power approaching overload state
 - **green**: power in a valid range
- If applicable: "ADC Overload" message
The dynamic range of the A/D-converter is exceeded (clipping).

IF Spectrum

A preview of the measured spectrum (power level vs. frequency) for the IF (intermediate frequency) signal is provided. The center frequency corresponds to the tuned carrier frequency. The frequency range shows the measured bandwidth. The amplitude range displays the entire dynamic range.




Figure 4-27: IF spectrum preview

Remote commands to retrieve results:

[RF?](#) on page 231

[LA?](#) on page 231

4.5.2.2 NDB ID analysis

Displays the results of the NDB signal id analysis. The ID can be analyzed at 400 Hz or 1020 Hz, see "ID Freq" on page 122.



Last ID.....	117
Carr Lev Change.....	117
ID Code.....	118
ID Period.....	118
Dot Length.....	118
Dash Length.....	118
Dot-Dash Gap.....	118
Letter Gap.....	118
ID AM.....	118
ID Freq.....	118

Last ID

Time since last ID pulse was measured

Remote command:

[LASTID_TIME](#) on page 289

Carr Lev Change

Variance in power level during ID transmission.

Remote command:

[NDB_CARLEV_CHANGE](#) on page 336

ID Code

Morse-decoded ID with three or four letters.

Remote command:

[ID_CODE](#) on page 336

ID Period

Time between two measured ID pulses

Remote command:

[ID_PERIOD](#) on page 289

Dot Length

Length of time a dot is transmitted in the used Morse code in milliseconds.

Remote command:

[ID_DOT_LENGTH](#) on page 288

Dash Length

Length of time a dash is transmitted in the used Morse cod in milliseconds.

Remote command:

[ID_DASH_LENGTH](#) on page 288

Dot-Dash Gap

Length of time that passes between a transmitted dot and a dash in the used Morse code in milliseconds.

Remote command:

[ID_DOTDASH_GAP](#) on page 289

Letter Gap

Length of time that passes between two transmitted letters in the used Morse code in milliseconds.

Remote command:

[ID_LETTER_GAP](#) on page 289

ID AM

AM Modulation depth of identifier signal.

Remote command:

[NDB_AMMOD](#) on page 336

ID Freq

Frequency of the morse signal.

Remote command:

[NDB_AMFREQ](#) on page 336

4.5.2.3 NDB distortion view

The NDB Dist view comprises the distortion factors for the beacon ID. The ID can be analyzed at 400 Hz or 1020 Hz, see "[ID Freq](#)" on page 122.




Figure 4-28: NDB Distortion view

AM 400/1020 Hz.....	119
K2 400/1020 Hz.....	119
K3 400/1020 Hz.....	119
K4 400/1020 Hz.....	120
Unwanted AM 30 to 120 Hz.....	120
THD 400/1020 Hz.....	120

AM 400/1020 Hz
 AM modulation depth of 400/1020 Hz beacon ID.
 Remote command:
[NDB_AMMOD](#) on page 336

K2 400/1020 Hz
 Distortion 2nd order, 400/1020 Hz beacon ID
 Remote command:
[NDB_K2_PCT](#) on page 337

K3 400/1020 Hz
 Distortion 3rd order, 400/1020 Hz beacon ID
 Remote command:
[NDB_K3_PCT](#) on page 337

K4 400/1020 Hz

Distortion 4th order, 400/1020 Hz beacon ID

Remote command:

[NDB_K4_PCT](#) on page 337

Unwanted AM 30 to 120 Hz

Measures spurs in the antenna switching range.

Remote command:

[NDB_POWSUPPL_FC](#) on page 337

THD 400/1020 Hz

Total Harmonic Distortion (THD), 400/1020 Hz beacon ID

Remote command:

[NDB_THD_PCT](#) on page 337

4.5.2.4 NDB recording view

The Recording view displays the recorded data for NDB measurements from the selected data list (see ["List"](#) on page 202).



Which measurement results are stored is described in the remote commands, see [GETDATADEF](#) on page 366.

The individual measurement results are described in the other NDB result views.

For details on data logging, see [Chapter 7.2, "Recording measurement data"](#), on page 200.



Status flags

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

4.5.3 Configuring NDB measurements

NDB measurements are always performed on LF input, using AC coupling. They require the R&S EVSG1-K7 LF-Analysis option.

The following settings are configurable for the NDB measurement.



Settings for recording, including trigger settings, are described in [Chapter 7.2, "Recording measurement data"](#), on page 200.



For the mapping of hard- and softkey commands to keyboard commands using VNC, see [Table 1-3](#).

• General measurement settings	121
• Receiver frequency	122
• Amplitude	122
• Setting the bandwidth	123
• Setting the measurement time (MTime)	124

4.5.3.1 General measurement settings

Access VNC: [s]

Some general settings are available for NDB measurements.

Level Unit	121
ID Freq	122

Level Unit

Switches the unit for all level displays in NDB measurement results between dBµV (default) and dBm.

Remote command:

[NDB_UNIT_LEVEL](#) on page 335

ID Freq

The NDB ID can be analyzed at 400 Hz or 1020 Hz.

Remote command:

[NDB_IDFREQ_400_1020](#) on page 336

4.5.3.2 Receiver frequency

Access VNC: [q]

The receiver frequency determines the nominal frequency at which the measurement is performed.

Freq	122
Step Size	122

Freq

Sets the nominal frequency for the measurement.

Remote command:

[RF](#) on page 231

Step Size

Defines the frequency step size for the rotary knob when setting the frequency.

The default step size for NDB mode is 1.0 kHz.

Remote command:

[NDB_DEFAULT_FREQSTEP](#) on page 333

4.5.3.3 Amplitude

Access VNC: [w]

The following settings define the amplification for the input signal.

RF Att	122
RF Mode	123
LF Imp	123
Transducer Correction	123

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Chapter 4.5.2.1, "RF level, frequency and IF spectrum display"](#), on page 116). Note that the valid level range depends on the selected measurement mode.

"Manual" The RF attenuation mode is specified manually (see ["RF Mode"](#) on page 69).

"Auto" The RF attenuation mode is selected automatically.
 The signal attenuation is selected automatically according to the signal strength.
 This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable.
 When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

LF Imp.

Switches the impedance for the LF input between 50 Ω and 20 k Ω .

For an impedance of 20 k Ω , the level is indicated as the voltage of the EMF (no-load voltage). The unit is automatically set to "dB μ V(EMF)".

Remote command:

[NDB_LFIN_IMPEDANCE](#) on page 334

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[NDB_EXTERNALATT_LFIN](#) on page 334

4.5.3.4 Setting the bandwidth

Access VNC: [e]

The bandwidth determines the frequency range for which the measurement is performed. Depending on the measurement mode, and whether a wideband or a specific frequency is measured, different settings are available.

[IF BW](#) 124

[IF BW Dist](#) 124

IF BW

Demodulation bandwidth used for level and modulation measurement.

Remote command:

[NDB_DEM_ID_BW](#) on page 333

IF BW Dist

Specifies the IF filter bandwidth for audio and distortion measurements.

Remote command:

[NDB_DEM_DIST_BW](#) on page 334

4.5.3.5 Setting the measurement time (MTime)

Access VNC: [d]

The measurement time determines the interval at which new measurement results are displayed. Internally, values are captured every 10 ms, that is: 100 per second.

If the defined measurement time is longer, the values captured internally in that interval are averaged and only the average value is displayed.

Note that the measurement time determines the minimum interval for values to be stored during recording (see ["Time"](#) on page 203).

Enter the time in milliseconds.

Remote command:

[MEASTIME](#) on page 231

5 Graphic measurement modes

- [R&S EVSG-K10 RF spectrum analysis](#).....125
- [IF spectrum analysis](#).....130
- [R&S EVSG-K11 AF spectrum analysis](#).....134
- [R&S EVSG-K12 Time domain analysis](#).....143
- [Using markers in the graphical displays](#).....152

5.1 R&S EVSG-K10 RF spectrum analysis

Access VNC: [m] > Down arrow key

The RF Spectrum mode displays the power vs. frequency diagram (spectrum) for a user-defined frequency range of the input signal. This diagram is useful to obtain an overview of the entire input signal. The RF Spectrum requires the R&S EVSG-K10 RF spectrum analysis option.

The x-axis displays the absolute measured frequency in Hz. The y-axis displays the measured power levels in dBm.

Marker functions allow you to analyze specific details in the spectrum.



Figure 5-1: RF Spectrum



Generally, each mode is configured individually. When you switch modes, the most recently defined settings for that mode are applied.

However, graphical results can also be displayed directly from the measurement modes with numeric results. In this case, the settings for the current mode are applied to the graphical results.

If the original measurement mode analyzes multiple carriers, you must select the carrier for which you want to see the graphical results when you switch the mode.

The following settings are displayed in the measurement settings area of the RF spectrum:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "RF Spectrum". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- Frequency range
"Center", "Span", "Start", "Stop"
The swept frequency range, see [Chapter 5.1.1, "Configuring the frequency range"](#), on page 126.
- RF attenuation ("Att")
The used attenuation mode; see also ["RF Mode"](#) on page 69.
- Reference level ("Ref Lev")
The maximum expected power level, see ["Ref Level"](#) on page 128.
- Level correction ("Lev Corr")
The applied level correction by a transducer. See ["Transducer Correction"](#) on page 69.
- Resolution Bandwidth ("RBW")
Resolution bandwidth with which the measurement is performed. See ["Resolution Bandwidth \(RBW Mode/Res BW\)"](#) on page 127.

Remote command to select RF Spectrum mode:

[MODE_FSCAN](#) on page 338

Remote command to retrieve trace results:

[FSCAN_GETSPECT](#) on page 342

5.1.1 Configuring the frequency range

Access VNC: [q]

The following settings configure the frequency range of the spectrum, that is: the x-axis.

Define the frequency range to be displayed using one of the following methods:

- **Center + Span**: the center frequency is displayed in the center of the x-axis, with half the span to either side
- **Start + Stop**: the x-axis starts with the start frequency and ends with the stop frequency

Center.....	127
Span.....	127
Start.....	127
Stop.....	127

Center
 Configures the center frequency. The configured value is displayed as "Center" in the measurement settings area.
 Remote command:
[FSCAN_FREQCENTER](#) on page 339

Span
 Configures the frequency span, which must be at least 100 kHz. The configured value is displayed as "Span" in the measurement settings area.
 Remote command:
[FSCAN_FREQSPAN](#) on page 339

Start
 Configures the start frequency of the x-axis. The configured value is displayed as "Start" in the measurement settings area.
 Remote command:
[FSCAN_FREQSTART](#) on page 340

Stop
 Configures the stop frequency of the x-axis. The configured value is displayed as "Stop" in the measurement settings area.
 Remote command:
[FSCAN_FREQSTOP](#) on page 340

5.1.2 **Configuring the bandwidth**

Access VNC: [e] > "F1"
[Resolution Bandwidth \(RBW Mode/Res BW\)](#)..... 127

Resolution Bandwidth (RBW Mode/Res BW)
 Defines the resolution bandwidth (RBW) of the spectrum. The resolution bandwidth defines the minimum frequency separation at which the individual components of a spectrum can be distinguished. Small values result in high precision, as the distance between two distinguishable frequencies is small. Higher values decrease the precision, but increase measurement speed.
 The RBW can be determined automatically by the R&S EVSF1000, or manually.

AUTO mode The RBW is determined automatically according to the sweep time and frequency range.

Manual mode Select a predefined fixed value manually.

Remote command:

[FSCAN_RESBW_AUTO](#) on page 341

[FSCAN_RES_BW](#) on page 341

5.1.3 Configuring the amplitude (y-axis)

Access VNC: [w]

The amplitude settings configure the y-axis of the spectrum.

Ref Level	128
Y-Range	128
RF Mode	128
Transducer Correction	129

Ref Level

The reference level determines the maximum power level displayed in the spectrum. Adjust the reference level as close as possible to the highest expected power level to avoid overload at the RF input or signal clipping.

Remote command:

[FSCAN_REFLEVEL](#) on page 340

Y-Range

Determines the displayed power level range on the y-axis of the spectrum. The range starts at the specified [Ref Level](#) at the top of the diagram.

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

5.1.4 Configuring the trace**Access VNC: [a]**

Trace settings determine how the display values are calculated from the measured values.

Trace mode	129
Average Count	129

Trace mode

Defines the update mode for subsequent traces.

"Clear/Write"	Overwrite mode (default): the trace is overwritten by each sweep
"Average"	The average is determined over several sweeps The Average Count determines the number of averaging procedures.
"Max Hold"	The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one. The Average Count determines the number of sweeps to evaluate.
"RMS"	The RMS value for each trace point over several sweeps is determined and displayed. The Average Count determines the number of sweeps to evaluate.

Remote command:

[FFT_TRACEMODE](#) on page 353

[IFSPECT_TRACE_MODE](#) on page 346

[FSCAN_TRACE_MODE](#) on page 341

Average Count

Determines the number of sweeps over which trace evaluation is performed (e.g. averaging or maxhold).

Remote command:

[FFT_TRACE_AVRGCOUNT](#) on page 354

[IFSPECT_TRACE_AVRGCOUNT](#) on page 346

[FSCAN_TRACE_AVRGCOUNT](#) on page 342

5.2 IF spectrum analysis

Access VNC: [m] > Down arrow key

IF Spectrum mode displays the measured power vs frequency spectrum for a (small) span around the center frequency of the input signal. This diagram is useful to perform detailed analysis on the signal around the center frequency. This mode requires the R&S EVSG-K10 RF spectrum analysis option.

The x-axis displays the frequency offset to the nominal RF frequency in Hz. The y-axis displays the measured power levels in dBm.

Marker functions allow you to analyze specific details in the spectrum.



Figure 5-2: IF Spectrum



Generally, each mode is configured individually. When you switch modes, the most recently defined settings for that mode are applied.

However, graphical results can also be displayed directly from the measurement modes with numeric results. In this case, the settings for the current mode are applied to the graphical results.

If the original measurement mode analyzes multiple carriers, you must select the carrier for which you want to see the graphical results when you switch the mode.

The following settings are displayed in the measurement settings area of the RF spectrum:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "RF Spectrum". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- Frequency range ("RF Freq", "Span")
The swept frequency range, see ["RF Freq"](#) on page 131.
- Reference level ("Ref Lev")
The maximum expected power level, see ["Ref Level"](#) on page 132.
- Level correction ("Lev Corr")
The applied level correction by a transducer. See ["Transducer Correction"](#) on page 69.
- Resolution Bandwidth ("RBW")
Resolution bandwidth with which the measurement is performed. See ["RBW"](#) on page 132.

Remote command to select RF Spectrum mode:

[MODE_IFSPECT](#) on page 343

Remote command to retrieve trace results:

[IFSPECT_GETSPECT](#) on page 347

5.2.1 Configuring the frequency range

Access VNC: [q]

The following settings configure the frequency range of the spectrum, that is: the x-axis.

RF Freq	131
Span	131

RF Freq

Configures the center frequency. The configured value is displayed as "RF Freq" in the measurement settings area.

Remote command:

[IFSPECT_FREQRF](#) on page 344

Span

Configures the frequency span, which must be at least 100 kHz. The span is distributed evenly to the left and right of the ["RF Freq"](#) on page 131. The configured value is displayed as "Span" in the measurement settings area.

Remote command:

[IFSPECT_FREQ_SPAN](#) on page 344

5.2.2 Configuring the bandwidth

Access VNC: [e] > "F1"

[RBW](#)..... 132

RBW

Defines the resolution bandwidth (RBW) of the spectrum. The resolution bandwidth defines the minimum frequency separation at which the individual components of a spectrum can be distinguished. Small values result in high precision, as the distance between two distinguishable frequencies is small. Higher values decrease the precision, but increase measurement speed.

The RBW can be determined automatically by the R&S EVSF1000, or manually.

AUTO mode The RBW is determined automatically according to the sweep time and frequency range.

Manual mode Select a predefined fixed value manually.

Remote command:

[IFSPECT_RES_BW](#) on page 345

[IFSPECT_RESBW_AUTO](#) on page 345

5.2.3 Configuring the amplitude (Y-Axis)

Access VNC: [w]

The amplitude settings configure the y-axis of the spectrum.

[Ref Level](#)..... 132
[Y-Range](#)..... 132
[RF Att](#)..... 133
[RF Mode](#)..... 133
[Transducer Correction](#)..... 133

Ref Level

The reference level determines the maximum power level displayed in the spectrum. Set the reference level as close as possible to the highest expected power level to avoid overload at the RF input or signal clipping.

Remote command:

[IFSPECT_REFLEVEL](#) on page 345

Y-Range

Determines the displayed power level range on the y-axis of the spectrum. The range starts at the specified [Ref Level](#) at the top of the diagram.

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

- | | |
|----------|---|
| "Manual" | The RF attenuation mode is specified manually (see "RF Mode" on page 69). |
| "Auto" | <p>The RF attenuation mode is selected automatically.</p> <p>The signal attenuation is selected automatically according to the signal strength.</p> <p>This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable.</p> <p>When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.</p> |

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

- | | |
|-------------|---|
| "Low Noise" | <p>15 dB pre-amplification</p> <p>Provides a high sensitivity. Suitable when scanning the area for distant signals.</p> |
| "Norm" | <p>0 dB</p> <p>Provides a normal sensitivity.</p> |
| "Low Dist" | <p>15 dB attenuation</p> <p>Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.</p> |

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

Transducer Correction

Configures the level correction. The specified value is added to the measured power levels to compensate for an inherent offset by the measurement setup, for example the antenna.

Remote command:

[SETUP:EXTERNALATT_RX1](#) on page 233

[SETUP:EXTERNALATT_RX2](#) on page 233

5.2.4 Configuring the trace

Access VNC: [a]

Trace settings determine how the display values are calculated from the measured values.

Trace mode.....	134
Average Count.....	134

Trace mode

Defines the update mode for subsequent traces.

"Clear/Write"	Overwrite mode (default): the trace is overwritten by each sweep
"Average"	The average is determined over several sweeps The Average Count determines the number of averaging procedures.
"Max Hold"	The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one. The Average Count determines the number of sweeps to evaluate.
"RMS"	The RMS value for each trace point over several sweeps is determined and displayed. The Average Count determines the number of sweeps to evaluate.

Remote command:

[FFT_TRACEMODE](#) on page 353

[IFSPECT_TRACE_MODE](#) on page 346

[FSCAN_TRACE_MODE](#) on page 341

Average Count

Determines the number of sweeps over which trace evaluation is performed (e.g. averaging or maxhold).

Remote command:

[FFT_TRACE_AVRGCOUNT](#) on page 354

[IFSPECT_TRACE_AVRGCOUNT](#) on page 346

[FSCAN_TRACE_AVRGCOUNT](#) on page 342

5.3 R&S EVSG-K11 AF spectrum analysis

Access VNC: [m] > Down arrow key

AF Spectrum mode displays the spectrum of a demodulated RF signal with AM components. This mode requires the R&S EVSG-K11 AF spectrum analysis option.

The x-axis displays the absolute measured frequency in kHz. The y-axis displays the modulation depth in dB.

Marker functions allow you to analyze specific details in the spectrum.




Figure 5-3: AF Spectrum for RF input

The following settings are displayed in the measurement settings area of the RF spectrum:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "AF Spectrum". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- "RF Freq"
Nominal measurement frequency of the RF signal, see ["RF Freq"](#) on page 138.
- "RF Lev"
The measured level of the RF signal
- Frequency range
"AF Center", "AF Span", "AF Start", "AF Stop"
The swept frequency range, see [Chapter 5.1.1, "Configuring the frequency range"](#), on page 126.
- RF attenuation ("Att")
The used attenuation mode; see also ["RF Mode"](#) on page 69.
- Resolution Bandwidth ("RBW")
Resolution bandwidth with which the measurement is performed. See ["Resolution Bandwidth \(RBW Mode/Res BW\)"](#) on page 127.

- For ILS or VOR signals: the modulation of the selected carrier ("AM Demod", "VOR Subc. AM", "VOR Subc. FM"), see ["Switching from numeric to graphical results"](#) on page 91

AF Spectrum for LF input

Using option R&S EVSG1-K7 LF-Analysis, you can also analyze LF input (AF signals only) in the AF Spectrum mode. In this case, the y-axis displays the modulation depth in volt.



Figure 5-4: AF Spectrum for LF input

For LF input, the following settings are displayed:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode
The currently active measurement mode on the active receiver board, e.g. "AF Spectrum". See [Chapter 3.3, "Measurement mode"](#), on page 41.
- Frequency range
"AF Center", "AF Span", "AF Start", "AF Stop"
The swept frequency range, see [Chapter 5.3.2, "Configuring the frequency range"](#), on page 138.
- LF Input type ("LF In")
Only AF signals can be analyzed as LF input in AF Spectrum mode. See ["Input RF/LF"](#) on page 63.

- ("Range")
Sensitivity of the measurement. See ["Range"](#) on page 72.
- Measurement Bandwidth ("AF In BW")
Measurement bandwidth for LF input. See ["AF In BW"](#) on page 139.
- Resolution bandwidth for LF input ("AF Res BW")
Resolution bandwidth with which the AF signal measurement is performed. See [Chapter 5.3.3, "Configuring the bandwidth"](#), on page 139.
- For ILS or VOR signals: the modulation of the selected carrier ("AM Demod", "AM Demod Offset" (low IF mode), "VOR Subc. AM", "VOR Subc. FM"), see ["Switching from numeric to graphical results"](#) on page 91



Generally, each mode is configured individually. When you switch modes, the most recently defined settings for that mode are applied.

However, graphical results can also be displayed directly from the measurement modes with numeric results. In this case, the settings for the current mode are applied to the graphical results.

If the original measurement mode analyzes multiple carriers, you must select the carrier for which you want to see the graphical results when you switch the mode.

Remote command to select RF Spectrum mode:

[MODE_FFT](#) on page 348

Remote command to retrieve trace results:

[FFT_GETSPECT](#) on page 354

- [Configuring the input signal](#).....137
- [Configuring the frequency range](#).....138
- [Configuring the bandwidth](#).....139
- [Configuring the amplitude \(Y-Axis\) for RF input](#).....140
- [Configuring the amplitude \(Y-Axis\) for LF input](#).....141
- [Configuring the trace](#).....143

5.3.1 Configuring the input signal

The AF Spectrum mode can display graphical results for RF or LF input.

Input RF/LF

Access VNC: [s]

Configures the input source for the receiver.

For details on the connectors see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23.

"RF In" An RF signal is provided from the RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000. They are connected to a receiving antenna (max. +13 dBm). The antenna must correspond to the specified frequency range for the measurement.

- "LF In" An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.
 If both receivers are used, only one of them can be set to analyze input from "LF In".
 The LF In connector is only available if R&S EVSF1-B4 is installed.
 Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.

Remote command:

[GS_RFLF_INPUT](#) on page 278

[LLZ_RFLF_INPUT](#) on page 268

[VOR_RFLF_INPUT](#) on page 303

[FFT_RFLF_INPUT](#) on page 353

[SCOPE_RFLF_INPUT](#) on page 358

[SETUP:INPUT](#) on page 234

5.3.2 Configuring the frequency range

Access VNC: [q]

The following settings configure the frequency range of the spectrum, that is: the x-axis.

Define the frequency range to be displayed using one of the following methods:

- **AF Center + AF Span:** the center frequency is displayed in the center of the x-axis, with half the span to either side
- **AF Start + AF Stop:** the x-axis starts with the start frequency and ends with the stop frequency

RF Freq	138
AF Center	138
AF Span	138
AF Start	139
AF Stop	139

RF Freq

Configures the nominal frequency of the RF input signal. The configured value is displayed as "RF Freq" in the measurement settings area.

Remote command:

[FFT_FREQRF](#) on page 351

AF Center

Configures the center frequency for the demodulated AM signal components. The configured value is displayed as "AF Center" in the measurement settings area.

Remote command:

[FFT_FREQ_CENTER](#) on page 350

AF Span

Configures the frequency span, which must be at least 100 kHz. The configured value is displayed as "AF Span" in the measurement settings area.

Remote command:

[FFT_FREQ_SPAN](#) on page 350

AF Start

Configures the start frequency of the x-axis. The configured value is displayed as "AF Start" in the measurement settings area.

Remote command:

[FFT_FREQ_START](#) on page 350

AF Stop

Configures the stop frequency of the x-axis. The configured value is displayed as "AF Stop" in the measurement settings area.

Remote command:

[FFT_FREQSTOP](#) on page 350

5.3.3 Configuring the bandwidth

Access VNC: [e] > "F1"

RBW	139
IF BW	139
AF In BW	139
IF BW AM	140

RBW

Defines the resolution bandwidth (RBW) of the spectrum. The resolution bandwidth defines the minimum frequency separation at which the individual components of a spectrum can be distinguished. Small values result in high precision, as the distance between two distinguishable frequencies is small. Higher values decrease the precision, but increase measurement speed.

The RBW can be determined automatically by the R&S EVSF1000, or manually.

AUTO mode The RBW is determined automatically according to the sweep time and frequency range.

Manual mode Select a predefined fixed value manually.

Remote command:

[FFT_RESBW_AUTO](#) on page 352

[FFT_RESBW_FIX_KHZ](#) on page 352

IF BW

Defines the IF demodulation bandwidth for RX input in "AF Spectrum" mode.

Remote command:

[FFT_IF_BW_KHZ](#) on page 352

AF In BW

Access VNC: [e]

Bandwidth with which the LF input is measured.

Remote command:
[SCOPE_BB_AF_BW_KHZ](#) on page 356
[FFT_BB_AF_BW_KHZ](#) on page 349

IF BW AM

Defines the IF demodulation bandwidth for the AM component of LF input.
This function is only available for AM carrier input, which cannot be selected directly in "AF Spectrum" mode. However, it becomes available when you do one of the following:

- Switch to the AF spectrum from "ILS LOC" or "ILS GP" mode in low IF mode
- Switch to the AF spectrum from "VOR" mode for LF input, selecting the AM demodulated subcarrier (see ["Switching from numeric to graphical results"](#) on page 91).

Remote command:
[FFT_BB_IF_BW_KHZ](#) on page 349

5.3.4 Configuring the amplitude (Y-Axis) for RF input

Access VNC: [w]

The amplitude settings configure the y-axis of the spectrum. For the AF Spectrum, the modulation depth of the AM signal components is displayed on the y-axis.
The following settings are available for RF input.

Y-Range	140
RF Att	140
RF Mode	141

Y-Range

Determines the displayed modulation depth range on the y-axis of the spectrum.
Remote command:
[FFT_GRID_YRANGE_DB](#) on page 351

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual" The RF attenuation mode is specified manually (see ["RF Mode"](#) on page 69).

"Auto" The RF attenuation mode is selected automatically.
The signal attenuation is selected automatically according to the signal strength.
This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable.
When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise" 15 dB pre-amplification
Provides a high sensitivity. Suitable when scanning the area for distant signals.

"Norm" 0 dB
Provides a normal sensitivity.

"Low Dist" 15 dB attenuation
Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

5.3.5 Configuring the amplitude (Y-Axis) for LF input

Access VNC: [w]

The amplitude settings configure the y-axis of the spectrum. The following settings are available for LF input.

Grid Y Max	142
Y Range	142
Grid Unit	142
Range	142
Coupling	142
DC Reference	142
LF In Factor	143

Grid Y Max

Defines the maximum displayed value of the y-axis.

Y Range

Determines the displayed modulation depth range on the y-axis of the spectrum.

Remote command:

[FFT_GRID_YRANGE_V](#) on page 351

Grid Unit

Access VNC: [s]

Switches the unit of the y-axis between V and % for LF input (see [Chapter 5.4.1, "Configuring the input signal"](#), on page 146).

Range

Access VNC: [w]

Defines the full-scale AF signal level. Define the correct level to avoid clipping and overload.

Switches the range between 1 V and 5 V.

Remote command:

[SETUP:BB_IN_RANGE](#) on page 236

Coupling

Access VNC: [w]

Specifies the handling of the DC component of the AF signal.

For low IF signals, AC coupling is always used.

"AC" The DC component of the AF signal is not forwarded.

"DC" The DC component of the AF signal is also forwarded and analyzed.

Remote command:

[SETUP:BB_IN_COUPL](#) on page 236

DC Reference

Access VNC: [w]

Defines the reference power in volt for LF input, available for AF signals with AC coupling only. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

For AC coupling, the DC power component of the AF signal is not forwarded. Thus, you must define the reference value manually.

Remote command:

[LLZ_BB_LFIN_DCOFFSETV](#) on page 263

[GS_BB_LFIN_DCOFFSETV](#) on page 273

[VOR_BB_LFIN_DCOFFSETV](#) on page 300

[FFT_BB_LFIN_DCOFFSETV](#) on page 349

[SCOPE_BB_LFIN_DCOFFSETV](#) on page 356

LF In Factor**Access VNC:** [w]

Applies a factor to the measured power levels, e.g. to compensate certain effects in the input system.

Remote command:

[SETUP:BB_IN_FACTOR](#) on page 236

5.3.6 Configuring the trace**Access VNC:** [a]

Trace settings determine how the display values are calculated from the measured values.

[Trace mode](#)..... 143

[Average Count](#)..... 143

Trace mode

Defines the update mode for subsequent traces.

- | | |
|---------------|--|
| "Clear/Write" | Overwrite mode (default): the trace is overwritten by each sweep |
| "Average" | The average is determined over several sweeps
The Average Count determines the number of averaging procedures. |
| "Max Hold" | The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one.
The Average Count determines the number of sweeps to evaluate. |
| "RMS" | The RMS value for each trace point over several sweeps is determined and displayed.
The Average Count determines the number of sweeps to evaluate. |

Remote command:

[FFT_TRACEMODE](#) on page 353

[IFSPECT_TRACE_MODE](#) on page 346

[FSCAN_TRACE_MODE](#) on page 341

Average Count

Determines the number of sweeps over which trace evaluation is performed (e.g. averaging or maxhold).

Remote command:

[FFT_TRACE_AVRGCOUNT](#) on page 354

[IFSPECT_TRACE_AVRGCOUNT](#) on page 346

[FSCAN_TRACE_AVRGCOUNT](#) on page 342

5.4 R&S EVSG-K12 Time domain analysis

Access VNC: [m] > Down arrow key

The AF Time Domain mode displays the modulation vs. time diagram of the demodulated RF signal, similar to an oscilloscope.

This mode requires the R&S EVSG-K12 Time domain analysis option.

The x-axis displays the measurement time. The y-axis displays the modulation depth in percent.

Marker functions allow you to analyze specific details in the spectrum.




Figure 5-5: AF Time Domain Mode of an ILS signal with DDM = 0,0 %



Generally, each mode is configured individually. When you switch modes, the most recently defined settings for that mode are applied.

However, graphical results can also be displayed directly from the measurement modes with numeric results. In this case, the settings for the current mode are applied to the graphical results.

If the original measurement mode analyzes multiple carriers, you must select the carrier for which you want to see the graphical results when you switch the mode.

The following settings are displayed in the measurement settings area of the RF spectrum:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode

The currently active measurement mode on the active receiver board, e.g. "AF Spectrum". See [Chapter 3.3, "Measurement mode"](#), on page 41.

- "RF Freq"
Nominal measurement frequency of the RF signal, see ["RF Freq"](#) on page 138.
- "RF Lev"
The measured level of the RF signal
- RF attenuation ("Att")
The used attenuation mode; see also ["RF Mode"](#) on page 69.
- Y-axis scaling ("Y % / Div")
Range per y-axis division. See ["Y % /Div"](#) on page 147.
- X-axis scaling ("Time / Div")
Time per x-axis division. See ["Time/Div"](#) on page 150.

AF Time Domain for LF input

Using option R&S EVSG1-K7 LF-Analysis, you can also analyze LF input (AF signals only) in the AF Time Domain mode. In this case, the power vs. time diagram is displayed.




Figure 5-6: AF Time Domain Mode of an ILS signal from LF input

For LF input, the following settings are displayed:

- RX board ("RX1" | "RX2")
The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.
- Measurement mode

The currently active measurement mode on the active receiver board, e.g. "AF Time Domain". See [Chapter 3.3, "Measurement mode"](#), on page 41.

- LF Input type ("LF In")
Only AF signals can be analyzed as LF input in AF Time Domain mode. See ["Input RF/LF"](#) on page 63.
- ("Range")
Sensitivity of the measurement. See ["Range"](#) on page 72.
- Measurement Bandwidth ("AF In BW")
Measurement bandwidth for LF input. See ["AF In BW"](#) on page 139.
- Y-axis scaling ("Y % / Div")
Range per y-axis division. See [Chapter 5.4.4, "Configuring the amplitude \(Y-Axis\) for LF input"](#), on page 148.
- X-axis scaling ("Time / Div")
Time per x-axis division. See ["Time/Div"](#) on page 150.

Remote command to select AF time domain mode:

[MODE_SCOPE](#) on page 355

Remote command to retrieve trace results:

[SCOPE_GETMEAS](#) on page 360

5.4.1 Configuring the input signal

The AF Time Domain mode can display graphical results for RF or LF input.

Input RF/LF

Access VNC: [s]

Configures the input source for the receiver.

For details on the connectors see [Chapter 1.5.2.2, "RX1 in / RX2 in"](#), on page 23.

- | | |
|---------|--|
| "RF In" | An RF signal is provided from the RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000. They are connected to a receiving antenna (max. +13 dBm). The antenna must correspond to the specified frequency range for the measurement. |
| "LF In" | <p>An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.</p> <p>If both receivers are used, only one of them can be set to analyze input from "LF In".</p> <p>The LF In connector is only available if R&S EVSF1-B4 is installed.</p> <p>Analyzing LF input requires option R&S EVSG1-K7 LF-Analysis.</p> |

Remote command:

[GS_RFLF_INPUT](#) on page 278

[LLZ_RFLF_INPUT](#) on page 268

[VOR_RFLF_INPUT](#) on page 303

[FFT_RFLF_INPUT](#) on page 353

[SCOPE_RFLF_INPUT](#) on page 358

[SETUP:INPUT](#) on page 234

5.4.2 Configuring the frequency range and bandwidth

The following settings configure the measured RF frequency or bandwidth of the time domain measurement.

RF Freq	147
IF BW	147
AF In BW	147

RF Freq

Access VNC: [q]

Configures the nominal frequency of the RF input signal. The configured value is displayed as "RF Freq" in the measurement settings area.

Remote command:

[SCOPE_FREQRF](#) on page 357

IF BW

Defines the bandwidth with which the RX input is measured.

Remote command:

[SCOPE_IF_BW_KHZ](#) on page 357

LF input:

[SCOPE_BB_IF_BW_KHZ](#) on page 356

AF In BW

Access VNC: [e]

Bandwidth with which the LF input is measured.

Remote command:

[SCOPE_BB_AF_BW_KHZ](#) on page 356

[FFT_BB_AF_BW_KHZ](#) on page 349

5.4.3 Configuring the amplitude (Y-Axis) for RF input

Access VNC: [w]

The amplitude settings configure the y-axis of the spectrum. The following settings are available for RF input.

Y % /Div	147
RF Att	148
RF Mode	148

Y % /Div

Defines the value range displayed in each division of the y-axis. The full y-axis range is eight times this value.

RF Att

Determines how the attenuation of the RF signal is defined. Adjust the attenuation such that the measured power level remains in the valid level range (indicated by the green area of the bargraph, see [Figure 4-4](#)). Note that the valid level range depends on the selected measurement mode.

"Manual"	The RF attenuation mode is specified manually (see "RF Mode" on page 69).
"Auto"	The RF attenuation mode is selected automatically. The signal attenuation is selected automatically according to the signal strength. This mode works best with clean signals. In difficult receiving conditions, the "Low Noise", "Normal" or "Low Distortion" modes can be more stable. When monitoring signals with mostly constant signal levels, it is also recommended that you use the "Low Noise", "Normal" or "Low Distortion" mode.

Remote command:

[SETATTMODE](#) on page 232

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[SETATTMODE](#) on page 232

[FSCAN_ATTMODE](#) on page 339

[SCOPE_ATTMODE](#) on page 355

[FFT_ATTMODE](#) on page 348

[IFSPECT_ATTMODE](#) on page 344

[GBAS:ATTMODE](#) on page 321

5.4.4 Configuring the amplitude (Y-Axis) for LF input**Access VNC:** [w]

The amplitude settings configure the y-axis of the spectrum. The following settings are available for LF input.

Grid Y Max.....	149
Y % /Div.....	149
Grid Unit.....	149
Range.....	149
Coupling.....	149
DC Reference.....	149
LF In Factor.....	150

Grid Y Max

Defines the maximum value of the y-axis.

Y % /Div

Defines the value range displayed in each division of the y-axis. The full y-axis range is eight times this value.

Grid Unit

Access VNC: [s]

Switches the unit of the y-axis between V and % for LF input (see [Chapter 5.4.1, "Configuring the input signal"](#), on page 146).

Range

Access VNC: [w]

Defines the full-scale AF signal level. Define the correct level to avoid clipping and overload.

Switches the range between 1 V and 5 V.

Remote command:

[SETUP:BB_IN_RANGE](#) on page 236

Coupling

Access VNC: [w]

Specifies the handling of the DC component of the AF signal.

For low IF signals, AC coupling is always used.

"AC" The DC component of the AF signal is not forwarded.

"DC" The DC component of the AF signal is also forwarded and analyzed.

Remote command:

[SETUP:BB_IN_COUPL](#) on page 236

DC Reference

Access VNC: [w]

Defines the reference power in volt for LF input, available for AF signals with AC coupling only. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

For AC coupling, the DC power component of the AF signal is not forwarded. Thus, you must define the reference value manually.

Remote command:

[LLZ_BB_LFIN_DCOFFSETV](#) on page 263

[GS_BB_LFIN_DCOFFSETV](#) on page 273

[VOR_BB_LFIN_DCOFFSETV](#) on page 300

[FFT_BB_LFIN_DCOFFSETV](#) on page 349

[SCOPE_BB_LFIN_DCOFFSETV](#) on page 356

LF In Factor
Access VNC: [w]

Applies a factor to the measured power levels, e.g. to compensate certain effects in the input system.

Remote command:

[SETUP:BB_IN_FACTOR](#) on page 236

5.4.5 Configuring the measurement time

Access VNC: [d] > "F1"

Time/Div
 Defines the time range displayed in each division of the x-axis. The full x-axis range, that is: the total measurement time, is eight times this value.

Remote command:

[SCOPE_TIMEDIV_RF](#) on page 358

5.4.6 Configuring the trigger

Access VNC: [k]

The trigger determines how often and when a new measurement is performed.



Performing a single sweep
 To perform a single sweep, press [Single] (VNC: [L]).

Trigger mode	150
Trigger Source	151
Trigger Edge	151
Trigger Level	151

Trigger mode
 Determines how the trigger is evaluated.

"Norm"	Each time a trigger event occurs, a measurement is performed.
"Auto"	Each time a trigger event occurs, a measurement is performed. If no trigger event occurs during a predefined waiting period, a measurement is performed without a trigger. This setting helps you determine the required trigger level.

"Single" When the trigger event occurs, a single measurement is performed.

Trigger Source

Determines how often and when a new sweep is performed.

"Ext." A measurement is performed each time a trigger signal from a connected external trigger device is received. The trigger device must be connected to the "Trigger In" connector on the rear panel of the R&S EVSF1000.

"Level" A measurement is performed when the input signal reaches the defined trigger level.

Trigger Edge

For external triggering, this setting defines whether a measurement is performed when the positive (rising) or negative (falling) edge of the trigger signal is received. Select the key repeatedly to toggle between the two settings.

Remote command:

[SCOPE_TRIGSLOPE](#) on page 359

Trigger Level

For the [Trigger Source](#) = "Level", this value specifies the level in percent the input signal must reach to trigger a measurement.

Remote command:

[SCOPE_TRIGLEVEL_RFPCT](#) on page 359

5.4.7 Configuring the trace

Access VNC: [a]

Trace settings determine how the display values are calculated from the measured values.

Trace mode	151
Average Count	152

Trace mode

Defines the update mode for subsequent traces.

"Clear/Write" Overwrite mode (default): the trace is overwritten by each sweep

"Average" The average is determined over several sweeps
The [Average Count](#) determines the number of averaging procedures.

"Max Hold" The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one.
The [Average Count](#) determines the number of sweeps to evaluate.

"RMS" The RMS value for each trace point over several sweeps is determined and displayed.
The [Average Count](#) determines the number of sweeps to evaluate.

Remote command:

[FFT_TRACEMODE](#) on page 353

[IFSPECT_TRACE_MODE](#) on page 346

[FSCAN_TRACE_MODE](#) on page 341

Average Count

Determines the number of sweeps over which trace evaluation is performed (e.g. averaging or maxhold).

Remote command:

[FFT_TRACE_AVRGCOUNT](#) on page 354


[IFSPECT_TRACE_AVRGCOUNT](#) on page 346

[FSCAN_TRACE_AVRGCOUNT](#) on page 342

5.5 Using markers in the graphical displays

Marker functions allow you to analyze specific details in the spectrum or time domain diagrams.

Active markers are displayed as colored triangles in the spectrum at the position they were placed. The exact position (frequency or time) and measured level at that position is indicated in the marker box in the upper right-hand corner of the diagram. Active markers are indicated by a highlighted softkey.



Up to four markers can be active at the same time. Markers 2 to 4 can be either normal markers or delta markers. A normal marker indicates the absolute signal value at the

defined position in the diagram. A delta marker indicates the value of the marker relative to marker 1.

Activating/Deactivating a marker.....	153
↳ Marker type (Type Mrk <2-4>).....	153
Deactivating all markers.....	153
Moving a marker to a peak in the diagram.....	153
Adapting the center frequency to the current marker position.....	153
Relative Unit (for AF spectrum only).....	153

Activating/Deactivating a marker

Access VNC: [i] > "F1"- "F4"

To activate a marker, select the corresponding softkey. An active marker is highlighted.

To select a marker that is already active, for example to move its position (see ["Moving a marker to a peak in the diagram"](#) on page 153), select the softkey again. A selected (editable) marker is highlighted orange.

To deactivate an active marker, select the marker until the highlighting is no longer displayed.

Marker type (Type Mrk <2-4>) ← Activating/Deactivating a marker

Determines the type of marker results.

"Normal"	A normal marker indicates the absolute value at the defined position in the diagram.
"Delta"	A delta marker defines the value of the marker relative to marker 1 (which is always of type "normal").

Deactivating all markers

Access VNC: [j] > "F1"

Deactivates all markers in the diagram.

Moving a marker to a peak in the diagram

Access VNC: [o] > "F1" / "F2"

Sets the currently active and selected marker (indicated in the softkey) to the highest or next-highest peak detected in the diagram. If no marker is active or selected, this function has no effect. To select a marker, see ["Activating/Deactivating a marker"](#) on page 153.

Adapting the center frequency to the current marker position

Access VNC: [o] > "F3"

Sets the center frequency of the spectrum to the position of the currently active and selected marker (indicated in the softkey). The spectrum is updated to the new frequency range. The span is maintained.

If no marker is active or selected, this function has no effect. To select a marker, see ["Activating/Deactivating a marker"](#) on page 153.

Relative Unit (for AF spectrum only)

Determines the unit for relative markers in the AF Spectrum diagram. Percentage and dB values are available.

6 GBAS/SCAT-I mode

Access VNC: [m] > Down arrow key

The R&S EVSG-K4 GBAS analysis/R&S EVSG-K5 SCAT-I Analysis options are firm-ware applications that add functionality to perform GBAS and SCAT-I analysis on the R&S EVSF1000.

The R&S EVSG-K4 GBAS analysis option enables you to receive and analyze the very high frequency (VHF) data broadcast (VDB) signal-in-space transmitted from a ground-based augmentation system (GBAS) ground subsystem to the airborne subsystem. This implementation is in line with the specification ICAO AN10 Vol1 [3] and RTCA DO-246 [1] (see [Chapter C, "References"](#), on page 381).

Similarly, using option R&S EVSG-K5 SCAT-I Analysis, data from special category I (SCAT-I) systems can be received and analyzed. The main difference is the content of the message data. This implementation is in line with the specification ICAO AN10 Vol1 [3] and RTCA DO-217 [2] (see [Chapter C, "References"](#), on page 381).

The R&S EVSG-K4 GBAS analysis/R&S EVSG-K5 SCAT-I Analysis applications feature:

- Receiving GBAS signal data from a GBAS ground station in a frequency range between 108.025 MHz and 117.950 MHz with a channel spacing of 25 kHz
- Receiving SCAT-I signal data from a SCAT-I ground station in a frequency range between 108.025 MHz and 117.950 MHz with a channel spacing of 25 kHz
- Analyzing the RF characteristics, signal strength and frequency accuracy of the GBAS/SCAT-I signal
- Demodulating, decoding and displaying GBAS/SCAT-I signal data
- Analyzing up to 8 time slots or individual time slot details in the GBAS/SCAT-I signal data
- Analyzing individual Final Approach Segment (FAS) data blocks
- Logging and storing up to 9999 lists of received GBAS/SCAT-I signal data



We strongly recommend that you provide a PPS signal for reference. Without PPS synchronization, signal timing and slot positions are possibly not correct.

For details, see [Chapter 6.1.4, "Time slot synchronization via PPS"](#), on page 158.

- [Basics on GBAS and SCAT-I analysis](#)..... 155
- [GBAS/SCAT-I status display](#)..... 159
- [GBAS / SCAT-I measurement information](#)..... 159
- [GBAS / SCAT-I measurement views and results](#)..... 161
- [GBAS/ SCAT-I measurement configuration](#)..... 174
- [Message XML interface](#)..... 178

6.1 Basics on GBAS and SCAT-I analysis

The following topics summarize some background information on the GBAS and other avionics-related standards. The provided overview information is intended as an explanation of the used terms and does not aim to be comprehensive.

- [GBAS specifics](#)..... 155
- [Broadcast timing structure](#)..... 157
- [Final approach segment \(FAS\) construction data](#)..... 157
- [Time slot synchronization via PPS](#)..... 158

6.1.1 GBAS specifics

GBAS is a ground-based augmentation system that can enhance satellite navigation. The GBAS is intended to improve aircraft safety and to enhance satellite navigation and the full range of precision approach and landing procedures, as well as the terminal area operations.

GBAS components

The illustration in [Figure 6-1](#) is a simplified representation of the GBAS' three main components:

- The GNSS satellite subsystem
- The airborne subsystem
- The GBAS ground subsystem.

The ground equipment consists of four reference GNSS receivers at exactly defined positions around the airport, GBAS ground station, and a VHF data broadcast transmitter (VDB).




Figure 6-1: GBAS components and signals (simplified representation)

- 1 = GNSS reference receiver
- 2 = GBAS ground station
- 3 = VHF data broadcast (VDB) transmitter
- a = GNSS navigation message
- b = Pseudorange
- c = GBAS Correction message
- d = VDB signal

The GBAS GNSS reference receivers receive the *GNSS navigation message*, perform pseudorange measurements and transmit this information to the GBAS ground station. The GBAS ground station determines errors in the calculated positions, adds additional parameters and approach path information, produces a *GBAS correction message* and sends it the VDB transmitter. The VDB transmitter modulates and encodes this message and *broadcasts* it to the airborne GBAS equipment, for example a GBAS receiver in the airplane. The GBAS equipment in the airplane is a high-precision multimode receiver that evaluates the message and applies correction parameters to improve the navigation algorithms from GPS.

This list outlines the three signals transmitted between the components and referred to as GBAS Signal-in-Space:

- GNSS satellite to GBAS ground subsystem navigation signal
- GNSS satellite to GBAS airborne subsystem navigation signal
- GBAS ground subsystem to GBAS airborne subsystem VHF data broadcast

Carrier frequencies and frequency channels

The VHF data broadcast is defined for carrier frequencies within the range of 108.025 MHz to 117.950 MHz and carrier spacing of 25.0 kHz.

6.1.2 Broadcast timing structure

The broadcast is a Time Division Multiple Access (TDMA). According to [1], the TDMA timing structure uses a two level hierarchy, composed of 500 ms long frames, each divided into 8 VDB time slots (A - H), see [Figure 6-2](#).




Figure 6-2: TDMA timing structure (simplified representation)

A VDB time slot is the minimum resource that an individual VDB transmitter can use. During one time slot, a VDB transmitter transmits exactly one burst.

The GBAS specification [1] defines the TDMA timing structure, including timing budget of the VDB bursts, burst data contents and message encoding in great details. The R&S EVSF1000 receives the required training sequence, decodes the message according to [1] and demodulates the D8PSK modulated data automatically.

6.1.3 Final approach segment (FAS) construction data

According to the standard [1], the message type 4 contains one or more data sets that contain approach data, associated vertical/lateral alert limits, and/or the Terminal Area Path (TAP).

The FAS path is a line in space that defines the path an airplane follows on its final approach. This line is defined by the Landing Threshold Point/Fictitious Threshold Point (LTP/FTP), Flight Path Alignment Point (FPAP), Threshold Crossing Height (TCH), and the Glide Path Angle (GPA).




Figure 6-3: Final Approach Segment (FAS) diagram, according to [1]

LTP/FTP = Landing Threshold Point/Fictitious Threshold Point; point at the center of the landing runway, defined by its WGS84 coordinates

GPIP = Glide Path Intercept Point; the point where the final approach path intercepts the local level plane

FPAP = Flight Path Alignment Point; point at the end of the runway that in conjunction with the LTP/FTP defines the geodesic plane of the precision final approach, landing and flight path.

TCH = Threshold Crossing Height

GPA = Glide Path Angle; angle at the TCH that describes the intended angle of descent at the final approach path.

The coordinates of the LTP/FTP are defined in WGS84 coordinates. In this coordinate system, a location is identified by three coordinates, the altitude, the latitude and the longitude.

6.1.4 Time slot synchronization via PPS


The GBAS/SCAT-I signal is synchronous to the PPS signal of the GNSS system. With the help of this synchronization, the GBAS/SCAT-I signal is assigned to eight time slots (twice a second).

If the R&S EVSF1000 finds a valid PPS signal at its selected trigger connector, the status line of the display indicates "PPS Locked". In this case, the R&S EVSF1000 can analyze the GBAS/SCAT-I signal and detect the individual GBAS time slots.

If no valid PPS signal is detected, the R&S EVSF1000 still analyzes the GBAS/SCAT-I signal and tries to synchronize to the GBAS/SCAT-I burst raster. In this case, the status line of the display indicates "Burst Locked". Without PPS synchronization, signal timing and slot positions are possibly not correct.

6.2 GBAS/SCAT-I status display

The basic measurement information is displayed in the mini display directly on the R&S EVSF1000 (see also [Chapter 1.6.1, "Basic configuration and status display"](#), on page 27).



For GBAS/SCAT-I mode, the following measurement information is displayed:

- **"F"**: The channel frequency that determines the carrier frequency at which the measurement is performed. See ["Frequency \(Freq\)"](#) on page 160.
- **"Tref"**: Time reference; indicates the status of the PPS signal from an external GNSS device (see ["Time reference status \(Time Ref.\)"](#) on page 161)
 - **"PPS"**:
A GNSS receiver or a valid signal is available at the PPS-In, Trigger-In, or RS232-GPS connector.
 - **"Unlk"**:
No valid signal available at the PPS-In or Trigger-In connector. GBAS/SCAT-I signals cannot be detected correctly.
- 

The burst status is indicated by the color of the slot cell (see also ["Status"](#) on page 163):

- **Green**: The status is "OK". The received burst passed the cyclic redundancy check (CRC).
- **Red**: An error occurred. The received burst did not pass the cyclic redundancy check (CRC).
- **Gray**: No burst received.
- **"L[dBm]min"** : Minimum burst level average in the current frame (see ["Burst Level Average \(Av \[dBm\]\)"](#) on page 163)
- **"L[dBm]max"** : Maximum burst level average in the current frame (see ["Burst Level Average \(Av \[dBm\]\)"](#) on page 163)

6.3 GBAS / SCAT-I measurement information

The following measurement information is displayed in all GBAS / SCAT-I views.

RX1 GBAS	Frame T	Slot E	Freq	116.42500 MHz
Att	MAN:Low Noise+			
Lev Corr	0.0 dB	IF BW	16.8 kHz	Time Ref. PPS Locked
				Mode Run

RX board (RX1 RX2).....	160
Measurement mode.....	160
Frame.....	160
Slot.....	160
Frequency (Freq).....	160
RF attenuation (Att).....	160
Level correction (Lev Corr).....	160
Bandwidth (IF BW).....	160
Time reference status (Time Ref.).....	161
Display Update Status (Mode).....	161

RX board (RX1 | RX2)

The currently active receiver board. See [Chapter 3.2, "Receiver board"](#), on page 40.

Measurement mode

The currently active measurement mode on the active receiver board; in this case: "GBAS" (for both GBAS and SCAT-I modes). See [Chapter 3.3, "Measurement mode"](#), on page 41.

Frame

The currently selected frame for which the results are displayed. The most recent frame is referred to as T, previous frames are T minus 1 (T-1), T-2, to T-39.

Slot

The currently selected slot for which the results are displayed. The slots are labeled A, B, C, D, E, F, G, H.

Frequency (Freq)

The channel frequency that determines the carrier frequency at which the measurement is performed.

The VHF data broadcast is defined for carrier frequencies within the range of 108.025 MHz to 117.950 MHz with a channel spacing of 25 kHz.

Remote command:

[GBAS : FREQRF](#) on page 323

RF attenuation (Att)

The used attenuation mode; see also ["RF Mode"](#) on page 176.

Level correction (Lev Corr)

The applied level correction by a transducer. See ["Transducer Correction"](#) on page 69.

Bandwidth (IF BW)

Bandwidth on which the measurement is performed. The default bandwidth is 16.8 kHz. For GBAS/SCAT-I measurements, the complete bandwidth is 25 kHz.

See also ["IF Filter"](#) on page 176.

Time reference status (Time Ref.)

Indicates the status of the PPS signal from an external GNSS device.

"PPS Locked"	A GNSS receiver or a valid signal is available at the PPS-In, Trigger-In, or RS232-GPS connector.
"Burst Locked"	No valid PPS signal available at any input connector, but a valid GBAS/SCAT-I burst raster was found. Signal timing and slot positions are possibly not correct.
"Unlocked"	No valid signal available at any input connector, and no valid GBAS/SCAT-I burst raster was found. GBAS/SCAT-I signals cannot be detected correctly.

Remote command:

[GBAS:PPSLOCKED?](#) on page 330

Display Update Status (Mode)

Indicates whether the display is updated or not.

Note: Data recording and streaming continue regardless of the display update status.

"Run"	Display is updated continuously.
"Pause"	Display is temporarily not updated.

Remote command:

[GBAS:BUFFER_RUNPAUSE](#) on page 322

6.4 GBAS / SCAT-I measurement views and results

The GBAS/SCAT-I measurement provides both numerical and graphical results in various views.

Remote command:

[GBAS:SCREENVIEW](#) on page 324

• Sequence view	161
• Frame view	163
• Burst view	167
• Constellation view	170
• Message view	171
• Recording view	172

6.4.1 Sequence view

Access: [Meas] > "View" > "Sequence"

The "Sequence" view is the default view in GBAS/SCAT-I mode and provides an overview of the GBAS/SCAT-I transmissions over time. Each frame contains 8 TDMA slots (see also [Chapter 6.1.2, "Broadcast timing structure"](#), on page 157). Six sequential

frames are displayed at a time, in a table with one column for each slot and one row per frame. You can scroll through all available frames using the rotary knob or the [Frame](#) and [Slot](#) functions.

In the "Sequence" view, the data from the last 40 frames is available. The data is stored in a so-called *ring buffer*. When the ring buffer is full, the next data set overwrites the first data set, that is: the oldest. Thus, the most recent 40 data sets are available. The most recently received frame is referred to as T. Each previous frame is referred to as T minus 1 (T-1), T-2 etc. Every 500 ms, a new frame is inserted, overwriting the frame T-39, and becomes the new frame T. Thus, the display is updated every 500 ms. To freeze the current display for evaluation, you can pause the table update (see ["Run/Pause"](#) on page 175). Data recording and streaming, however, continue as usual. When updating is resumed, all frames in the table are updated.

RX1 GBAS									Meas GBAS
Frame T				Slot E		Freq 116.42500 MHz			Run/Pause Pause
Att MAN:Low Noise+		Lev Corr 0.0 dB		IF BW 16.8 kHz		Time Ref. PPS Locked		Mode Pause	
T	-125.2 dBm	-125.0 dBm	-124.7 dBm	-124.7 dBm	EDDF -65.7 dBm MT: 1	-126.1 dBm	EDDF -65.3 dBm MT: 4	-126.9 dBm	
T-1	-125.7 dBm	-124.1 dBm	-123.4 dBm	-123.6 dBm	EDDF -65.4 dBm MT: 1	-125.2 dBm	EDDF -65.4 dBm MT: 4	-124.7 dBm	View Sequence
T-2	-125.3 dBm	-124.9 dBm	-125.4 dBm	-125.2 dBm	EDDF -65.4 dBm MT: 1	-126.2 dBm	EDDF -64.6 dBm MT: 4	-126.3 dBm	Frame 0
T-3	-124.9 dBm	-124.3 dBm	-124.8 dBm	-125.0 dBm	EDDF -65.4 dBm MT: 1	-124.5 dBm	EDDF -64.8 dBm MT: 2	-124.6 dBm	Slot E
T-4	-125.6 dBm	-123.3 dBm	-125.5 dBm	-125.4 dBm	EDDF -65.7 dBm MT: 1	-125.6 dBm	EDDF -65.3 dBm MT: 4	-124.7 dBm	
T-5	-125.6 dBm	-125.4 dBm	-125.5 dBm	-124.5 dBm	EDDF -65.4 dBm MT: 1	-124.3 dBm	EDDF -65.4 dBm MT: 4	-125.0 dBm	
	A	B	C	D	E	F	G	H	
DLLIST: 1 SIZE: 158 local  Full									



Results for a single frame or slot

The currently selected frame and slot are indicated by a dotted rectangle in the table. To view the details for a particular frame or slot, turn the rotary knob to scroll through the slots and frames. When the required slot or frame is selected, select the view you want to see the slot results in.

For more details, see:

- [Chapter 6.4.2, "Frame view"](#), on page 163
- [Chapter 6.4.3, "Burst view"](#), on page 167
- [Chapter 6.4.4, "Constellation view"](#), on page 170
- [Chapter 6.4.5, "Message view"](#), on page 171

For each slot in each displayed frame, the following information is provided in the corresponding table cell (for a valid GBAS burst, if available).

EDDF
-65.4 dBm
MT: 1

GBAS ID.....	163
Burst Level Average (Av [dBm]).....	163
Application Data (App. Dat.).....	163
Status.....	163

GBAS ID

4-character identifier of the ground station broadcasting the message. If there is more than one message inside the burst, the first GBAS ID is displayed.

Remote command:

[GBAS:GBASID?](#) on page 326

Burst Level Average (Av [dBm])

Arithmetic average of the burst power level measured over the period of the synchronization and ambiguity resolution field of the burst.

If no burst was detected, the arithmetic average of the noise power is displayed.

Remote command:

[LA?](#) on page 323

Application Data (App. Dat.)

Detected message types (MT) in the burst

Example: "MT:1,2": messages of type 1 and 2 detected

Status

The burst status is indicated by the color of the slot cell:

Green	The status is "OK". The received burst passed the cyclic redundancy check (CRC).
Red	An error occurred. The received burst did not pass the cyclic redundancy check (CRC).
Gray	No burst received.

6.4.2 Frame view

Access: [Meas] > "View" > "Frame"

To use the available spectrum most efficiently, despite the low data rate, GBAS transmissions use the Time Division Multiple Access (TDMA) method (see also [Chapter 6.1.2, "Broadcast timing structure"](#), on page 157). Thus, multiple GBAS bursts, even from different transmitters, can be sent in a single frame. To do so, the transmitters must adhere to the time slots strictly. Nevertheless, time delays can occur during

transmission. The GBAS "Frame" view allows you to measure the time behavior of the slots precisely.

As opposed to the "Sequence" view, the "Frame" view displays the results of a single frame only. By default, the most recently measured frame T is displayed. To display the results for a different frame, use the [Frame](#) function.

The display is updated each time a complete frame has been measured, that is: every 500 ms. To freeze the current display for evaluation, you can pause the view update (see ["Run/Pause"](#) on page 175). Data recording and streaming, however, continue as usual. When updating is resumed, the displayed results in the view are updated.




The "Frame" view contains two different displays:

- [Chapter 6.4.2.1, "Frame power vs. time diagram"](#), on page 164
- [Chapter 6.4.2.2, "Frame results table"](#), on page 165

6.4.2.1 Frame power vs. time diagram

The power vs. time diagram displays the measured power per time, normalized to the PPS signal. The fixed slot grid defined by the PPS (reference) signal is indicated by vertical lines in the diagram. In addition to the time in milliseconds, the slot label A to H is indicated on the x-axis. The time axis always starts at 0 seconds or 500 milliseconds.



The measured power is indicated for a range of -120 dBm to 0 dBm on the y-axis.

6.4.2.2 Frame results table

In the frame results table, the details for each slot in the selected frame are displayed, one slot per column. The currently selected slot is indicated by a dotted rectangle in the frame results table. If a slot timing error or a signal level error occurs, the slot is highlighted red.

	A	B	C	D	E	F	G	H
Train.FEC					OK		OK	
App.Dat.					MT: 1		MT: 4	
App.FEC					OK		OK	
S.Occu[%]	--	--	--	--	54.552	--	94.781	--
BER					0.0e+00		0.0e+00	
Valid B.					110		110	
Failed B.					0		0	
Sync.[μs]					576.0		576.0	
Overload								



To scroll through the parameters in the table for a single slot, use the arrow keys up and down.

Burst Level Average (Av [dBm]).....	166
Slot Level Peak (Pk [dBm]).....	166
Carrier frequency offset (Offs. [kHz]).....	166
EVM RMS.....	166
GBAS ID.....	166
Training Sequence FEC (Train. FEC).....	166
Application Data (App. Dat.).....	166
Application FEC (App. FEC).....	167
Slot Occupancy (S.Occu [%]).....	167
Bit error rate (BER) before FEC.....	167
Valid Bursts (Valid B.).....	167

Failed Bursts (Failed B.).....	167
Sync. Sequence (Sync. [us]).....	167
Overload.....	167

Burst Level Average (Av [dBm])

Arithmetic average of the burst power level measured over the period of the synchronization and ambiguity resolution field of the burst.

If no burst was detected, the arithmetic average of the noise power is displayed.

Remote command:

[LA?](#) on page 323

Slot Level Peak (Pk [dBm])

Highest measured power level in the slot in dBm

Remote command:

[GBAS : PEAKLEV?](#) on page 330

Carrier frequency offset (Offs. [kHz])

Offset of the measured carrier frequency from the nominal frequency

Remote command:

[GBAS : FMEAS?](#) on page 323

EVM RMS

Error vector magnitude RMS in percent.

Indicates the quality of the transmitted symbols in relation to the ideal constellation point. The EVM normalization reference is the mean constellation power.

Remote command:

[GBAS : EVM?](#) on page 325

For baseband input also:

[GBAS : EVM_ANGLE_NORM](#) on page 322

GBAS ID

4-character identifier of the ground station broadcasting the message. If there is more than one message inside the burst, the first GBAS ID is displayed.

Remote command:

[GBAS : GBASID?](#) on page 326

Training Sequence FEC (Train. FEC)

Training sequence status based on the FEC

"OK" Training sequence correct

"NOK" Training sequence not valid, no bits corrected

<x> Number of corrected bits in the training sequence

Application Data (App. Dat.)

Detected message types (MT) in the burst

Example: "MT:1,2": messages of type 1 and 2 detected

Application FEC (App. FEC)

Application data status based on the FEC

"OK"	Application data correct
"NOK"	Application data not valid, no bits corrected
<x>	Number of corrected bits in the application data

Slot Occupancy (S.Occu [%])

The percentage of the available bits in the slot that contain burst data, calculated as:

$$\text{<bits_burst> / 1968.75 bits * 100 \%}$$

Bit error rate (BER) before FEC

Bit error rate (BER) before forward error correction (FEC). The [Training Sequence FEC \(Train. FEC\)](#) and the [Application FEC \(App. FEC\)](#) are used to detect the bit errors.

Calculated as:

$$\text{<bits_ok> / <bits_error>}$$

To reset the BER value, use the [Reset BER](#) function.

Remote command:

[GBAS : GBASBER?](#) on page 326

Valid Bursts (Valid B.)

Number of received bursts that passed the cyclic redundancy check (CRC) and are thus considered valid.

To reset the value, use the [Reset BER](#) function.

Failed Bursts (Failed B.)

Number of received bursts that did not pass the cyclic redundancy check (CRC) and are thus considered invalid.

To reset the value, use the [Reset BER](#) function.

Sync. Sequence (Sync. [us])

Position of the synchronization sequence within the burst in μs .

Overload

Indicates a power overload at any of the input connectors, which can account for inaccurate results. If an overload occurs, an error message is also displayed in the measurement information in all GBAS / SCAT-I views.

"OK"	No overload
"RF Ovld"	Input signal too high
"IF Ovld"	IF signal too high
"ADC Ovld"	ADC input signal too high

6.4.3 Burst view

Access: [Meas] > "View" > "Burst view"

The "Burst" view is similar to the "Frame" view. However, the "Burst" view displays the results for an individual slot.




Figure 6-4: Example for a "Burst" view with a diagram and result table

By default, the first slot (A) from the most recently measured frame T is selected. To display the results for a different slot, use the [Frame](#) and [Slot](#) functions.

The display is updated each time a complete slot has been measured, that is: every 62.5 ms. To freeze the current display for evaluation, you can pause the view update (see ["Run/Pause"](#) on page 175). Data recording and streaming, however, continue as usual. When updating is resumed, the displayed results in the view are updated.

The "Burst" view contains two different displays:

- [Chapter 6.4.3.1, "Slot power vs. time diagram"](#), on page 168
- [Chapter 6.4.3.2, "Slot results table"](#), on page 169
- [Slot power vs. time diagram](#)..... 168
- [Slot results table](#)..... 169

6.4.3.1 Slot power vs. time diagram

A power vs. time diagram displays the measured power in the slot per time, normalized to the PPS signal. The x-axis shows the time in milliseconds. It always starts at 0 seconds or a multiple of 62.5 milliseconds. The default range is 62.5 milliseconds. If a TDMA timing error occurs, the GBAS/SCAT burst can exceed the displayed time range.

The measured power is indicated for a range of -120 dBm to 0 dBm on the y-axis.




Figure 6-5: Power vs. time diagram for a slot in Burst view

The following functions are available for the slot power vs. time diagram:

Zoom +/ Zoom -

Changes the time range displayed in the diagram to view more details in a slot ("Zoom +") or outside of the slot ("Zoom -").

Data points

Shows or hides dots in the diagram indicating the measured data points.




Figure 6-6: Power vs. time diagram with highlighted data points

6.4.3.2 Slot results table

In the slot results table, the slot details for the selected slot are displayed. The results are the same as those displayed in the [Frame results table](#).

Burst Level Avg.	-65.67 dBm	Train. FEC	OK	Valid Bursts	110
Slot Level Peak	-61.80 dBm	App. Data	MT: 1	Failed Bursts	0
C. Offset	-0.094 kHz	App. FEC	OK	Sync.Seq.Start	576.0 µs
EVM RMS	2.9 %	Slot Occupancy	54.552 %	Overload	
GBAS ID	EDDF	BER Before FEC	0.0e+00		




If no valid burst is detected in the slot, the slot results table shows only the measured noise level.

6.4.4 Constellation view

Access: [Meas] > "View" > "Constell. view"

The "Constellation" view consists of a constellation diagram and the measured values for the individual slot (see [Chapter 6.4.2.2, "Frame results table"](#), on page 165).



The constellation diagram shows the in-phase and quadrature components of the received D8PSK symbols in the slot. The in-phase components (I) are displayed on the x-axis, the quadrature (Q) components on the y-axis.

The eight ideal constellation points for D8PSK modulation are indicated by red dots.

The following functions are available for the constellation diagram:

Clear Inter.

Determines the interval after which the constellation diagram is cleared automatically.

"Off"	(Default:) All constellation points from all bursts are displayed in the same diagram, no automatic clearance.
"Burst"	After each burst, the diagram is cleared and a new constellation diagram is displayed.

Clear

Clears all points from previous bursts in the constellation diagram and starts a new diagram.

6.4.5 Message view

Access: [Meas] > "View" > "Message view"

The "Message" view shows the messages received during a single slot or burst. In addition to the message itself, the header and footer are analyzed. If the burst contains multiple messages, they are listed in the table one after the other.

The data is interpreted from the received burst bitstream according to rules and data definitions configured in XML files. You can configure the information provided in the "Message" view table using the message xml interface (see [Chapter 6.6, "Message XML interface"](#), on page 178).

For each type of data content, a separate row is displayed with the following information:

- "Data content": textual description of the type of information
- "Bits": number of bits from the burst bitstream that were evaluated to obtain the information
- "Value": result of the interpreted bits
- "Binary representation": the raw data in the evaluated bits

RX1 GBAS				Frame T	Slot E	Freq	116.42500 MHz	Meas Msg
Att MAN:Low Noise+								Run/Pause
Lev Corr 0.0 dB				IF BW 16.8 kHz	Time Ref. PPS Locked	Mode	Pause	Pause
Data content	Bits	Value	Binary representation					
Station Slot Identifier	3	E	100					
Transmission Length	17	976	00000001111010000					
Training Sequence FEC	5	OK	01110					
Message Block	0							
Message Block Identifier	8	normal	10101010					
GBAS ID	24	EDDF	000101000100000100000110					
Message Type Identifier	8	MsgType1	00000001					
Message Length	8	928	01110100					
Message	0	MTI:1						
Modified Z-count [s]	14	213.5	00100001010111					
Additional Message Flag	2	all	00					
Number of Measurements	5	9	01001					
Measurement Type	3	C/A_L1	000					
Ephemeris Decorrelation Parameter...	8	0.000180	00100100					
Ephemeris CRC MSB	8	121	01111001					
Ephemeris CRC LSB	8	115	01110011					
DL-LIST: 1				SIZE: 158	local	Full		



Use the arrow keys and the rotary knob to scroll through the table.

6.4.6 Recording view

Access: [Meas] > "View" > "Rec."

The Recording view displays the recorded data for GBAS/SCAT-I measurements from the selected data list (see "[List](#)" on page 202). If available, the stored GNSS data from the GNSS receiver is also displayed.

RX1 GBAS DL-List 1 Line 11 Freq 116.42500 MHz										Meas REC
Att MAN:Low Noise+										DL Line 11
Lev Corr 0.0 dB IF BW 16.8 kHz Time Ref. PPS Locked Mode Pause										View Rec
RX	STIOCP	Index	Date	Time	Slot	FREQ[MHz]	Lev.Av[dBm]	Lev.Pk[dBm]	C.Offse	-> Rec Burst View -> Rec Const. View -> Rec Msg. View
1	S	1	04.12.2018	13:35:24.760	C	116.42500	-124.98	-114.89	---	
1		2	04.12.2018	13:35:24.823	D	116.42500	-124.92	-115.20	---	
1		3	04.12.2018	13:35:24.885	E	116.42500	-65.67	-61.80	-0.094	
1		4	04.12.2018	13:35:24.948	F	116.42500	-125.27	-115.08	---	
1		5	04.12.2018	13:35:25.010	G	116.42500	-65.32	-61.88	-0.093	
1		6	04.12.2018	13:35:25.073	H	116.42500	-125.64	-115.38	---	
1		7	04.12.2018	13:35:25.135	A	116.42500	-124.59	-114.70	---	
1		8	04.12.2018	13:35:25.198	B	116.42500	-125.03	-114.58	---	
1		9	04.12.2018	13:35:25.260	C	116.42500	-124.56	-114.44	---	
1		10	04.12.2018	13:35:25.323	D	116.42500	-124.78	-115.13	---	
1		11	04.12.2018	13:35:25.385	E	116.42500	-65.41	-61.87	-0.092	
1		12	04.12.2018	13:35:25.448	F	116.42500	-124.02	-114.61	---	
1		13	04.12.2018	13:35:25.510	G	116.42500	-64.84	-61.73	-0.096	
1		14	04.12.2018	13:35:25.573	H	116.42500	-123.81	-115.05	---	
1		15	04.12.2018	13:35:25.635	A	116.42500	-123.77	-114.57	---	
1		16	04.12.2018	13:35:25.698	B	116.42500	-124.90	-114.26	---	
1		17	04.12.2018	13:35:25.760	C	116.42500	-125.19	-115.49	---	
DL-LIST: 1 SIZE: 158 local Full										

The individual measurement results are described in [Chapter 6.4.2.2, "Frame results table"](#), on page 165.



Recording GBAS/SCAT-I measurement results

When recording data in GBAS/SCAT-I mode, one record is stored for each slot, with a duration of 62.5 ms. The record contains measurement values and message data. Recording is continued even if the display update is temporarily stopped (by the "Pause" function, see ["Run/Pause"](#) on page 175). Start and stop recording from any measurement view using the [Record] key. Record only the selected and currently displayed slot or frame using the [Single] key.

You can define which data is stored; see [Chapter 7.2.3, "Recording settings"](#), on page 202.

For details on data logging, see [Chapter 7.2, "Recording measurement data"](#), on page 200.



Status flags

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)

The following functions are available to configure the "Recording" view.

DL Line	174
-> Rec. Burst View / -> Rec. Const. View / -> Rec. Msg. View	174

DL Line

Selects a particular line (record) in the data recording file.

-> Rec. Burst View / -> Rec. Const. View / -> Rec. Msg. View

Displays the selected data record in detail in the selected view. Message view is only available if message data was stored in the data record.

To return to the "Recording" view, select "-> Return".

6.5 GBAS/ SCAT-I measurement configuration

The following settings are available for GBAS/ SCAT-I measurements.



Settings for recording are described in [Chapter 7.2, "Recording measurement data"](#), on page 200.

• View configuration	174
• Frequency configuration	175
• Amplitude configuration	175
• Bandwidth configuration	176
• General configuration	176

6.5.1 View configuration

The following functions are available to configure the GBAS/ SCAT-I views except for the "Recording" view.

Access VNC: [A]

Run/Pause.....	175
View.....	175
Frame.....	175
Slot.....	175

Run/Pause

Stops and resumes the display update. Data recording and streaming continue as usual. When updating is resumed, the display reflects the latest results again.

View

Switches between

- [Sequence view](#)
- [Frame view](#)
- [Burst view](#)
- [Constellation view](#)
- [Message view](#)
- [Recording view](#)

Frame

Selects the frame to be displayed in the power vs. time diagram and at the top of the results table. By changing the frame number, for example using the rotary knob, you can scroll through the frames in the table and through the most recent 40 frames in the diagram.

Slot

Selects the slot to be displayed in the power vs. time diagram and at the top of the results table. By changing the slot name, for example using the rotary knob, you can scroll through the slots in the table and in the diagram.

Remote command:

[GBAS : SEQN_SLOT](#) on page 324

6.5.2 Frequency configuration

Access VNC: [Q] > [F2]

Frequency (Freq)

The channel frequency that determines the carrier frequency at which the measurement is performed.

The VHF data broadcast is defined for carrier frequencies within the range of 108.025 MHz to 117.950 MHz with a channel spacing of 25 kHz.

Remote command:

[GBAS : FREQRF](#) on page 323

6.5.3 Amplitude configuration

Access VNC: [w]

The following settings define the amplification for the input signal.

RF Att

Determines whether the RF attenuation is defined automatically or manually.

"Manual"	Select the RF Mode manually. For signals with mostly constant signal levels, it is recommended that you select the optimal mode manually.
"Auto"	The optimal mode is selected automatically according to the input signal strength. In difficult receiving conditions, for example the presence of high-level interferers or areas with strong multi-path conditions, selecting the suitable attenuation mode manually can lead to more stable measurement results. If the R&S EVSF1000 has to adapt the attenuation frequently, indicated by a frequent clicking noise from the attenuator, spikes can occur in the trace.

Remote command:

GBAS:ATTMODE AUTO, see [GBAS:ATTMODE](#) on page 321

RF Mode

Defines the RF attenuation mode to be used.

"Low Noise"	15 dB pre-amplification Provides a high sensitivity. Suitable when scanning the area for distant signals.
"Norm"	0 dB Provides a normal sensitivity.
"Low Dist"	15 dB attenuation Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Remote command:

[GBAS:ATTMODE](#) on page 321

6.5.4 Bandwidth configuration

Access VNC: [e]

IF Filter

The IF filter determines the bandwidth on which the measurement is performed. The default filter bandwidth is 16.8 kHz. For GBAS/SCAT-I measurements, the complete channel bandwidth is 25 kHz.

6.5.5 General configuration

Access VNC: [S]

PPS SRC.....	177
Export xml.....	177
Import xml.....	177
DEC DEF.....	177
Reset BER.....	177
EVM Mode.....	177

PPS SRC

Source of the PPS signal required as a time reference

"PPS SMA"	Signal provided at the PPS In connector
"PPS GPS"	Signal provided at the RS232-GPS connector

Export xml

Exports the internal message type xml definition to a connected USB storage device (see [Chapter 6.6, "Message XML interface"](#), on page 178).

Exporting the xml definition is useful to create a customized definition without having to start from an empty file.

Import xml

Imports a customized message type xml definition from a connected USB storage device to the R&S EVSF1000 (see [Chapter 6.6, "Message XML interface"](#), on page 178).

Note that this definition is only used if you set [DEC DEF](#) to "Custom".

DEC DEF

Determines which message type xml definition that the decoder uses.

"Default"	Uses the definition stored internally on the R&S EVSF1000
"Custom"	Uses the imported definition (see "Import xml" on page 177).

Reset BER

Resets the values for the following measurement results:

- ["Bit error rate \(BER\) before FEC"](#) on page 167
- ["Valid Bursts \(Valid B.\)"](#) on page 167
- ["Failed Bursts \(Failed B.\)"](#) on page 167

Remote command:

[GBAS : RESETBER](#) on page 330

EVM Mode

Determines the mode of EVM calculation for baseband input in "GBAS" mode.

"ANGLE"	Only angle deviations are considered in EVM calculation.
"NORM"	Both angle and amplitude deviation are considered in EVM calculation.

Remote command:

[GBAS : EVM_ANGLE_NORM](#) on page 322

6.6 Message XML interface

The R&S EVSG-K4 GBAS analysis / R&S EVSG-K5 SCAT-I Analysis options receive and analyze VDB GBAS transmissions according to ICAO AN10 Vol1 [3] and RTCA DO-246 [1]. Analysis includes physical measurement values such as level, frequency or EVM. The results can be displayed or recorded. A bitstream is also provided with each transmission (*burst*). The bitstream contains the digital information required by a GNSS receiver for its calculations. To display this information in human-readable format, the bitstream needs to be interpreted as described in the document.

The R&S EVSG-K4 GBAS analysis / R&S EVSG-K5 SCAT-I Analysis options provide a special parser that transforms the data efficiently, controlled by a set of XML files. The XML files contain the rules and data definitions for conversion and are loaded during runtime. The converted, human-readable data is then displayed in the "Message" view (see [Chapter 6.4.5, "Message view"](#), on page 171).

You can edit the XML control files with any text editor to obtain specific outputs, for example, or to accommodate the output to changes in the specifications. However, a good knowledge of the ICAO AN10 Vol1 [3] and RTCA DO-217 [2] specifications is essential to understand the transformation process.

The R&S EVSF1000 provides a default set of XML files for an initial message type definition. These files are stored internally on the instrument. You can export the files to a USB storage device and import the customized files back to the R&S EVSF1000 (see ["Import xml"](#) on page 177).

To customize the "Message" view results

1. Connect a USB storage device to the R&S EVSF1000.
2. Select [Config] > "Export xml".
The required file structure and files are stored on the storage device.
3. Edit the files as required. See the descriptions below for more information.
4. Select [Config] > "Import xml".

The edited files are stored on the R&S EVSF1000.

5. Select [Config] > "DEC DEF" > "Custom".

The R&S EVSF1000 decoder uses the edited, imported message definition and displays the defined results in the "Message" view.

• General processing	179
• Output elements and control elements	180
• XML file format description	183
• Format description of elements	185
• Output elements	185
• Control elements	193
• Auxiliary elements	197

6.6.1 General processing

The parser in the GBAS/SCAT-I application uses the first message control XML file as instructions for processing. As input, it receives a bitstream from the GBAS burst in the input signal.

The general process of interpreting the bitstream consists of the following steps:

1. The parser applies the first instruction on the leading bits of the bitstream, which usually produces a value or text as output.

2. The parser applies the next instruction on the subsequent bits of the bitstream.

As a result, either an output is produced, or further instructions are provided. Further instructions can be provided in additional XML files, or depend on the current bitstream value, or on a previous value (see ["Control elements"](#) on page 181).

3. The parser continues to process the instructions as defined in the XML file, applying them to the subsequent, not-yet-processed bits of the bitstream.

4. When the end of the last XML file has been processed, the parser stops.


The converted, human-readable data is displayed in the "Message" view.

Step 1

```

<Element>
  <data_content>ABC_XYZ</data_content>
  <data_content_short>ABC</data_content_short>
  <bits_used>4</bits_used>
  <type>value</type>
</Element>
XML file

```

**Interpretation**


Data Content	Bits used	Value	Binary
ABC_XYZ	4	3	0011

Step 2

```

<Element>
  <data_content>KLMO</data_content>
  <data_content_short>KLM</data_content_short>
  <bits_used>8</bits_used>
  <type>value</type>
</Element>
XML file

```

**Interpretation**


Data Content	Bits used	Value	Binary
KLMO	8	118	01110110

Step n

```

<Element>
  <data_content>Fill Bits</data_content>
  <data_content_short>FILL_BITS</data_content_short>
  <type>fill</type>
</Element>
</Gbas>
XML file

```

**Output in Message view table**

Data Content	Bits used	Value	Binary
ABC_XYZ	4	3	0011
KLMO	8	118	01110110

6.6.2 Output elements and control elements

Different types of elements are supported to interpret all existing values in a GBAS burst. However, the types are generic and can be configured to handle other values, as well.

Many elements simply convert a binary value in the bitstream to human-readable output for the "Message" view table. Conversion in this case can consist of various different instructions, such as:

- Comparing bitstrings and providing a check result
- Converting binary values to decimal values
- Converting binary values to text descriptions

For different instructions, you must define different element types.

Example: Interpretation of a "fixed"-type element

The `fixed`-type element expects a certain number of bits to have a specific value. If the incoming bitstream matches, the result value is `OK`, otherwise it is `NOK`.

The result of the interpretation on the R&S EVSF1000 is a table similar to the examples in DO246, in this case:

Table 6-1: Output in Message view table

Data Content	Bits used	Value	Binary
Power stabilization	15	OK	000000000000000
Sync. and ambiguity resolution	48	OK	0100011111011111 1000110001110110 0000011110010000

All available element types are described in [Chapter 6.6.4, "Format description of elements"](#), on page 185.

Control elements

Each GBAS burst can contain one or more messages. The messages have different message types with different content. The content of the same message type can depend on certain parameters which are only known during runtime. Therefore, control elements such as a case-dependent branch to a further XML file are supported.

Example: Case-dependent processing

This example shows how the parser is directed to different instructions, which are stored in additional XML files, depending on the determined message type:

```
<Element>
  <data_content>Message</data_content>
  <data_content_short>MSG</data_content_short>
  <type>link_sel</type>
  <link_sel>MTI</link_sel>
  <link_case>
    <value>1</value>
    <link>GbasMsgType1.xml</link>
  </link_case>
  <link_case>
    <value>2</value>
    <link>GbasMsgType2.xml</link>
  </link_case>
  <link_case>
    <value>4</value>
    <link>GbasMsgType4.xml</link>
  </link_case>
</Element>
```

The additional XML files have the same format and supported elements. They can branch to even more files, there is no limit to how deeply the files are nested.

Further control elements implement loops which repeat sequences for several repetitions ("for"-loop) or while there is enough data left ("while"-loop).

Control elements can also contain references to previous elements, that is: to results obtained in previous instruction steps. References are defined using the element's unique identifier, which is a mandatory part of each element.

Using links and loops, the parser can navigate through the entire bitstream.

Parser results

The result of the interpreted bitstream is a comma-separated list of values which is displayed in the "Message" view (see [Chapter 6.4.5, "Message view"](#), on page 171).

Recording GBAS data

When you record and export the results of a GBAS measurement, all measured values and the bitstream for each record are stored as a comma-separated list. This basic CSV file contains a data link for each record in the list. The link points to a further CSV file which contains all human-readable texts for that record. All data files for the current recording are stored in a subdirectory that is exported together with the basic CSV file. The file with the human-readable text values contains the data that is displayed in the "Message" view.

Example:

One row of data from the basic CSV file for list number 20 (gbas_rx1_list20.csv):

```
1,,3,18.09.2018,14:29:57.844,D,108.0000,0.000,-8.15,-4.63,-,7.0,CMJ ,NOK,4,NOK,
0.0e+00,882,-.-,-.-,-.-,20.553,481.0,00° 00.00000000' N,00° 00.00000000' E,0.00,0.00,
--.--,--,--,0,NO GPS,NO GPS,--,--,MAN:Norm,0,1 82 30 00 55 05 4B 30 20
3A 94 0F F0 40 60 30 F2 98 C0 C8 40 28 E0 61 47 5D 48 09 7B C9 00 AD D8 33 3C BF 34
07 40 AA 81 34 80 26 00 B2 15 A5 45 26 13 94 08 F0 40 60 30 86 90 A8 04 70 28 E0 3D
83 ED 48 38 C5 E9 00 4B D8 DF 46 40 3C 21 BF 8C 81 B4 80 26 00 EB 05 B2 F5 26 13 D9
7F C0 EA A1 A4 3D 54 89 D8 00 00 ,=HYPERLINK("gbas_rx1_list20/MSG000003_D.csv")
```

Extract of data file gbas_rx1_list20/MSG000003_D.csv:

```
Name,Type,bits used,Value,Unit,binary
Power Stabilization,fixed,15,OK,,0000000000000000
Sync. and Amb. Resolution,fixed,48,OK,,01000111110111110001100011101100000011110010000
```

Table 6-2: Output in Message view table

Data Content	Bits used	Value	Binary
Power stabilization	15	OK	0000000000000000
Sync. and ambiguity resolution	48	OK	010001111101111100011000111011000 00011110010000

6.6.3 XML file format description

The GBAS/SCAT-I message interpretation files comprise at least the following XML files:

- **Burst.xml**: describes the basic structure of a message and is identical for all messages.
This is the basic (root) file for interpretation.
- **GbasMsgBlock.xml**: describes the LAAS message block.
This file is referred to by **Burst.xml** and can refer to further XML files.
- **GbasMsgType<x>.xml**: describes each message type in an individual file.
These files are referred to by **Burst.xml** and can refer to further XML files.




Figure 6-7: Examples for xml message interpretation files; left: message type 1; right: message types 1 and 4

The GBAS/SCAT-I option provides XML files for all currently supported GBAS/SCAT-I message types, as shown in [Table 6-3](#).

Table 6-3: Provided XML files for GBAS/SCAT-I message types

Message type	Description	Reference
GBAS-MT1	Pseudo-range corrections – 100 second smoothed pseudo-ranges.	ICAO AN10 Vol1 / RTCA DO-246
GBAS-MT2	GBAS-related data.	ICAO AN10 Vol1 / RTCA DO-246
GBAS-MT4	Final approach segment (FAS) data.	ICAO AN10 Vol1 / RTCA DO-246
GBAS-MT11	Pseudo-range corrections – 30 second smoothed pseudo-ranges.	ICAO AN10 Vol1 / RTCA DO-246
SCAT-I-MT1		RTCA DO-217
SCAT-I-MT4		RTCA DO-217

Burst.xml

Each GBAS bitstream consists of several elements. The first elements are the same for all bursts:

- Power stabilization (15 bits)
- Synchronicity & ambiguity resolution (48 bits)
- SSID (3 bits)
- Transmission length (17 bits)
- ...

This general information is provided in the `Burst.xml` file, which is the start file for conversion. The root element in this file is `<Gbas>`, which means the file starts with `<Gbas>` and ends with `</Gbas>`.

Within the `<Gbas>` element, a definition for each subelement (`<Element>`) is provided.

Example: Element definition in burst.xml file

```
<Gbas>
  <Element>
    <data_content>Power Stabilization</data_content>
    <data_content_short>POW_STAB</data_content_short>
    <bits>0000000000000000</bits>
    <type>fixed</type>
  </Element>
  <Element>
    <data_content>Sync. and Amb. Resolution</data_content>
    <data_content_short>SYNC_AMB_RES</data_content_short>
    <bits>00001001111000000110111000110001111101111100010</bits>
    <type>fixed</type>
  </Element>
  ...
</Gbas>
```


The format of the individual elements is described in the following sections.

6.6.4 Format description of elements

Different types of elements are supported to interpret all existing values in a GBAS burst. However, the types are generic can be configured to handle other values, as well.

Each `<Element>` in the XML file must have the following subelements:

Table 6-4: Mandatory subelements

Name	Description
<code><data_content></code>	Text that describes the content, usually the description from the DO246 document
<code><data_content_short></code>	A short description or unique keyword used to reference the element. Select the name carefully - changing the name later can cause errors in the functionality of other elements
<code><type></code>	Determines how the parser processes the element

The element type determines how the data is interpreted. Depending on the `<type>`, further elements can be mandatory.

6.6.5 Output elements

• Unsigned type	185
• Signed type	186
• Longitude type	187
• Latitude type	188
• Id type	189
• Fixed type	189
• Value type	189
• FEC type	190
• CRC type	190
• List type	191
• Enum type	192
• Dummy type	193

6.6.5.1 Unsigned type

Interprets the value in a given number of bits as an unsigned (positive) integer value in decimal format

Table 6-5: Mandatory subelements

Name	Description
<code><bits_used></code>	Static number of bits

Table 6-6: Optional subelements

Name		Description
<resolution>		Determines the resolution of the element contents, e.g. a result value. The value is multiplied with the <resolution> factor to obtain the output result. Note that the number of decimals of the <resolution> factor also defines the number of decimals in the result. (Default: 1)
<unit>		Additional unit which is appended to the result
<special>		Special text that is provided as a result instead of using the value and resolution
	<value>	Actual result value
	<name>	Provided result text

Example:

```

<Element>
  <data_content>Source Availability Duration</data_content>
  <data_content_short>SRC_DUR</data_content_short>
  <bits_used>8</bits_used>
  <type>unsigned</type>
  <special>  <value>254</value>  <name>&gt;2540</name>  </special>
  <special>  <value>255</value>  <name>not provided</name>  </special>
  <resolution>10</resolution>
  <unit>s</unit>
</Element>

```

6.6.5.2 Signed type

Interprets the value in a given number of bits as a signed integer value in decimal format

Table 6-7: Mandatory subelements

Name	Description
<bits_used>	Static number of bits

Table 6-8: Optional subelements

Name	Description
<resolution>	Determines the resolution of the element contents, e.g. a result value. The value is multiplied with the <resolution> factor to obtain the output result. Note that the number of decimals of the <resolution> factor also defines the number of decimals in the result. (Default: 1)
<unit>	Additional unit which is appended to the result
<special>	Special text that is provided as a result instead of using the value and resolution

Name		Description
	<value>	Actual result value
	<name>	Provided result text

Example:

```

<Element>
  <data_content>Pseudorange    Correction    (PRC)</data_content>
  <data_content_short>PRC</data_content_short>
  <bits_used>16</bits_used>
  <type>signed</type>
  <resolution>0.01</resolution>
  <unit>m</unit>
</Element>

```

6.6.5.3 Longitude type

Like a signed value, but output is formatted in <degree>-<minute>-<second> format, with "E" = East for positive and "W" = West for negative values

Table 6-9: Mandatory subelements

Name	Description
<bits_used>	Static number of bits

Table 6-10: Optional subelements

Name		Description
<resolution>		Determines the resolution of the element contents, e.g. a result value. The value is multiplied with the <resolution> factor to obtain the output result. Note that the number of decimals of the <resolution> factor also defines the number of decimals in the result. (Default: 1)
<unit>		Additional unit which is appended to the result
<special>		Special text that is provided as a result instead of using the value and resolution
	<value>	Actual result value
	<name>	Provided result text

Example:

```

<Element>
  <data_content>Longitude</data_content>
  <data_content_short>Long</data_content_short>
  <bits_used>32</bits_used>
  <type>long</type>
  <resolution>0.0005</resolution>
</Element>

```

Table 6-11: Output in Message view table

Data Content	Bits used	Value	Binary
Longitude	32	W93°25'13.0000"	11010111111010001000101010110000

6.6.5.4 Latitude type

Like a signed value, but output is formatted in degree-minute-second format, with "E" = East for positive and "W" = West for negative values

Table 6-12: Mandatory subelements

Name	Description
<bits_used>	Static number of bits

Table 6-13: Optional subelements

Name		Description
<resolution>		Determines the resolution of the element contents, e.g. a result value. The value is multiplied with the <resolution> factor to obtain the output result. Note that the number of decimals of the <resolution> factor also defines the number of decimals in the result. (Default: 1)
<unit>		Additional unit which is appended to the result
<special>		Special text that is provided as a result instead of using the value and resolution
	<value>	Actual result value
	<name>	Provided result text

Example:

```

<Element>
  <data_content>Latitude</data_content>
  <data_content_short>Lat</data_content_short>
  <bits_used>32</bits_used>
  <type>lat</type>
  <resolution>0.0005</resolution>
</Element>

```

Table 6-14: Output in Message view table

Data Content	Bits used	Value	Binary
Latitude	32	N45°40'32.0000"	00010011100110100001000100000000

6.6.5.5 Id type

Decodes the unique airport ID which consists of 4 characters, coded in 24 bits.

Example:

```

<Element>
  <data_content>GBAS ID</data_content>
  <data_content_short>GBAS_ID</data_content_short>
  <type>id</type>
</Element>

```

6.6.5.6 Fixed type

The *fixed*-type element expects a certain number of bits to have a specific value. If the incoming bitstream matches, the result value is OK, otherwise it is NOK.

Table 6-15: Mandatory subelements

Name	Description
<bits>	Binary bitstream content made of 0 and 1

Example:

```

<Element>
  <data_content>Reserved and Zero</data_content>
  <data_content_short>Zeroes</data_content_short>
  <bits>00000</bits>
  <type>fixed</type>
</Element>

```

6.6.5.7 Value type

Binary data without evaluation. Used to document content when a numerical interpretation does not make sense.

Table 6-16: Mandatory subelements

Name	Description
<bits_used>	Static number of bits

Example:

```

<Element>
  <data_content>Ephemeris  CRC  LSB</data_content>
  <data_content_short>EPH_CRC_LSB</data_content_short>
  <bits_used>8</bits_used>
  <type>value</type>
</Element>

```

6.6.5.8 FEC type

Binary data without evaluation.

Table 6-17: Mandatory subelements

Name	Description
<bits_used>	Static number of bits

Example:

```

<Element>
  <data_content>Ephemeris  CRC  LSB</data_content>
  <data_content_short>EPH_CRC_LSB</data_content_short>
  <bits_used>8</bits_used>
  <type>value</type>
</Element>

```

6.6.5.9 CRC type

Calculates a checksum and compares it with the given value. Evaluates to OK or NOK.

Table 6-18: Mandatory subelements

Name	Description
<bits_used>	Static number of bits
<start>	Reference (<data_content_short>) to the element at which the checksum calculation starts

Example:

```

<Element>
  <data_content>Message Block CRC</data_content>
  <data_content_short>MSG_B_CRC</data_content_short>
  <bits_used>32</bits_used>
  <start>MBI</start>
  <type>crc</type>
</Element>

```

Table 6-19: Output in Message view table

Data Content	Bits used	Value	Binary
Message Block CRC	32	OK	11100000011100100001110100100100

6.6.5.10 List type

Converts different integer values to text output

Requires a `<list>` subelement for each pair of `<name>` and `<value>`.

Table 6-20: Mandatory subelements

Name		Description
<code><bits_used></code>		Static number of bits
<code><list></code>		Pair of <code><name></code> and <code><value></code> subelements; Multiple <code><list></code> elements allowed
	<code><name></code>	Provided result text
	<code><value></code>	Result value (integer) For last entry in list also <code>default</code> ; Default applies if no other case does

Example:

```
<Element>
  <data_content>Message Block Identifier</data_content>
  <data_content_short>MBI</data_content_short>
  <bits_used>8</bits_used>
  <type>list</type>
  <list>
    <name>normal</name>
    <value>170</value>
  </list>
  <list>
    <name>test</name>
    <value>255</value>
  </list>
  <list>
    <name>invalid   MBI</name>
    <value>default</value>
  </list>
</Element>
```

6.6.5.11 Enum type

Converts each different result value to an output text. Requires an `<enum>` subelement for each possible result value. If there are undefined values, use the `list` type.

Table 6-21: Mandatory subelements

Name	Description
<code><bits_used></code>	Static number of bits
<code><enum></code>	Texts to be output for specific number values; Multiple <code><enum></code> elements allowed and required The number of <code><enum></code> subelements must equal the number of possible results for the number of <code><bits_used></code>. Number values are implicitly defined as the order number of the <code><enum></code> subelement and start at 0.
<code><name></code>	Provided result text

Example:

```
<Element>
  <data_content>Ground Station Accuracy Designator</data_content>
  <data_content_short>GStAccDes</data_content_short>
  <bits_used>2</bits_used>
  <type>enum</type>
  <enum> <name>A</name> </enum>
  <enum> <name>B</name> </enum>
  <enum> <name>C</name> </enum>
  <enum> <name>spare</name></enum>
</Element>
```


6.6.5.12 Dummy type

No evaluation, but the binary content is documented, and the parser continues with the next element.

Can be used when there are unknown contents whose length is known.

Table 6-22: Mandatory subelements

Name	Description
<Length>	Previous element (<data_content_short>) that contains the length of the unknown elements in bit.
<Start>	Previous element (<data_content_short>) after which the length count starts

Example:

Example for a dummy that reads additional MT2 block without further definition.

```
<Element>
  <data_content>Unknown Additional Block</data_content>
  <data_content_short>UnBlk</data_content_short>
  <type>dummy</type>
  <Length>AddBlkLen</Length>
  <Start>AddBlkLen</Start>
</Element>
```

6.6.6 Control elements

- [Link_sel type](#)..... 193
- [Loop type](#)..... 196
- [While type](#)..... 196

6.6.6.1 Link_sel type

Depending on the result of the selected element, processing continues with the specified element or subprocess.

Requires a <link_sel> and one or more <link_case> subelements.

Table 6-23: Mandatory subelements

Name	Description
<link_sel>	Reference (<data_content_short>) to a previous element whose value determines further processing; If no <link_sel> subelement is provided and only one <link_case> subelement, processing always continues with the referenced element.
<link_case>	Possible case of further processing

Name	Description
<value>	Integer value or default If the value of the <link_sel> subelement corresponds to this value, processing continues with this <link_case>. Default applies if no other case does
<link> <sub>	Reference to the element (<data_content_short>) or a file with which processing continues Subprocess containing further elements to be processed

Example: Link selector with files and a default value

```

<Element>
  <data_content>Message</data_content>
  <data_content_short>MSG</data_content_short>
  <type>link_sel</type>
  <link_sel>MTI</link_sel>
  <link_case><value>1</value><link>GbasMsgType1.xml</link></link_case>
  <link_case><value>2</value><link>GbasMsgType2.xml</link></link_case>
  <link_case><value>4</value><link>GbasMsgType4.xml</link></link_case>
  <link_case><value>default</value><link>GbasMsgTypeX.xml</link></link_case>
</Element>

```

Example: Link selector with a direct link

With only one link and no decisive value, processing continues with the given file.

```

<Element>
  <data_content>Message Block Header</data_content>
  <data_content_short>MB_HEAD</data_content_short>
  <type>link_sel</type>
  <link_case>
    <link>GbasMsgBlock.xml</link>
  </link_case>
</Element>

```

Example: Link selector with subdefinitions

```

<Element>
  <data_content>Additional Data Block</data_content>
  <data_content_short>AddBlk</data_content_short>
  <type>link_sel</type>
  <link_sel>AddBlkNum</link_sel>
    <link_case>
      <value>2</value>
      <sub>
        <Element>
          <data_content>Channel Number</data_content>
          <data_content_short>ChNum</data_content_short>
          <bits_used>16</bits_used>
          <type>unsigned</type>
        </Element>
        <Element>
          <data_content>Delta Latitude</data_content>
          <data_content_short>DLat</data_content_short>
          <bits_used>8</bits_used>
          <type>signed</type>
          <resolution>0.2</resolution>
          <unit>°</unit>
        </Element>
      ...
    </link_case>
    <link_case>
      <value>3</value>
      <sub>
        <Element>
          <data_content>K md e D GPS</data_content>
          <data_content_short>KmdeDGps</data_content_short>
          <bits_used>8</bits_used>
          <type>unsigned</type>
          <resolution>0.05</resolution>
          <unit></unit>
        </Element>
        <Element>
          <data_content>K md e D GLONASS</data_content>
          <data_content_short>KmdeDGlo</data_content_short>
          <bits_used>8</bits_used>
          <type>unsigned</type>
          <resolution>0.05</resolution>
          <unit></unit>
        </Element>
      ...
    </link_case>
  </Element>

```

6.6.6.2 Loop type

Repeats the included elements for a given number of times;

Table 6-24: Mandatory subelements

Name	Description
<NUM>	Only for type loop: Reference to the element (<data_content_short>) whose value determines the number of processing repetitions
<loop>	Only for type loop: Subprocess containing further elements to be processed within a loop

Example:

Abbreviated example for a loop over the MT1-satellites:

```
<Element>
  <data_content>Measurement   Block</data_content>
  <data_content_short>MSG_BLK</data_content_short>
  <type>loop</type>
  <NUM>NOF_M</NUM>
  <Loop>
    <Element>
      <data_content>Ranging   Source   ID</data_content>
      <data_content_short>Z_COUNT</data_content_short>
      <bits_used>8</bits_used>
      <type>unsigned</type>
      <resolution>1</resolution>
    </Element>
    <Element>
      <data_content>Issue   of   Data   (IOD)</data_content>
      ...   </Element>
    </Loop>
  </Element>
```

6.6.6.3 While type

Repeats the included elements while there are enough bits left to proceed;

Table 6-25: Mandatory subelements

Name	Description
<BitsLeft>	Number of bits required at the end of the loop to perform the next cycle (minimum+1 required); otherwise loop is finished
<TrLen>	Previous element that contains the transmission length in bit. Sometimes the transmission length is provided in bytes; in this case, make sure the resolution of that previous element is set to 8 to convert its value to bits
<TrStart>	Previous element at which the transmission length begins to count bits
<loop>	Subprocess containing further elements to be processed within a loop

Example:

Example of a "while" loop that repeats the message block as long as there are more than 48 bits left:

```
<Element>
  <data_content>Message   Block</data_content>
  <data_content_short>MSG_BLOCK</data_content_short>
  <type>while</type>
  <BitsLeft>48</BitsLeft>
  <TrLen>TRANS_L</TrLen>
  <TrStart>MSG_BLOCK</TrStart>
  <Loop>
    <Element>
      <data_content>Message   Block   Header</data_content>
      <data_content_short>MB_HEAD</data_content_short>
      <type>link_sel</type>
      <link_case>
        <link>GbasMsgBlock.xml</link>
      </link_case>
    </Element>
  </Loop>
</Element>
```

6.6.7 Auxiliary elements

- [Fill type](#).....197

6.6.7.1 Fill type

Used for the transmission end. It determines the number of bits that are left in the data stream. This number is usually 0. Otherwise the `<fill>` element indicates how many bits are still available at the end of the transmission.

Example:

```
<Element>
  <data_content>Fill Bits</data_content>
  <data_content_short>FILL_BITS</data_content_short>
  <type>fill</type>
</Element>
```

7 Data management

The R&S EVSF1000 allows you to store and load measurement settings, and export measurement data for analysis later. Finally, you can store the measurement results displayed on the screen.

- [Storing and recalling measurement settings \(preset\)](#).....198
- [Recording measurement data](#).....200
- [Creating and storing screenshots](#)..... 207

7.1 Storing and recalling measurement settings (preset)

Possibly you would like to restore or repeat a measurement you performed under specific conditions on the R&S EVSF1000. Or you would like to troubleshoot a measurement and require a defined instrument state to detect the precise cause of the error. In these cases, you can store and recall instrument and measurement settings. You can store and recall up to 20 different settings, referred to as *UserPresets*, on the instrument.

Settings stored in a UserPreset

In each UserPreset, the following current settings are stored:

- All measurement settings (see [Chapter 2, "Measurements and results"](#), on page 37)
- All general instrument settings except for the network settings (see [Chapter 8, "Common instrument settings"](#), on page 209)
- Date and time of storage

The list of UserPresets and the corresponding functions are available in the [Preset] menu.

- [Storage and recall functions](#).....198

7.1.1 Storage and recall functions

VNC access: [y]

For each stored UserPreset, the storage date and time are indicated in the "Preset" window. Empty UserPresets are indicated as "not used".

Storing and recalling measurement settings (preset)

Preset			Preset
No	Preset Name	Date and Time of Saving	Preset
1	User_Preset_01	09.07.2020 16:32:08	Preset
2	User_Preset_02	Not used	
3	User_Preset_03	Not used	Save
4	User_Preset_04	Not used	
5	User_Preset_05	Not used	Save to USB
6	User_Preset_06	Not used	
7	User_Preset_07	Not used	Recall
8	User_Preset_08	Not used	
9	User_Preset_09	Not used	Recall from USB
10	User_Preset_10	Not used	
11	User_Preset_11	Not used	Delete
12	User_Preset_12	Not used	
13	User_Preset_13	Not used	Rename
14	User_Preset_14	Not used	
15	User_Preset_15	Not used	
16	User_Preset_16	Not used	
17	User_Preset_17	Not used	
18	User_Preset_18	Not used	
19	User_Preset_19	Not used	
20	User_Preset_20	Not used	
Rec List 1	Size 11	Local	Mains

Use the arrow keys to scroll through the UserPresets.



While the "Preset" view is displayed, audio and display settings are not available. Return to a measurement view first ([a]).

Preset.....	199
L Factory Preset.....	200
Save.....	200
Save to USB.....	200
Recall.....	200
Recall from USB.....	200
Delete.....	200
Rename.....	200

Preset

When delivered, the R&S EVSF1000 has a default configuration. You can restore this defined initial state at any time as a known starting point for measurements. Presetting is often recommendable as a first step in troubleshooting when unusual measurement results arise.

Two different preset functions are available, the "simple" preset and the "Factory Preset".

The "simple" preset function retains the instrument's IP address and host name, and all stored data.

Factory Preset ← Preset**VNC access:** [y]

The default configuration is restored, except for the instrument's IP address and host name. All stored data is deleted!

Remote command:

[FACTORY_PRESET](#) on page 250

Save

Stores the current measurement settings in the selected UserPreset under the specified name, together with the current date and time.

If the selected UserPreset already contained settings before, they are overwritten.

Save to USB

Stores the current measurement settings under the specified name on a connected USB storage device, together with the current date and time.

The default name is `User_Preset_<no.>.evsfpreset`, where `<no.>` is a consecutive number. The file name can be edited. The files are stored to the subdirectory `EVSF1000_PRESETS`.

Recall

Overwrites the current measurement settings by the settings stored in the selected UserPreset.

Recall from USB

Overwrites the current measurement settings by the settings stored in the selected UserPreset on a connected USB storage device.

Delete

Deletes the settings and the name assigned to the selected UserPreset.

Rename

Renames the selected UserPreset.

7.2 Recording measurement data

During a measurement with the R&S EVSF1000, the input signal is captured and various results are calculated and displayed on the screen (see [Chapter 2, "Measurements and results"](#), on page 37). These results can also be stored in data lists, which can be exported as `.csv` files for further investigation.

Data is stored continuously for all measurements that are performed after recording is started and until it is stopped. The data for each recording session is stored to a file internally. The file name is defined by the following syntax:

```
<measmode>_<rx_board>_list<no.>.csv
```

Where:

- **<measmode>**: the used measurement mode

- **<rx_board>**: the used receiver board (rx1, rx2)
- **list<no.>**: the used data list
- [GNSS data synchronization](#).....201
- [I/Q data recording and streaming](#).....201
- [Recording settings](#).....202
- [Activating and triggering data recording](#).....204
- [Viewing recorded data](#).....206
- [Analyzing recorded I/Q data](#).....206
- [Exporting measurement data](#).....207

7.2.1 GNSS data synchronization

Together with the measurement results, the GNSS data at the time of signal input is also stored, if available (see [Chapter 8.7, "GNSS configuration"](#), on page 225). Storing GNSS data is useful to synchronize specific measurement results with the precise time and location of the input signal. However, signal transmission via the RS232 serial connection can cause delays in the stored GNSS time as opposed to the actual time of input. Therefore, it is useful to synchronize the stored GNSS data to the PPS signal also provided by the GNSS receiver.

7.2.2 I/Q data recording and streaming

Optionally, the raw, unprocessed I/Q data can also be stored with the data recording. In this case, the I/Q data is stored as a separate file with the same file name as the data list, but the extension `.iq`. This feature requires the R&S EVSG1-K25 I/Q data streaming option.

I/Q data is stored with a sample rate of 125000 samples per second. I and Q values are stored with 32 bit each, in little endian and signed integer format. The I/Q data level is aligned to the RF input signal of the R&S EVSF1000. That is: 0 dBm correspond to a magnitude value of 0x10000000 (hexadecimal). Each sample requires 8 bytes of storage, which adds up to 1 MB per second. The I/Q data files can become very large. After 33 minutes, they exceed 2 GB, meaning they can no longer be stored on a FAT-formatted USB storage device. In this case, you require a storage device with a linux file system, e.g. ext4. Also consider the limitations of the internal storage device. When using two RX boards simultaneously, the storage is filled up twice as quickly.

I/Q data can also be streamed during the measurement using the LAN interface of the R&S EVSF1000 (TCP port 8001 (RX1) or 8002 (RX2)). Simply connect a TCP/IP client to the port and the data is streamed immediately. The format is the same as for recording.

Example:

```
netcat 172.23.226.22 8001 > File1.iq
```

Starts streaming I/Q data from the RX1 input to a file named `File1.iq`.

You can use the I/Q data to analyze the signal in external software, for example, or to reproduce the signal on a signal generator.

7.2.3 Recording settings

Access VNC: [s] > [F7]

(For numeric measurement modes only)



Recording GBAS/SCAT-I measurement results

In GBAS/SCAT-I mode, one record is stored for each slot, in a time interval of 62.5 ms, as long as recording is active. Triggering is not supported. Recording is continued even if the display update is temporarily stopped (by the "Pause" function).

Start and stop recording from any measurement view using the [Record] key.

Record the selected and currently displayed slot or frame only using the [Single] key.

The record contains measurement values and the message bitstream for the slot. All records are stored in a CSV file. This basic CSV file contains a data link for each record in the list. The link points to a further CSV file which contains all human-readable texts for that record. All data files for the current recording are stored in a subdirectory that is exported together with the basic CSV file.

See also "[Recording GBAS data](#)" on page 182.

List.....	202
Clear List.....	202
Time.....	203
Data selection (Sel, not GBAS/SCAT-I mode).....	203
Data selection (Select, GBAS/SCAT-I mode only).....	203
L Parameter.....	203
L Msg Log.....	203
L Graph Log.....	204
L Slot <x> Log.....	204
Export List to USB.....	204
Clear All Lists.....	204
Rec IQ.....	204

List

Selects a specific data set list (1 to 999, the list number is shown in the softkey).

Remote command:

[SETACTIVELIST](#) on page 365

[GETACTIVELIST](#) on page 361

Clear List

Deletes all entries in the current list.

Remote command:

[CLEARACTIVELIST](#) on page 361

Time

Specifies how often an entry is appended to the data list. Enter the time in milliseconds.

Note that the minimum spacing between two values is defined by the availability of measurement result values (see [Chapter 4.1.4.6, "Setting the measurement time \(MTime\)"](#), on page 74). If more values are available than are stored, that is: "Time" > [Setting the measurement time \(MTime\)](#), the calculated values are averaged to obtain only the required number of results.

In GBAS/SCAT-I mode, one record is stored for each slot, in a time interval of 62.5 ms, as long as recording is active. The time interval cannot be edited.

Data selection (Sel, not GBAS/SCAT-I mode)

By default, the whole data set is recorded. You can configure the scope of the data to be displayed and exported. For details on the individual data sets, see the remote command ([SELECTLISTPARAM](#) on page 364).

"All"	Includes all EVSF1000 and R&S EVS300 values.
"Full"	Compatible to R&S EVS300.
"Medium"	A reduced set of values
"Short"	A minimum set of values

Remote command:

[SELECTLISTPARAM](#) on page 364

Data selection (Select, GBAS/SCAT-I mode only)

By default, the whole data set for every slot is recorded. You can configure the scope of the data to be displayed and exported. For details on the individual data sets, see the remote command ([GBAS : GETMEAS](#) on page 327).

Parameter ← Data selection (Select, GBAS/SCAT-I mode only)

Defines which parameters are stored for each slot.

"All"	Includes all EVSF1000 and R&S EVS300 values
"Full"	Compatible to R&S EVS300
"Medium"	A reduced set of values
"Short"	A minimum set of values
"Raw"	Only the decoded, non-interpreted measurement values from the bitstream in binary format

Remote command:

[GBAS : GETMEAS](#) on page 327

Msg Log ← Data selection (Select, GBAS/SCAT-I mode only)

Defines which message information is stored for each slot.

"All"	All message data (human-readable + bitstream) is stored (default).
"TXT"	Only the human-readable, interpreted message values are stored.
"RAW HEX"	Only the decoded, non-interpreted message data from the bitstream in binary format is stored.

"None" Message data is not included in the slot data record.

Remote command:

[GBAS:MSG_TOLOGG](#) on page 329

Graph Log ← Data selection (Select, GBAS/SCAT-I mode only)

Defines whether graphical information such as the time domain and constellation values are stored.

Remote command:

[GBAS:GRAPH_TOLOGG](#) on page 329

Slot <x> Log ← Data selection (Select, GBAS/SCAT-I mode only)

Activates or deactivates data recording for the corresponding slot.

To toggle between the slots A to D and slots E to H in the menu, press the "More soft-keys" key.

Export List to USB

Exports the data list to a connected USB storage device.

Remote command:

[SAVEACTIVELIST2USB](#) on page 364

Clear All Lists

Deletes all entries in all data lists.

Remote command:

[CLEARALLLISTS](#) on page 363

Rec IQ

If enabled, the raw, unprocessed I/Q data is also recorded. This feature requires the R&S EVSG1-K25 I/Q data streaming option.

I/Q data is stored as a separate file with the same file name as the data list, but the extension `.iq`. Furthermore, the data list contains two additional entries:

"IQSamples": indicates how many samples the data set includes; depending on the measurement time this number can vary.

"IQPosition": indicates the starting position of the data set within the I/Q data file

Remote command:

[RECIQ](#) on page 363

7.2.4 Activating and triggering data recording

By default, data is recorded in a specific time interval (see ["Time"](#) on page 203) as long as recording is active. Alternatively, you can use an external trigger, if available, to determine when data is stored. For example, you can store data at regular distances during a moving measurement, based on a rotary position transducer.



Recording GBAS/SCAT-I measurement results

In GBAS/SCAT-I mode, one record is stored for each slot, in a time interval of 62.5 ms, as long as recording is active. Triggering is not supported. Recording is continued even if the display update is temporarily stopped (by the "Pause" function).

Starting and Stopping Recording.....	205
Trigger Source.....	205
Offset.....	205
Trigger Edge.....	205
Input.....	205
Recording a single data record (GBAS/SCAT-I mode only).....	206

Starting and Stopping Recording

Access VNC: [p]

When you press the key, data is recorded to the selected list, indicated in the status bar ("Rec List"). The number of data sets that the list currently contains is indicated as "Size". How often and when a new data set is entered in the list depends on the "Trigger Source" on page 205.

If enabled, raw, unprocessed I/Q data is also recorded to a separate file (see "Rec IQ" on page 204).

Trigger Source

Access VNC: [k] > "F2"

Determines how often and when a new data set is entered in the list during recording.

"Time"	Data is stored in regular time intervals, defined by "Time" on page 203.
"Ext."	Data is stored each time a trigger signal from a connected external trigger device is received. The trigger device must be connected to the "Trigger In" connector on the rear panel of the R&S EVSF1000.

Offset

Access VNC: [k] > "F4"

Defines an offset to the specified trigger event before data storage is actually started.

Trigger Edge

Access VNC: [k] > "F5"

For external triggering, this setting defines whether data is stored when the positive (rising) or negative (falling) edge of the trigger signal is received. Select the key repeatedly to toggle between the two settings.

Input

Access VNC: [k] > "F7"

Determines which input triggers data storage or defines the GNSS PPS synchronization source.

"PPS GPS"	Signal provided at the RS232-GPS or GNSS connector
"PPS SMA"	Signal provided at the PPS In connector

Remote command:

[PPSSMA_TRIG_SOURCE?](#) on page 235

Recording a single data record (GBAS/SCAT-I mode only)

Access: [Single]

Records the selected and currently displayed slot or frame only.

This function is only available for GBAS/SCAT-I mode (R&S EVSG-K4 GBAS analysis/R&S EVSG-K5 SCAT-I Analysis).

7.2.5 Viewing recorded data

The "Recording" view displays the recorded data for the current measurement mode from the selected data file (see ["List"](#) on page 202).

The following functions are available in the "Recording" view for all modes.

DL Line

Selects a particular line (record) in the data recording file.

7.2.6 Analyzing recorded I/Q data

Optionally, raw, unprocessed I/Q data is recorded to a separate file during recording (see ["Rec IQ"](#) on page 204).

Additional information on the I/Q data is stored in the CSV data list, indicating where in the `.iq` file the I/Q data for a specific data set starts and how many samples it contains. You can use this information to synchronize the raw I/Q data with the evaluated measurement data for each data set.

You can also use the stored I/Q data to reproduce the measured signal on a signal generator. Using the R&S ARB Toolbox, for example, you can convert the `.iq` data file to a `.wv` file.

To convert the `.iq` data file to a `.wv` file

1. In the R&S ARB Toolbox, right-click the `.iq` data file.
2. Select "Convert" > "Convert from Data".
3. Select the following settings for the data format:
 - "File Type": "Binary"
 - "Data format": "Integer"
 - "Endianness": "Little-Endian (x86)"
 - "Precision": "32 Bit"
 - "Signedness": "Signed (Two's Complement)"
4. Define the clock rate as *125 kHz*.

7.2.7 Exporting measurement data

After recording measurement data, you can export the CSV files with the results for further investigation.


To export measurement data

- 1. Connect the storage device to the USB connector on the instrument.
- 2. In the "Recording" settings, select "Export List to USB".

7.3 Creating and storing screenshots

Access: [Setup] > "Screenshots"

You can create a screenshot of the current display on the R&S EVSF1000 at any time during operation. Creating screenshots is useful to document measurement results, for example.



Creating a Screenshot.....	207
Number of Screenshots.....	208
Storage of screenshots on.....	208
Colors for copying to USB.....	208
Exporting Screenshots to a USB device.....	208
Deleting all Screenshots Stored on the R&S EVSF1000.....	208



Creating a Screenshot
Access VNC: [x]

When you create a screenshot, the display is stored as a graphic file on the instrument (until it is explicitly deleted). It can be copied to a USB memory device later (see [Exporting Screenshots to a USB device](#)). Internally, the screenshot files are named "Screenshot_", followed by a consecutive number.

If a USB device is connected to the R&S EVSF1000 when the screenshot is created, the screenshot is stored there directly as a .PNG file. A dialog box with the default file name is displayed. To change the name of the file on the USB device, click in the name field and overwrite the default name. Note, however, that the file is also stored internally, and the file name remains unchanged. Thus, if you export all screenshots to a USB device later, the same screenshot is stored with the internal name again.

The [Number of Screenshots](#) indicated in the "Setup - Screenshots" window is increased after each new screenshot.

Number of Screenshots

Indicates the number of screenshots currently stored on the instrument.

Storage of screenshots on

Specifies the location of the screenshots to be saved.

"Internal mem"	The screenshots are stored in the internal memory (default setting).
"Internal + USB"	The screenshots are stored in the internal memory and on a connected USB device.
"USBstick"	The screenshots are stored directly on a connected USB device.

Colors for copying to USB

If the screenshots are stored to a USB device, you can specify the colors used for the screenshot.

"Normal"	The screenshot is stored as shown on the screen.
"Converted"	The screenshot is stored with inverted colors, that is: black text on a white background for better legibility on paper.
"Norm + Convert"	Default: two screenshots are stored, one as shown on the screen, one with inverted colors.

Exporting Screenshots to a USB device

All internally stored screenshots on the R&S EVSF1000 are stored as .PNG files in the main directory of the connected USB device. The file name is defined by the following syntax:

```
EVSx_<date>_<time>[_converted].png
```

where the `_converted` suffix is only applied to screenshots with inverted colors.

Deleting all Screenshots Stored on the R&S EVSF1000

All screenshots stored on the R&S EVSF1000 are deleted irrevocably.

Once the screenshots have been stored to an external memory device, you can delete them from the instrument. Otherwise you copy them again each time you create new screenshots and want to store them to a USB device.

8 Common instrument settings

Common instrument settings are applied regardless of which measurement mode is selected.

All common instrument settings can be configured via remote commands (see [Table 1-3](#)) or using a remote keyboard via VNC.



For the mapping of hard- and softkey commands to keyboard commands using VNC, see [Table 1-3](#).



Configuring screenshots is described in [Chapter 7, "Data management"](#), on page 198. Configuring the signal input is described in [Chapter 3.1, "Input signal settings"](#), on page 40.

8.1 Audio output settings

Access VNC: [c]

(Not in "Preset" view.)

Audio output is available at the headphones connector on the front panel of the R&S EVSF1000.

For example, the demodulated identifier in ILS mode is output as a 1020 Hz morse signal.

AF Volume	209
Squelch	209
Demod	210
Audio BW	210
Speaker	210
KB Beep	210

AF Volume

Defines the volume of the AF output at the loudspeaker or the headphones connector. Enter a percentage value (0 % to 100 %).

Remote command:

[SETUP:VOLUME](#) on page 238

Squelch

Defines the level threshold below which the demodulated data is set to 0. This is useful, for example, to avoid demodulation noise during transmission breaks.

This setting is only relevant for numeric measurement modes.

The squelch level is an absolute value.

The current squelch level is indicated numerically on the softkey and graphically on the bargraph indicator.

Remote command:
[SQUELCH](#) on page 239

Demod
 Selects between AM / FM modulation for receiver signals.

Audio BW
 Frequency range to be output to the speaker or headphones.

"Full" Full bandwidth is output

"Voice (def)" Voice frequencies (> 3 kHz) filtered out

"ID Notch" ID frequency (1020 Hz) filtered out

"V/ID Notch" Voice and ID frequencies filtered out

Remote command:
[SETUP:AUDIOBW](#) on page 237

Speaker
 Enables or disables AF output at the loudspeaker on the rear panel of the R&S EVSF1000.

Remote command:
[SETUP:SPEAKER](#) on page 238

KB Beep
 Enables or disables a tone when a key on the keyboard is pressed. This is useful as feedback during operation in a noisy environment.

8.2 Display

Access VNC: [v]
 (Not in "Preset" view.)

Some general settings are available for the VNC display of the R&S EVSF1000.

RX Unit 1 / RX Unit 2	210
Level View	211
Zoom	211



RX Unit 1 / RX Unit 2
 Select the receiver board whose settings and results are displayed. The currently selected receiver board is indicated by a vertical blue line on the softkey.

This setting is only available if a second receiver board is installed (requires the R&S EVSG-B1 Second Signal Processing Unit option, see [Chapter 3.2, "Receiver board"](#), on page 40).

While two different measurements can be performed simultaneously using two receiver boards, the results can only be displayed for one board at a time. Use this function to toggle between the two measurements.

Remote command:

[CH](#) on page 234

Level View

Configure the display of power levels.

"Digits" The level value is displayed numerically, as digits.

"Bargraph" The level value is displayed graphically, as a bargraph.

Remote command:

[SETUP:UNIT:BARGRAPH](#) on page 252

Zoom

This command is available in LOC, GS, VOR and COM modes.

If enabled, the most important measurement parameters are displayed enlarged for better readability.



8.3 LAN (remote) settings

Access VNC: [n] > [F4]

The following settings are required to operate the R&S EVSF1000 in a LAN, for example from a controller PC.

Setup - Remote

TCP/IP DHCP	On ▼
TCP/IP Address	10.255.255.98
TCP/IP Netmask	255.255.255.0
TCP/IP Gateway	10.255.255.1
Hostname	EVSG-900015
VNC Password	Off ▼
Used IP Address	172.23.226.41
Used IP Netmask	255.255.255.128
Used IP Gateway	172.23.226.1

Setup - Remote

TCP/IP DHCP	Off
TCP/IP Address 1	10.255.255.98
TCP/IP Address 2	10.255.255.99
TCP/IP Netmask	255.255.255.0
TCP/IP Gateway	10.255.255.1
Hostname	EVSG_PB
Used IP Address	10.255.255.99
Used IP Netmask	255.255.255.0
Used IP Gateway	10.255.255.1
Active IP	2

Figure 8-1: R&S EVSF1000 with R&S EVSF1-B4 option

TCP/IP DHCP	213
TCP/IP Address	214
TCP/IP Netmask	214
TCP/IP Gateway	214
Hostname	215
VNC Password	215
Used IP Address	215
Used IP Netmask	215
Used IP Gateway	215

TCP/IP DHCP

If the network supports dynamic TCP/IP configuration using the Dynamic Host Configuration Protocol (DHCP), all address information is assigned to the instrument automatically. In this case, the TCP/IP parameters are not editable. The currently used settings are indicated as [Used IP Address](#), [Used IP Netmask](#), [Used IP Gateway](#).

If the network does not support DHCP, you must set the addresses manually.

By default, the instrument is configured to use a static IP address, that is: DHCP is disabled.

If DHCP is disabled, remote devices must use an IP address within the same [TCP/IP Netmask](#) as the instrument. (Usually, that means only the last number of the IP address differs.)

To toggle this setting via the remote keyboard, press the [Tab] key.

The DHCP setting is shown on the instrument's mini display (see [Chapter 1.6.1, "Basic configuration and status display"](#), on page 27).

Note: When a DHCP server is used, a new IP address can be assigned each time you restart the instrument. You must determine this address on the instrument itself. Thus, when using a DHCP server, it is recommended that you use the permanent instrument name, which determines the address via the DNS server, if available (see ["Hostname"](#) on page 215).

TCP/IP Address

Unique address of the instrument in the network. The currently assigned IP address and submask are indicated next to the setting. The default address is 10.255.255.98.

The IP address consists of four number blocks separated by dots. Each block contains values between 0 and 255.

To change the IP address via the remote keyboard, press the [INS] key and enter the new address.

The IP address is shown on the instrument's mini display (see [Chapter 1.6.1, "Basic configuration and status display"](#), on page 27).

If the R&S EVSF1-B4 option is installed, you can configure two different IP addresses. Depending on the "IP-Address Select" input, one or the other is used (see [Chapter 1.5.2.11, "IP-Address select"](#), on page 26). The mini display indicates the currently used address.

Example:

172.17.40.139

Example: With R&S EVSF1-B4 option

With the configuration shown in [Figure 8-1](#), if the "IP-Address Select" (pin 3) of the ARINC connector is connected to ground, the address configured as "TCP/IP Address 2" is used: 10.255.255.99.

TCP/IP Netmask

The subnet mask consists of four number blocks separated by dots. Each block contains values between 0 and 255.

Example:

255.255.255.0

TCP/IP Gateway

The gateway consists of four number blocks separated by dots. Each block contains values between 0 and 255.

Example:

192.168.1.1

This setting is only required if the R&S EVSF1000 is installed in a network and the instrument needs to communicate with other connected devices. For simple 1:1 connections between the instrument and control PC, the setting is irrelevant.

Hostname

Unique instrument name in the network, as an alternative to the unique IP address.

Each instrument is delivered with an assigned instrument name, but this name can be changed.

The default instrument name is a non-case-sensitive string with the following syntax:

EVSF<serial_number>

For example, EVSF1000-123456.

For information on determining the serial number, see [Chapter 1.5.2.12, "Device ID"](#), on page 26.

Use the keypad to enter the name, see [Table 1-4](#).

Remote command:

[GETHOSTNAME](#) on page 245

VNC Password

Enables or disables the requirement of a password to access the instrument remotely via VNC.

After enabling the use of a password, you must reboot the R&S EVSF1000 before it becomes active.

The password for VNC access is *instrument*. It cannot be changed.

Used IP Address

If [TCP/IP DHCP](#) is activated, the assigned IP address is displayed.

Used IP Netmask

If [TCP/IP DHCP](#) is activated, the assigned netmask is displayed.

Used IP Gateway


If [TCP/IP DHCP](#) is activated, the assigned gateway address is displayed.

8.4 Data link (Wi-Fi) settings

Access VNC: [n] > [F5]

The R&S EVSF1000 can be equipped with an optional R&S EVSD1-Z5 Data-link-module (Wi-Fi). Thus, you can configure the R&S EVSF1000 as a Wi-Fi access point for wireless communication from a remote device.

The following settings configure the R&S EVSF1000 as a Wi-Fi access point.



Wi-Fi.....216

SSID.....216

WPA-PSK Key.....217

Channel.....217

Wi-Fi Speed.....217

Country.....217

IP.....217

Netmask.....218

Gateway.....218

DHCP server.....218

Status.....218

Wi-Fi

Enables or disables a data connection via the optional Wi-Fi interface.

Remote command:

WIFI:ONOFF on page 248

SSID

Service set identifier, the name of the Wi-Fi. The default name is EVSF<serial number>.

Note: Enter the ID using the (number) keypad on the external keyboard as described in "Entering numbers and (special) characters via the keypad" on page 34.

Remote command:

WIFI:SSID on page 247

WPA-PSK Key

Wi-Fi password. Consists of minimum 8 characters.

The default Wi-Fi password is RS<serial_number>, e.g. RS123456.

For information on determining the serial number, see [Chapter 1.5.2.12, "Device ID"](#), on page 26.

Note: Enter the key using the (number) keypad on the external keyboard as described in ["Entering numbers and \(special\) characters via the keypad"](#) on page 34.

Remote command:

[WIFI:WPAPSK](#) on page 247

Channel

Wi-Fi channel.

The frequency range and the supported Wi-Fi standard for the selected channel are indicated for reference.

Supported channels:

1,2,3,4,5,6,7,8,9,10,11,12,13,36,40, 44, 48, 52, 56, 60,64, 100, 104, 108, 112, 116, 120, 124,128,132, 136,140,149,153,157,161,165

Default: 1

Remote command:

[WIFI:CHANNEL](#) on page 248

Wi-Fi Speed

Determines the used Wi-Fi data rate.

"Low" (Default:) Uses 20 MHz bandwidth. Data transfer is less susceptible to distortion.

"High" Uses 80 MHz bandwidth, if available. Guard interval is reduced to increase the data rate. Data transfer becomes more susceptible to distortion.

Remote command:

[WIFI:SPEED](#) on page 249

Country

Country code of the country the drone is operated in. National legislations support different channels, bandwidths etc. for Wi-Fi communication. If you select a channel or bandwidth that is not supported by the selected country, an error message is displayed in the [Status](#) information.

Remote command:

[WIFI:COUNTRY](#) on page 249

IP

Unique address of the instrument in the network. The currently assigned IP address and submask are indicated next to the setting. The default address is 192.168.1.1.

The IP address consists of four number blocks separated by dots. Each block contains values between 0 and 255.

To change the IP address via the remote keyboard, press the [INS] key and enter the new address.

Example:

172.17.40.139

Remote command:

WIFI:IP on page 247

Netmask

The subnet mask consists of four number blocks separated by dots. Each block contains values between 0 and 255.

Example:

255.255.255.0

Remote command:

WIFI:NETMASK on page 247

Gateway

The gateway consists of four number blocks separated by dots. Each block contains values between 0 and 255.

Example:

192.168.1.1

Remote command:

WIFI:GATEWAY on page 248

DHCP server

Indicates that a DHCP server is used. The IP address and subnet mask of the connected devices are obtained automatically from the DHCP server.

Status

Indicates the status of the Wi-Fi connection.


"ON"	Wi-Fi access point is running. In addition, the following information is indicated: "CH:"<used channel number> "WIDTH:"<used channel bandwidth> The used channel number can differ from the selected Channel, if a signal is detected elsewhere (dynamic frequency selection).
"OFF"	Wi-Fi access point not (yet) running successfully. Additional information indicates the reason for the error. • None: Wi-Fi is disabled • "CONFIG": Configuration is in progress • "NO HW": Wi-Fi adapter not installed or not supported on instrument • "AP ERROR": Access point could not be started, e.g. because selected Channel is not supported.

Remote command:
WIFI:STATUS on page 250

8.5 System settings

Access VNC: [n] > [F6]

The following settings configure the general instrument system.



Date.....219

Time..... 219

Boot on Power Up..... 220

Flash size / Flash used..... 220

Date
Sets the date of the internal clock in the format dd.mm.yyyy.

Example:
10.05.2017

Remote command:
SETUP:DATE on page 251

Time
Sets the time of the internal clock in the format hh.mm.ss.

Example:
12.08.23

Remote command:

[SETUP:TIME](#) on page 251

Boot on Power Up

Automatically switches on the R&S EVSF1000 when it is connected to an external power supply (if not in operation already). This setting cannot be changed on the R&S EVSF1000.

Remote command:

[SETUP:BOOTONPOWERUP](#) on page 250

Flash size / Flash used

Indicates the size of the flash memory in the R&S EVSF1000, and the percentage currently in use.

8.6 Instrument configuration and operating status settings

The following settings concern the instrument operating status, and hardware and software configuration.

Auto-Calibration (Cal)	220
Error Log	221
L Copy to USB	222
L Delete all error messages	222
HW Status	222
Installed Options	223
Inventory	224
L SW Update	225

Auto-Calibration (Cal)

Access VNC: [n] > [F8] > [F1]

Autocalibration corrects changes in the attenuation characteristics of the internal RF signal paths (on both receiver boards, if available) using an internal calibration signal. These changes can occur due to the aging process or temperature drifts. The calibration optimizes the accuracy of the level measurements.

The "Setup - CAL" display shows the status for each calibration step for the most recent calibration. The first line of the result table indicates the date and time of the auto-calibration, and the temperature during the autocalibration.

Note: Start the instrument at least 15 minutes before starting autocalibration to ensure that the instrument has reached its operating temperature (for details, refer to the data sheet).

During the auto-calibration procedure, do not apply any input signal to the R&S EVSF1000.

To start the auto-calibration, select "Start Autocal " and press the [Enter] key.

The auto-calibration procedure is ready after a few minutes and in the result table, all entries must have the status "OK".

	RX1	RX2
Start Autocal	01.06.2017 09:13:25 34.0°C	
75MHz Low Noise	OK	
75MHz Norm	OK	
75MHz Low Dist	OK	
108MHz Low Noise	OK	
108MHz Norm	OK	
108MHz Low Dist	OK	
118MHz Low Noise	OK	
118MHz Norm	OK	
118MHz Low Dist	OK	
220MHz Low Noise	OK	
220MHz Norm	OK	
220MHz Low Dist	OK	
Bypass Low Noise	OK	
Bypass Norm	OK	

Figure 8-2: Successful auto-calibration

If an error occurs during the auto-calibration process, switch the instrument off and on again and repeat the auto-calibration process. If the error still exists, contact the Rohde & Schwarz service.

It is recommended that you perform an autocalibration every 2 months or if the difference of the environment temperature changes by more than 10 °C.

Remote command:

[AUTOKALSTATUS](#) on page 257

[KALSCREEN](#) on page 257

[STARTKAL](#) on page 257

[GETKALSTATUS](#) on page 257

Error Log

Access VNC: [n] > [F8] > [F2]

The last 100 instrument status messages or errors displayed in the status bar during operation of the R&S EVSF1000 are also stored in an error log file on the instrument. Thus, if problems occur, you can check the error log for irregular behavior or failures.

Setup - Error Log	
Copy to USB...	Delete all error messages...
10.07.2020 14:03:35	C:1 TEST ERROR MESSAGE NR. 03
10.07.2020 14:03:22	C:1 TEST ERROR MESSAGE NR. 02
10.07.2020 14:02:59	C:1 TEST ERROR MESSAGE NR. 01

Remote command:

[GETERRORLOG](#) on page 255

Copy to USB ← Error Log

Copies all entries in the error log to a text file on a connected USB device. The default file name is `EVSx_errorlog_<datetime>.txt`.

This file is useful if problems occur and you need support. Send the copied error file to the Rohde & Schwarz support center for troubleshooting.

Delete all error messages ← Error Log

Deletes all entries in the error log irrevocably.

Remote command:

[CLEARERRORLOG](#) on page 255

HW Status

Access VNC: [n] > [F8] > [F3]

The hardware status overview provides information on the current operating status of the individual hardware components in the R&S EVSF1000, such as test voltages and temperatures.

The values are provided individually for RX1 and RX2 boards.

Setup - HW Status		
RX Board	RX1	RX2
IF2_MINUS_5V	-4.98V OK	
IF2_5V	4.92V OK	
RF_MINUS_5V6	-5.46V OK	
RF_5V6	5.63V OK	
LO1_LEVEL	2.06V OK	
LO1_PRETUNE	10.13V OK	
LO1_6V5	6.85V OK	
RFDIV_3V3	3.28V OK	
LO3_5V	4.96V OK	
DDS_3V3	3.31V OK	
IF1_AMP2	5.56V OK	
IF1_AMP1	5.49V OK	
VV_SUPPL	5.42V OK	
VV_BYP_ATT	2.50V OK	
RAND_SW	2.50V OK	

The test voltages are measured continuously, internally, and checked against defined limit values. If one of the test voltages exceeds the tolerance for more than 10 s, the following measures are taken by the R&S EVSF1000:

- An error message is created in the error log (see ["Error Log"](#) on page 221).
- The measured test voltage is indicated in red.
- "UNCAL" is displayed in the measurement window, indicating the measured values are possibly invalid.

The "UNCAL" message is displayed until you switch off the instrument and switch it back on again. If the message appears again, contact the Rohde & Schwarz support center. See [Chapter 12, "Contacting customer support"](#), on page 376.

Remote command:

[GETUNCAL](#) on page 230

[BI?](#) on page 255

[GETTEMP](#) on page 255

Installed Options

Access VNC: [n] > [F8] > [F4]

Displays a table with the currently installed option keys.

For all purchased R&S EVSF1000 options, a license key is provided by Rohde & Schwarz.

Setup - Options		
Designation	License Type	Validity
Activate new...		
Install License.xml		
K1-ILS CRS/CLR An...	Permanent	unlimited
K2-VOR Analysis	Permanent	unlimited
K3-MB Analysis	Permanent	unlimited
K6-COM Analysis	Permanent	unlimited
K10-RF Spectrum ...	Permanent	unlimited
K11-AF Spectrum ...	Permanent	unlimited

Allow you to start installation of a License manually.

To activate a new option key, select "Activate new..." and enter the number of the license key.

Alternatively, select "Install license.xml" to install a license from the main directory of a connected USB device.

The following information is displayed in the Options table:

"Designation" Specifies the name of the license key.

"License Type" The license type can be permanent or limited to a temporary duration.

"Validity" For temporary licenses, the validity is indicated. If the expiry date has passed, the license becomes invalid.

Additional information on the selected option is displayed below the table.

Remote command:

[GETOPTIONS](#) on page 255

Inventory

Access VNC: [n] > [F5]

The hardware and software inventory list provides information on the hardware version of the instrument (integrated modules, options etc.) and on the currently installed software versions. Additionally installed software options are provided in the [Installed Options](#) list.

For each piece of hardware, the identification number, serial number and revision are provided in the inventory list. For each software item, the installed version number is provided.

Setup - Inventory			
Hardware	Ident No.	Revision	Serial No.
EVSG	1329.8009.02	01.00	900015
Datasheet	01.00		
EVSG_K	1329.8009K02	01.00	900015
MAINBOARD	1329.8050.02	05.00	101018
RX_BOARD	1329.8015.02	04.08	101006
Battery Board	1329.8121.02	03.00	101059
Software	Ident No.	Version	
Release	1329.8650	01.40 BETA12	SW Update
EVSG SW		01.38I	
Build:	Jul 10 2020 11:44:00		
ILS/VOR FPGA Version		00.49.08	
GBAS FPGA Version		00.09.01*	

Remote command:

[INV?](#) on page 256

[VER?](#) on page 256

SW Update ← Inventory

Updates the R&S EVSF1000 software using an update file on a connected USB device.

The R&S EVSF1000 automatically searches the USB device for new software. The update file has the extension `.evs` and must be located in the main directory of the USB device. The search can take a few seconds.

When the software has been found, press the [ENTER] key to confirm the message to install the software.

Note: Never remove the USB device or switch off the instrument during a software update. Otherwise, an undefined software state can be the result.

8.7 GNSS configuration

Access VNC: [n] > [F8] > [F6]

If a GNSS receiver is connected to the R&S EVSF1000, the basic GNSS receiver settings are displayed here.

Setup - GPS / GNSS	
Baudrate	115200
GPS-Delay	0 ms
PPS-Sync	Off
Interface	USB u-blox
IP Address	127.0.0.1
IP Port	8091
Exp.Format	Min
Latitude	50° 38.78580000' N
Longitude	07° 01.00859000' E
Altitude	192.10
Speed	0.14 knots 0.26 km/h
Time	09:24:24.600
Date	24.01.2023
Status	GPS, 8 Sats.
Incoming	GPGGA,092424.60,5038.78581,N,00701.00857,E,1,08,1.58,192.1,M,47.7
GPRMC	GPRMC,092424.60,A,5038.78581,N,00701.00857,E,0.142,43.16,240123,,
GPGGA	GPGGA,092424.60,5038.78581,N,00701.00857,E,1,08,1.58,192.1,M,47.7
GPGSA	

Rec List 1 Size 2239 Local Mains 2/2 ▼

Baudrate.....	226
GPS-Delay.....	226
PPS-Sync.....	226
Interface.....	227
Exp. Format.....	227

Baudrate

Specifies the baudrate of the GNSS signal. The following values are supported:

4800 | 9600 | 19200 | 38400 | 57600 | 115200 | 230400

Remote command:

[SETUP:GPS_BAUDRATE](#) on page 242

GPS-Delay

Specifies a delay between the received GNSS time and the actual time. This value corrects the delay of the transmission of GNSS coordinates via a serial interface. Supported values are from -300 ms to +1000 ms.

Remote command:

[SETUP:SETGPSDELAY](#) on page 243

PPS-Sync

Activates/deactivates synchronization between the GNSS time in the stored data sets and the PPS signal provided by the GNSS receiver.

Note: PPS input recommended. We strongly recommend that you connect the PPS signal of the GNSS receiver to the "PPS In" connector of the R&S EVSF1000.

Although it is possible to store data on the R&S EVSF1000 without the PPS signal connected, the stored data can be assigned to the actual GNSS time incorrectly. For details, see [Chapter 7.2.1, "GNSS data synchronization"](#), on page 201.

"OFF"	No PPS synchronization is performed.
"PPS_IN rise"	Stored GNSS time is synchronized to the rising edge of the incoming PPS signal.
"PPS_IN fall"	Stored GNSS time is synchronized to the falling edge of the incoming PPS signal.
"RS232 rise"	Stored GNSS time is synchronized to the rising edge of the incoming GNSS signal.
"RS232 fall"	Stored GNSS time is synchronized to the falling edge of the incoming GNSS signal.

Remote command:

[SETUP:PPS_SYNC](#) on page 243

Interface

Determines the interface used to connect a GNSS receiver.

"RS-232"	(See Chapter 1.5.2.4, "RS-232 GPS" , on page 23)
"USB"	Chapter 1.5.1.2, "USB connectors" , on page 20
"USB u-blox"	Chapter 1.5.1.2, "USB connectors" , on page 20
"TCP/IP"	GNSS data provided from specified IP address. Define the "IP Address" and "IP Port" at which the signal is provided.

Remote command:

[SETUP:SETGPSINTERFACE](#) on page 241

Exp. Format

Export format for the GNSS data output by the data logger.

"Min"	(Default:) Minutes, seconds, degrees
"Decimal"	Decimal format

9 Remote commands

Using the LAN connection (Fast Ethernet), you can operate nearly all device functions and transfer measurement data remotely from a PC or network.

Connect a terminal client, e.g. "putty" (<https://www.putty.org>) to the R&S EVSF1000 using the TCP port 8000. The required commands are simple text commands, not SCPI-conform. Use any line-based command tool, such as telnet, to send commands to the R&S EVSF1000.



Only one remote session can be active. A new attempt to establish a connection disconnects the current active session.

Channel addressing

To address one of two independent RX boards by remote control, the R&S EVSF1000 uses *Direct Addressing*.

- **Direct Addressing**
To address an RX board directly, any command can be preceded by the prefix @1 or @2 followed by the command.
Example: Set frequency of RX board 1
@1 RF108100
Example: Get DDM from RX board 2
@2 DDO

9.1 Common instrument and measurement setup

The following commands are required to configure general instrument and measurement settings that are independent of the measurement mode.

• Common measurement settings	229
• Signal input	234
• Trigger settings	235
• Baseband input	235
• Audio, demodulation and output configuration	237
• GNSS data	239
• Network settings and remote operation	245
• Wi-Fi commands	246
• System settings	250
• Result display settings	251
• Retrieving instrument information	254
• Calibration	257
• Deprecated commands	258

9.1.1 Common measurement settings

The following commands are required for all measurements.

GETMEAS.....	229
GETMDEF.....	230
GETUNCAL.....	230
LA?.....	231
MEASTIME?.....	231
MEASTIME.....	231
RF?.....	231
RF.....	231
RFCH.....	231
SETATTMODE.....	232
SETUP:DEMODAMFM.....	232
SETUP:DEMOD_OUT_AGC.....	233
SETUP:DEMOD_OUT_COUPLING.....	233
SETUP:EXTERNALATT_RX1?.....	233
SETUP:EXTERNALATT_RX1.....	233
SETUP:EXTERNALATT_RX2?.....	233
SETUP:EXTERNALATT_RX2.....	233

GETMEAS <result type>,<RX-board>

This command outputs the current measurement result for one or both RX-boards. Several measurement result types are defined.

Parameters:

<result type> Outputs the measurement result as one of the listed types.

FULL

EVS300 compatibility mode

ALL

All values of the current measurement mode are sent as comma-separated text, using actual units.

MEDIUM

A fixed selection of parameters is exported.

SHORT

A short, fixed selection of parameters is exported.

<RX-Board> Output measurement result for the selected RX board.

1

RX board 1 selected

2

RX board 2 selected

1+2

Both RX boards selected

Return values:

<results> Measurement result.

<State> **READY.**
The command was executed successfully.

Example: GETMEAS FULL, 1+2

GETMDEF <ParamSel>,<RX-board>

This command outputs the header columns for data provided by [GETMEAS](#).

Parameters:

<ParamSel> Determines which parameter selection is output.

FULL
EVS300 compatibility mode

ALL
All values of the current measurement mode are sent as comma-separated text, using actual units.

MEDIUM
A fixed selection of parameters is exported.

SHORT
A short, fixed selection of parameters is exported.

<RX-Board> Selects the RX board for which results are exported.

1
RX board 1 selected

2
RX board 2 selected

1+2
Both RX boards selected

Return values:

<Results> Comma-separated list of header data for the selected results.

<State> **READY.**
The command was executed successfully.

GETUNCAL <State>

Indicates whether an **UNCAL** condition has occurred on the instrument. This condition either indicates the calibration data is invalid, or it is caused by a hardware error.

The "UNCAL" condition remains active until you switch off the instrument and switch it back on again. If the message appears again, contact the Rohde & Schwarz support center. See [Chapter 12, "Contacting customer support"](#), on page 376.

Parameters:

<State> **OK**
Instrument is calibrated correctly and no errors occurred.

UNCAL
Instrument calibration invalid or an error has occurred.

Manual operation: See ["HW Status"](#) on page 222

LA?

This command queries the RF signal level in numeric measurement modes.

Return values:

<signal level> RF signal level
Default unit: dBm

Usage: Query only

MEASTIME?**MEASTIME** <Time>

This command gets or sets the measurement time for "ILS LOC", "ILS GP", "ILS MB", "VOR" and "COM" mode.

Parameters:

<Time> Measurement time
Default unit: ms

Return values:

<State> **READY.**
The command was executed successfully.

RF?**RF**

This command sets RF frequency. All values are interpreted with one digit behind the decimal point, for example, RF 108700.5 in numeric measurement modes.

Parameters:

<freq> RF frequency
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Freq"](#) on page 68
See ["Freq"](#) on page 83
See ["Freq"](#) on page 112
See ["Freq"](#) on page 122

RFCH <Channel>

This command sets the receiver frequency channel on the active receiver board according to the ICAO frequency list, or returns the currently defined channel.

Parameters:

<Channel> The specified ICAO-channel for the measurement. See [Chapter A, "ILS channel frequency list"](#), on page 377.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["CH"](#) on page 67

SETATTMODE

This command selects the attenuation of the active mode ("ILS LOC", "ILS GP", "ILS MB", "VOR" or "COM" mode).

Parameters:

<Attenuation>

Select the attenuation type from the listed ones.

AUTO

The RF attenuation mode is selected automatically.

LN

(Low Noise) 15 dB pre-amplification

Provides a high sensitivity. Suitable when scanning the area for distant signals.

NORM

0 dB

Provides a normal sensitivity.

LD

(Low Dist) 15 dB attenuation

Provides a low sensitivity. Suitable when analyzing a nearby signal, to avoid overload due to high-level signals.

Return values:

<State>

READY.

Command was executed successfully.

Manual operation: See ["RF Att"](#) on page 68
 See ["RF Mode"](#) on page 69
 See ["RF Att"](#) on page 122
 See ["RF Mode"](#) on page 123

SETUP:DEMAMFM <Mode>

Gets or sets the audio demodulation mode.

Parameters:

<Mode>

AM | FM

Return values:

<State>

READY.

The command was executed successfully.

SETUP:DEMOD_OUT_AGC <Mode>

Determines whether the level for demodulation output is automatically corrected using the automatic gain control (AGC).

Parameters:

<Mode> OFF | ON

Return values:

<State> **READY.**
The command was executed successfully.

SETUP:DEMOD_OUT_COUPLING <Mode>

Gets or sets the coupling type for Demodulation-Out mode.

Parameters:

<Mode> AC | DC

Return values:

<State> **READY.**
The command was executed successfully.

SETUP:EXTERNALATT_RX1?**SETUP:EXTERNALATT_RX1 <Attenuation>**

Gets or sets the external attenuation of "RX1 IN".

Parameters:

<Attenuation> External attenuation
Default unit: dB

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Transducer Correction"](#) on page 69

SETUP:EXTERNALATT_RX2?**SETUP:EXTERNALATT_RX2 <Attenuation>**

Gets or sets the external attenuation of "RX2 IN".

Parameters:

<Attenuation> External attenuation
Default unit: dB

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Transducer Correction"](#) on page 69

9.1.2 Signal input

The following commands are required to configure the signal input.

CH?	234
CH	234
GETNRPTYPE	234
GETNRPPOW	234
SETUP:INPUT?	234
SETUP:INPUT	234

CH?

CH <RX board>

This command selects the active RX-board.

Parameters:

<RX board>	1
	Select the RX-board 1.
	2
	Select the RX-board 2.

Return values:

<State>	READY.
	The command was executed successfully.

Manual operation: See ["RX Unit 1 / RX Unit 2"](#) on page 210

GETNRPTYPE

Gets the type of a connected NRP power sensor.

Return values:

<String>	Type of NRP power sensor.
----------	---------------------------

GETNRPPOW

Gets the current NRP power sensor level.

Return values:

<level>	Power sensor level
	Default unit: dBm

SETUP:INPUT?

SETUP:INPUT <Channel>,<Input>

This command selects the input source for channel 1 and 2.

Parameters:

<Channel>	1
	Selects channel 1

	2 Selects channel 2
<Input>	RF RF input at the front side
	BB Baseband input at the rear side Baseband input is only available if the R&S EVSF1-B4 option (ARINC connector) is installed.
Return values:	
<State>	READY. The command was executed successfully.
Example:	SETUP:INPUT 1, RF
Manual operation:	See "Input RF/LF" on page 63

9.1.3 Trigger settings

The following command is required to configure basic trigger settings.

PPSSMA_TRIG_SOURCE?.....235

PPSSMA_TRIG_SOURCE? <Source>

Gets or sets the external trigger event source for "ILS LOC", "ILS GP", "ILS MB", "VOR" and "COM" modes, or defines the PPS synchronization source.

Return values:

<Source>	PPS SMA Signal provided at the PPS In connector
	PPS GPS Signal provided at the RS232-GPS or GNSS connector
<State>	READY. The command was executed successfully.

Manual operation: See "Input" on page 205

9.1.4 Baseband input

The following commands are required to configure baseband input.

They are only available if options R&S EVSF1-B4 and R&S EVSG1-K7 LF-Analysis are installed.

SETUP:BB_IN_COUPL?	236
SETUP:BB_IN_COUPL	236
SETUP:BB_IN_FACTOR?	236
SETUP:BB_IN_FACTOR	236

SETUP:BB_IN_RANGE?.....	236
SETUP:BB_IN_RANGE.....	236

SETUP:BB_IN_COUPL?**SETUP:BB_IN_COUPL** <Coupling>

Gets or sets the coupling for the baseband (LF In) input.

Parameters:

<Coupling> **<AC | DC>**
 Coupling for baseband input.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Coupling](#)" on page 72**SETUP:BB_IN_FACTOR? <Value>****SETUP:BB_IN_FACTOR** <Value>

Gets or sets a compensation factor for the baseband (LF In) input power.

Parameters:

<Value> Factor to be applied to the measured LF power.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[LF In Factor](#)" on page 73**SETUP:BB_IN_RANGE?****SETUP:BB_IN_RANGE** <Sensitivity>

Gets or sets sensitivity range for the baseband (LF In) input.

Parameters:

<Sensitivity> **100_MV**
 Sets 100 mV.

5V
 Sets 5 V.

1V
 Sets 1 V.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Range](#)" on page 72

9.1.5 Audio, demodulation and output configuration

The following commands are required to configure various types of output.

SETUP:AUDIOBW.....	237
SETUP:DDM_RANGE_LLZ.....	237
SETUP:DDM_RANGE_GS.....	238
SETUP:SPEAKER.....	238
SETUP:VOLUME.....	238
SQUELCH?.....	239
SQUELCH.....	239

SETUP:AUDIOBW <output volume>

This command specifies the bandwidth for audio output.

Parameters:

<output volume>	FULL VOICE ID_NOTCH V_ID_NOTCH
	FULL
	Full bandwidth is output
	VOICE
	Voice frequencies (> 3 kHz) output
	ID_NOTCH
	ID frequency (1020 Hz) output
	V_ID_NOTCH
	Voice and ID frequencies output
	Range: 0 to 100
	*RST: VOICE
	Default unit: %

Return values:

<State>	READY.
	The command was executed successfully.

Manual operation: See "Audio BW" on page 210

SETUP:DDM_RANGE_LLZ <Channel>,<Range>

This command selects a predefined DDM range. This command is active for analog output in ILS localizer mode.

Parameters:

<Channel>	1
	Selects input source for channel 1.
	2
	Selects input source for channel 2.
<Range>	Range: 1 to 4

Return values:

<State> **READY.**
The command was executed successfully.

SETUP:DDM_RANGE_GS <Channel>,<Range>

This command selects a predefined DDM range. The command is active for analog output in ILS glidepath mode.

Parameters:

<Channel> **1**
Selects input source for channel 1.

2
Selects input source for channel 2.

<Range> Range: 1 to 4

Return values:

<State> **READY.**
The command was executed successfully.

SETUP:SPEAKER <State>

This command activates/deactivates the speaker.

The speaker function is not available for the R&S EVSF1000

Parameters:

<State> ON | OFF

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Speaker](#)" on page 210

SETUP:VOLUME <output volume>

This command specifies the AF output volume.

Parameters:

<output volume> Range: 0 to 100
Default unit: %

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[AF Volume](#)" on page 209

SQUELCH?**SQUELCH** <Level>

This command gets or sets the squelch level of the active mode ("ILS LOC", "ILS GP", "ILS MB", "VOR" or "COM" mode).

Parameters:

<Level> Squelch level of active mode
 Default unit: dBm

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Squelch"](#) on page 209

9.1.6 GNSS data

The following commands are required to configure and retrieve GNSS data.

GETGPSGPBOD.....	240
GETGPSGPGA.....	240
GETGPSGPGLL.....	240
GETGPSGPHDT.....	240
GETGPSGPRMC.....	240
GETGPSGPGSA.....	240
GETGPSGPGSV.....	240
GETGPSGPTRF.....	241
GETGPSGPVBW.....	241
GETGPSGPVTG.....	241
GETGPSGPXTE.....	241
GETGPSGPZDA.....	241
SETUP:SETGPSINTERFACE.....	241
GETGPSUNDULATION.....	242
SETUP:GPS_BAUDRATE?.....	242
SETUP:GPS_BAUDRATE.....	242
SETUP:GPS_IP_AD.....	242
SETUP:GPS_IP_PORT.....	242
SETUP:SETGPSDELAY.....	243
SETUP:PPS_SYNC?.....	243
SETUP:PPS_SYNC.....	243
SETUP:GPSREF.....	244
SETUP:REFLAT?.....	244
SETUP:REFLAT.....	244
SETUP:REFLONG?.....	244
SETUP:REFLONG.....	244
SETUP:TIMESYNC?.....	244
SETUP:TIMESYNC.....	244

GETGPSGPBOD

This command requests the last incoming GPBOD message from the GNSS receiver.

Return values:

<message> The last incoming GPBOD message.

GETGPSGPGGA

This command requests the last incoming GPGGA message from the GNSS receiver.

Parameters:

<message> The last incoming GPGGA message.

GETGPSGPGLL

This command requests the last incoming GPGLL message from the GNSS receiver.

Return values:

<message> The last incoming GPGLL message.

GETGPSGPHDT

This command requests the last incoming GPHDT message from the GNSS receiver.

Return values:

<message> The last incoming GPHDT message.

GETGPSGPRMC

This command requests the last incoming GPRMC message from the GNSS receiver.

Parameters:

<message> The last incoming GPRMC message.

GETGPSGPGSA

This command requests the last incoming GPGSA message from the GNSS receiver.

Return values:

<message> The last incoming GPGSA message.

GETGPSGPGSV

This command requests the last incoming GPGSV message from the GNSS receiver.

Return values:

<message> The last incoming GPGSV message.

GETGPSGPTRF

This command requests the last incoming GPTRF message from the GNSS receiver.

Return values:

<message> The last incoming GPTRF message.

GETGPSGPVBW

This command requests the last incoming GPVBW message from the GNSS receiver.

Return values:

<message> The last incoming GPVBW message.

GETGPSGPVTG

This command requests the last incoming GPVTG message from the GNSS receiver.

Return values:

<message> The last incoming GPVTG message.

GETGPSGPXTE

This command requests the last incoming GPXTE message from the GNSS receiver.

Return values:

<message> The last incoming GPXTE message.

GETGPSGPZDA

This command requires the last incoming GPZDA message from the GNSS receiver.

Return values:

<message> The last incoming GPZDA message.

SETUP:SETGPSINTERFACE <Connector>

Determines the interface used to connect a GNSS receiver.

Parameters:

<Connector>	RS_232 RS-232 interface
	USB USB interface
	USB_UBLOX USB u-blox interface
	TCPIP GNSS data provided from IP address specified using SETUP:GPS_IP_AD and SETUP:GPS_IP_PORT .

*RST: RS_232

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Interface"](#) on page 227

GETGPSUNDULATION

Gets the undulation.

Return values:

<string>

SETUP:GPS_BAUDRATE? <Baudrate>**SETUP:GPS_BAUDRATE** <Baudrate>

This command sets or returns the baud rate.

NOTE: Make sure to use a valid GNSS baud rate.

Parameters:

<Baudrate>

4800 | 9600 | 19200 | 38400 | 57600 | 115200 | 230400

Possible baud rates

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Baudrate"](#) on page 226

SETUP:GPS_IP_AD <IPAddress>

Defines the IP address of a GNSS receiver connected via TCP/IP.

Parameters:

<IPAddress>

TCP/IP address between 0.0.0.0 and 0.255.255.255

Return values:

<State>

READY.

The command was executed successfully.

Example:

SETUP:GPS_IP_AD 10.0.2.166

SETUP:GPS_IP_PORT <IPPort>

Defines the IP port of a GNSS receiver connected via TCP/IP.

Parameters:

<IPPort>

TCP/IP port

Return values:

<State> **READY.**
The command was executed successfully.

Example: `SETUP:GPS_IP_PORT 8000`

SETUP:SETGPSDELAY <Delay>

This command specifies the GNSS delay compensation.

NOTE: This setting has no effect when using PPS synchronization.

Parameters:

<Delay> Specify the delay compensation. Default is 100 ms.
Range: -500 to +500
Default unit: ms

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["GPS-Delay"](#) on page 226

SETUP:PPS_SYNC?**SETUP:PPS_SYNC <synchronization>**

Gets or sets the PPS synchronization for the instrument.

Parameters:

<Synchronization> **OFF**
No PPS synchronization is performed.

PPS_IN_RISE
Stored GNSS time is synchronized to the rising edge of the incoming PPS signal.

PPS_IN_FALL
Stored GNSS time is synchronized to the falling edge of the incoming PPS signal.

RS232_RISE
Stored GNSS time is synchronized to the rising edge of the incoming GNSS signal.

RS232_FALL
Stored GNSS time is synchronized to the falling edge of the incoming GNSS signal.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["PPS-Sync"](#) on page 226

SETUP:GPSREF <Latitude>,<Longitude>

By default, the reference point for GNSS information is automatically taken from the position of the built-in GNSS antenna of the R&S EVSF1000. However, it can be changed manually to any other position using this command.

Parameters:

<Latitude>	<degrees><minutes><direction> Latitude of the reference point in degrees, minutes (decimal format) and direction (S N)
<Longitude>	<degrees><minutes><direction> Longitude of the reference point in degrees, minutes (decimal format) and direction (W E)

Example: `SETUP:GPSREF 89°44.123456789S,23°55.123456789S`

SETUP:REFLAT?**SETUP:REFLAT** <Latitude>

Gets or sets the latitude of the GNSS reference point.

Parameters:

<Latitude>	GNSS reference point latitude
------------	-------------------------------

Return values:

<State>	READY. The command was executed successfully.
---------	---

SETUP:REFLONG?**SETUP:REFLONG** <Longitude>

Gets or sets the longitude of the GNSS reference point.

Parameters:

<Longitude>	GNSS reference point longitude.
-------------	---------------------------------

Return values:

<State>	READY. The command was executed successfully.
---------	---

SETUP:TIMESYNC?**SETUP:TIMESYNC** <Source>

Defines or queries the time source with which the R&S EVSF1000 clock is synchronized. If the R&S EVSF1000 clock differs from the selected synchronization source time by more than 1000 ms, the R&S EVSF1000 clock is adjusted accordingly.

Parameters:

<Source>	OFF No synchronization is performed for the internal R&S EVSF1000 clock.
----------	--

GPS
Synchronization with a connected GNSS (see the main R&S EVSF1000 User Manual).

Example: `SETUP:TIMESYNC OFF`

9.1.7 Network settings and remote operation

The following commands are required to configure network settings and remote operation.

GETHOSTNAME	245
LO	245
MLOC	245
RLC	246
REMOTELOCK	246
SETUP:NTPSERVER?	246
SETUP:NTPSERVER	246

GETHOSTNAME

This command returns the host name of the instrument.

Return values:
<hostname>

Manual operation: See "[Hostname](#)" on page 215

LO

This command sets the R&S EVSF1000 back to local control.

Return values:
<State> **READY.**
The command was executed successfully.

Usage: Setting only

MLOC

The `MLOC` command is identical to the `LO` command.

Return values:
<State> **READY.**
The command was executed successfully.

RLC <State>
REMOTELOCK <State>

This command deactivates/activates local operation by keyboard.

Parameters:

<State>

ON

If set, no local operation by keyboard is possible.

OFF

The R&S EVSF1000 must be set to "OFF" or must be restarted to activate local operation by keyboard.

Return values:

<State>

READY.

The command was executed successfully.

SETUP:NTPSERVER?
SETUP:NTPSERVER <IPAddress>

Defines the IP address of the NTP server used for time synchronization of the internal R&S EVSF1000 clock (see [SETUP:TIMESYNC](#) on page 244).

Parameters:

<IPAddress>

TCP/IP address between 0.0.0.0 and 0.255.255.255

Example:

```
SETUP:TIMESYNC NTP
```

```
SETUP:NTPSERVER 10.0.2.166
```

Usage:

Setting only

9.1.8 Wi-Fi commands

The following commands are required to configure and control the optional R&S EVSD1-Z5 Data-link-module (Wi-Fi).

WIFI:SSID	247
WIFI:WPAPSK	247
WIFI:IP	247
WIFI:NETMASK	247
WIFI:GATEWAY	248
WIFI:ONOFF?	248
WIFI:ONOFF	248
WIFI:CHANNEL?	248
WIFI:CHANNEL	248
WIFI:SPEED?	249
WIFI:SPEED	249
WIFI:COUNTRY?	249
WIFI:COUNTRY	249
WIFI:STATUS	250

WIFI:SSID <ID>

Defines the service set identifier, the name of the Wi-Fi.

Parameters:

<ID> *RST: EVSD<serial number>

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[SSID](#)" on page 216

WIFI:WPAPSK <Password>

Defines the Wi-Fi password.

Parameters:

<Password> *RST: RS<serial number>

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[WPA-PSK Key](#)" on page 217

WIFI:IP <IPAddress>

Unique address of the instrument in the network.

Parameters:

<IPAddress> Four number blocks separated by dots. Each block contains values between 0 and 255.
*RST: 192.168.1.1

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[IP](#)" on page 217

WIFI:NETMASK <Mask>

Defines the Wi-Fi subnet mask.

Parameters:

<Mask> Four number blocks separated by dots. Each block contains values between 0 and 255.
*RST: 255.255.255.0

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Netmask"](#) on page 218

WIFI:GATEWAY <Address>

Wi-Fi gateway address

Parameters:

<Address> Four number blocks separated by dots. Each block contains values between 0 and 255.

*RST: 192.168.1.2

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Gateway"](#) on page 218

WIFI:ONOFF?

WIFI:ONOFF <State>

Enables or disables a data connection via the optional Wi-Fi interface.

Parameters:

<State> ON | OFF

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Wi-Fi"](#) on page 216

WIFI:CHANNEL?

WIFI:CHANNEL <Channel>

Wi-Fi channel

Parameters:

<Channel> 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 36 | 40 | 44 | 48 |
52 | 56 | 60 | 64 | 100 | 104 | 108 | 112 | 116 | 120 | 124 | 128 |
132 | 136 | 140 | 149 | 153 | 157 | 161 | 165

*RST: 1

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Channel"](#) on page 217

WIFI:SPEED?**WIFI:SPEED** <DataRate>

Determines the used Wi-Fi data rate.

Parameters:

<DataRate>

LOW

(Default:) Uses 20 MHz bandwidth. Data transfer is less susceptible to distortion.

HIGH

Uses 80 MHz bandwidth, if available. Guard interval is reduced to increase the data rate. Data transfer becomes more susceptible to distortion.

*RST: LOW

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Wi-Fi Speed"](#) on page 217**WIFI:COUNTRY?****WIFI:COUNTRY** <Code>

Country code

Parameters:

<Code>

00 | AD | AE | AF | AI | AL | AM | AN | AR | AS | AT | AU | AW |
 AZ | BA | BB | BD | BE | BF | BG | BH | BL | BM | BN | BO | BR |
 BS | BT | BY | BZ | CA | CF | CH | CI | CL | CN | CO | CR | CU |
 CX | CY | CZ | DE | DK | DM | DO | DZ | EC | EE | EG | ES | ET |
 EI | FM | FR | GB | GD | GE | GF | GH | GL | GP | GR | GT | GU |
 GY | HK | HN | HR | HT | HU | ID | IE | IL | IN | IR | IS | IT | JM |
 JO | JP | KE | KH | KN | KP | KR | KW | KY | KZ | LB | LC | LI |
 LK | LS | LT | LU | LV | MA | MC | MD | ME | MF | MH | MK | MN |
 MO | MP | MQ | MR | MT | MU | MV | MW | MX | MY | NG | NI |
 NL | NO | NP | NZ | OM | PA | PE | PF | PG | PH | PK | PL | PM |
 PR | PT | PW | PY | QA | RE | RO | RS | RU | RW | SA | SE |
 SG | SI | SK | SN | SR | SV | SY | TC | TD | TG | TH | TN | TR |
 TT | TW | TZ | UA | UG | US | UY | UZ | VC | VE | VI | VN | VU |
 WF | WS | YE | YT | ZA | ZW

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Country"](#) on page 217

WIFI:STATUS <Status>

Indicates the status of the Wi-Fi connection.

Parameters:

<Status>	ON
	Wi-Fi access point is running.
	OFF
	Wi-Fi access point not (yet) running successfully. Additional information indicates the reason for the error. See "Status" on page 218.

Return values:

<State>	READY.
	The command was executed successfully.

Manual operation: See ["Status"](#) on page 218

9.1.9 System settings

The following commands are required to configure basic system settings.

FACTORY_PRESET	250
SETUP:BOOTONPOWERUP	250
SETUP:DATE	251
SETUP:TIME	251
WAIT4EXE	251

FACTORY_PRESET

This command restores the factory default settings. The IP-settings and Data logger lists are not modified.

Return values:

<State>	READY.
	The command was executed successfully.

Manual operation: See ["Factory Preset"](#) on page 200

SETUP:BOOTONPOWERUP <State>

If power is applied to the instrument, it can be started immediately.

Parameters:

<State>	ON
	The R&S EVSF1000 is started immediately after power is applied to the instrument.

Return values:

<State>	READY.
	The command was executed successfully.

Example: `SETUP:BOOTONPOWERUP ON`

Manual operation: See ["Boot on Power Up"](#) on page 220

SETUP:DATE <Date>

This command sets the instrument date.

Parameters:

<Date> DD.MM.YYYY

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Date"](#) on page 219

SETUP:TIME <Time>

This command sets the instrument time.

Parameters:

<Time> HH:MM:SS

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Time"](#) on page 219

WAIT4EXE <State>

Sets the behavior of the status message "READY".

Parameters:

<State> **ON**
The "READY." message is delayed until every command is executed.

OFF
The "READY." message is returned as soon as a command is syntactically accepted.

Return values:

<State> **READY.**
The command was executed successfully.

9.1.10 Result display settings

The following commands are required to configure the result displays for measurements.

SETUP:UNIT:BARGRAPH?	252
SETUP:UNIT:BARGRAPH	252
SETUP:UNIT:DDM?	252

SETUP:UNIT:DDM.....	252
SETUP:UNIT:ILSPHASE?.....	253
SETUP:UNIT:ILSPHASE.....	253
SETUP:UNIT:POLARITYDDM?.....	253
SETUP:UNIT:POLARITYDDM.....	253
SETUP:UNIT:SDM?.....	253
SETUP:UNIT:SDM.....	253
SETUP:UNIT:UPPERFREQ?.....	254
SETUP:UNIT:UPPERFREQ.....	254
SETUP:UNIT:VORDIRECTION?.....	254
SETUP:UNIT:VORDIRECTION.....	254

SETUP:UNIT:BARGRAPH?**SETUP:UNIT:BARGRAPH** <MesDe>

This command sets the representation of bar graph.

Parameters:

<MesDe>

ILSPHASE

Sets the MesDe parameter as ILSPHASE.

Cockpit

Sets the MesDe parameter as Cockpit.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation:

See "DDM Bargr" on page 75

See "Level View" on page 211

SETUP:UNIT:DDM?**SETUP:UNIT:DDM** <Unit>

This command sets the DDM unit.

Parameters:

<Unit>

1

Sets DDM unit as dimensionless.

uA

Sets DDM unit as μA .

PCT

Sets DDM unit as percentage.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation:

See "DDM Unit" on page 74

SETUP:UNIT:ILSPHASE?**SETUP:UNIT:ILSPHASE** <ILS phase>

This command gets or sets the ILS phase representation.

Parameters:

<ILS phase>

BIPOLAR

The phase is represented as bipolar, if between -60...+60.

UNIPOLAR

The phase is represented as unipolar, if between 0...+120.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["ILS Phase"](#) on page 74**SETUP:UNIT:POLARITYDDM?****SETUP:UNIT:POLARITYDDM** <Value>

This command gets or sets the DDM polarity.

The phase is represented as unipolar, if between 0...+120.

Parameters:

<Value>

90-150

Sets DDM polarity as 90-150.

150-90

Sets DDM polarity as 150-90.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["DDM Polarity"](#) on page 74**SETUP:UNIT:SDM?****SETUP:UNIT:SDM** <Unit>

This command sets the SDM unit.

Parameters:

<Unit>

1

Sets SDM unit as dimensionless.

uASets SDM unit as μA .**PCT**

Sets SDM unit as percentage.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["SDM Unit"](#) on page 74

SETUP:UNIT:UPPERFREQ?**SETUP:UNIT:UPPERFREQ** <Upper frequency>

This command gets or sets the upper frequency to course or clearance (while the lower frequency is always vice versa).

Parameters:

<Upper frequency> **CRS**
Sets the upper frequency to course.

CRL
Sets the upper frequency to clear.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "Upper Freq" on page 67

SETUP:UNIT:VORDIRECTION?**SETUP:UNIT:VORDIRECTION** <Direction>

This command gets or sets the VOR direction point of view.

Parameters:

<Direction> **from | to**
Sets the VOR direction point of view as "from" or "to".

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "Signal Direction" on page 101

9.1.11 Retrieving instrument information

The following commands are required to retrieve information on the instrument and operation status.

BI?	255
CLEARERRORLOG	255
GETERRORLOG	255
SETUP:GETERRORLOG	255
GETOPTIONS	255
GETTEMP	255
*IDN?	255
INV?	256
OPTIONGETCHECKED	256
SAVEDATA	256
VER?	256

BI?

This command returns built-in-test information.

Return values:

<BI-Info>

Usage: Query only

Manual operation: See ["HW Status"](#) on page 222

CLEARERRORLOG

This command clears the error log.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Delete all error messages"](#) on page 222

GETERRORLOG**SETUP:GETERRORLOG**

Returns the error log.

Return values:

<string>

Entries of the error log

GETOPTIONS

This command returns a list of installed and available options.

Return values:

<list of options>

Examples: ILS CRS/CLR Analysis, VOR Analysis, MB Analysis, ...

Manual operation: See ["Installed Options"](#) on page 223

GETTEMP

This command queries the temperatures of the main and RX boards.

Return values:

<temperature>

Temperature value of the main and boards.

Manual operation: See ["HW Status"](#) on page 222

***IDN?**

This command queries the instrument identification.

Return values:

<Instrument
Identification>

Usage: Query only

INV?

This command queries the inventory that contains, among other information, serial numbers of device and boards.

Return values:

<Inv-Info>

Usage: Query only

Manual operation: See ["Inventory"](#) on page 224

OPTIONGETCHECKED

Check if all options are available.

Return values:

<Option State> **true**
The option is available.
false
The option is not available.

Example: OPTIONGETCHECKED
K1=true,K2=true,K3=true,K4=false

SAVEDATA

This command stores the current settings in the flash memory. The settings are normally stored during shutdown. However, if the R&S EVSF1000 restarts after a power interruption, it does not remember the settings. Use this function sparingly for essential settings that you want to avoid losing by all means. Each write process to the flash causes additional wear.

Return values:

<State> **READY.**
The command was executed successfully.

VER?

This command queries SW version.

Return values:

<sw-version>

Usage: Query only

Manual operation: See ["Inventory"](#) on page 224

9.1.12 Calibration

The following commands are required to perform and analyze calibration.

AUTOKALSTATUS	257
AUTOKALSTATUS_EXTENDED	257
GETKALSTATUS	257
KALSCREEN	257
STARTKAL	257

AUTOKALSTATUS

This command gets the auto-calibration (Autocal) status and date for the RX boards.

Manual operation: See "[Auto-Calibration \(Cal\)](#)" on page 220

AUTOKALSTATUS_EXTENDED

This command gets the extended autocal state for RX boards.

Return values:

<State> Extended autocal state

GETKALSTATUS

This command shows the current task of auto-calibration.

Return values:

Status Current task of auto-calibration.

Manual operation: See "[Auto-Calibration \(Cal\)](#)" on page 220

KALSCREEN

This command shows the auto-calibration ("Setup - Cal") screen.

Return values:

<State> **READY.**
Command was executed successfully.

Manual operation: See "[Auto-Calibration \(Cal\)](#)" on page 220

STARTKAL

This command launches autocalibration for current RX-board.

The command returns immediately, while the calibration takes several minutes. To find out when the calibration is ready, use the [GETKALSTATUS](#) command.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "Auto-Calibration (Cal)" on page 220

9.1.13 Deprecated commands

The following commands are maintained for compatibility with former Rohde & Schwarz analyzers only. For new remote control programs, use the following commands:

- [MODE_LOC](#) on page 260
- [MODE_LOC](#) on page 260
- [MODE_GP](#) on page 260
- [MODE_MB](#) on page 293
- [MODE_VOR](#) on page 300
- [MODE_COM](#) on page 310
- [MODE_FSCAN](#) on page 338
- [MODE_IFSPECT](#) on page 343
- [MODE_FFT](#) on page 348
- [MODE_SCOPE](#) on page 355

M?	258
MB	259
MI	259
MV	259

M?

This command queries the current active mode.

Return values:

<ActiveMode>	ILS_LOC ILS Localizer mode
	ILS_GP ILS Glide Path mode
	MB Marker Beacon mode
	VOR VHF omnidirectional radio range mode (R&S EVSG-K2 VOR analysis)
	COM COM mode (R&S EVSG-K6 COM analysis)
	FSCAN RF spectrum mode (R&S EVSG-K10 RF spectrum analysis)
	IFSPECTRUM IF spectrum mode (R&S EVSG-K10 RF spectrum analysis)
	FFT AF Spectrum mode (R&S EVSG-K11 AF spectrum analysis)

SCOPE

AF Time Domain mode (R&S EVSG-K12 Time domain analysis)

GBASGBAS/SCAT-I mode (R&S EVSG-K4 GBAS analysis /
R&S EVSG-K5 SCAT-I Analysis)**NDB**

Non-directional beacon mode (R&S EVSG1-K7 LF-Analysis)

Usage: Query only

MB

This command switches the instrument to the "ILS MB" mode.

Return values:<State> **READY.**
The command was executed successfully.

MI

This command switches the instrument to the "ILS LOC" mode.

Return values:<State> **READY.**
The command was executed successfully.

MV

This command switches the instrument to the "VOR" mode.

Return values:<State> **READY.**
The command was executed successfully.

9.2 ILS localizer (LOC) and glidepath (GP) modes

The following commands are required to configure and perform measurements in the ILS Localizer and Glidepath modes.

- [Configuring the ILS LOC and GP modes](#).....260
- [Configuring ILS localizer measurements](#).....260
- [Configuring ILS glidepath measurements](#).....270
- [Retrieving ILS loc and GP results](#).....279
- [Retrieving ID results](#).....288
- [Deprecated commands](#).....289

9.2.1 Configuring the ILS LOC and GP modes

The following commands are required to activate the modes.

MODE_LOC.....	260
MODE_GP.....	260

MODE_LOC

The MODE_LOC command is identical to the MI command.

For description, see MI on page 259.

MODE_GP

This command switches the instrument to the "ILS GP" mode.

Return values:

<State> **READY.**
The command was executed successfully.

9.2.2 Configuring ILS localizer measurements

The following commands are required to configure ILS Loc measurements

DEMODE_LLZ?.....	261
DEMODE_LLZ.....	261
LLZ_BB_1F_OFFSETKHZ?.....	262
LLZ_BB_1F_OFFSETKHZ.....	262
LLZ_BB_AF_BW_IDDIST_KHZ?.....	262
LLZ_BB_AF_BW_IDDIST_KHZ.....	262
LLZ_BB_BW_KHZ?.....	262
LLZ_BB_BW_KHZ.....	262
LLZ_BB_LFIN_DCOFFSETV?.....	263
LLZ_BB_LFIN_DCOFFSETV.....	263
LLZ_BB_LOWIF_BW_IDDIST_KHZ?.....	263
LLZ_BB_LOWIF_BW_IDDIST_KHZ.....	263
LLZ_BB_LOWIF_BW_KHZ?.....	263
LLZ_BB_LOWIF_BW_KHZ.....	263
LLZ_BB_WIDE1F?.....	264
LLZ_BB_WIDE1F.....	264
LLZ_CARRIER_THRESHOLD_DB?.....	264
LLZ_CARRIER_THRESHOLD_DB.....	264
LLZ_DEFAULT_FREQSTEP?.....	264
LLZ_DEFAULT_FREQSTEP.....	264
LLZ_DEM_ID_BW?.....	265
LLZ_DEM_ID_BW.....	265
LLZ_DEM_ID_WIDE_BW?.....	265
LLZ_DEM_ID_WIDE_BW.....	265
LLZ_DEM_WIDE_BW?.....	265

LLZ_DEM_WIDE_BW.....	265
LLZ_DEM_1F2F_BW?.....	266
LLZ_DEM_1F2F_BW.....	266
LLZ_DEMFREQS_OFFSET_1F?.....	266
LLZ_DEMFREQS_OFFSET_1F.....	266
LLZ_DEMFREQS_OFFSET_AUTOMAN?.....	266
LLZ_DEMFREQS_OFFSET_AUTOMAN.....	266
LLZ_DEMFREQS_OFFSET_LOWERFREQ?.....	267
LLZ_DEMFREQS_OFFSET_LOWERFREQ.....	267
LLZ_DEMFREQS_OFFSET_UPPERFREQ?.....	267
LLZ_DEMFREQS_OFFSET_UPPERFREQ.....	267
LLZ_ID_STAT?.....	267
LLZ_ID_STAT.....	267
FILTER_LLZ_RESIDFM?.....	267
FILTER_LLZ_RESIDFM.....	267
LLZ_RFLF_INPUT?.....	268
LLZ_RFLF_INPUT.....	268
LLZ_START_FINDCARRIER.....	268
LLZ_TRIG_EDGE?.....	268
LLZ_TRIG_EDGE.....	268
LLZ_TRIG_SOURCE?.....	269
LLZ_TRIG_SOURCE.....	269
VIEW_GS?.....	269
VIEW_GS.....	269
VIEW_LLZ?.....	270
VIEW_LLZ.....	270

DEMODE_LLZ?**DEMODE_LLZ** <1F/2F mode>

Gets or sets the 1F/2F mode in "ILS LOC" mode.

Parameters:

<1F/2F mode>

1F

ILS system with one carrier. The nominal frequency is the carrier frequency.

2F

ILS system with two carriers. The carrier frequencies (Course and Clearance) are above and below the nominal frequency (in a distance of a few kHz).

2F_CRS

Course of an ILS system (depending on the ILS system, it can be the upper or lower carrier frequency).

2F_CLR

Clearance of an ILS system (depending on the ILS system, it can be the upper or lower carrier frequency).

WIDE

In the wideband mode, 1-frequency and 2-frequency systems can be analyzed. Both carriers are inside one filter and can be demodulated together.

Note: In this mode, there is no configuration and display of the carrier offset.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["1F/2F"](#) on page 64

LLZ_BB_1F_OFFSETKHZ? <Offset>

LLZ_BB_1F_OFFSETKHZ <Offset>

This command gets or sets the frequency of the low IF signal for LF input in "ILS LOC" mode.

Parameters:

<Offset>

Offset of the low IF signal from 0 Hz.

Default unit: kHz

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Low IF Offset"](#) on page 72

LLZ_BB_AF_BW_IDDIST_KHZ? <Bandwidth>

LLZ_BB_AF_BW_IDDIST_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (AF mode) for ID and distortion measurement in "ILS LOC" mode.

Parameters:

<Bandwidth>

0_5KHZ | 1_5KHZ | 3KHZ | 5KHZ

Bandwidth

Default unit: kHz

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["IF/AF Bandwidth \(Dist/ID\)"](#) on page 73

LLZ_BB_BW_KHZ? <Bandwidth>

LLZ_BB_BW_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (AF mode) in "ILS LOC" mode.

Parameters:

<Bandwidth> 0.5KHZ | 1.5KHZ | 3KHZ | 5KHZ | 9KHZ | 12.5KHZ | 18KHZ | 25KHZ
 Bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Bandwidth \(IF BW/AF In BW\)"](#) on page 73

LLZ_BB_LFIN_DCOFFSETV? <DCOffset>

LLZ_BB_LFIN_DCOFFSETV <Power>

This command gets or sets the reference power for LF input (AF signals only) in "ILS LOC" mode. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

Parameters:

<Power> Reference DC power of the AF signal
 Default unit: V

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["DC Reference"](#) on page 72

LLZ_BB_LOWIF_BW_IDDIST_KHZ? <Bandwidth>

LLZ_BB_LOWIF_BW_IDDIST_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (low IF mode) for ID and distortion measurement in "ILS LOC" mode.

Parameters:

<Bandwidth> 0_5KHZ | 1_5KHZ | 3KHZ | 5KHZ
 Bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["IF/AF Bandwidth \(Dist/ID\)"](#) on page 73

LLZ_BB_LOWIF_BW_KHZ? <Bandwidth>

LLZ_BB_LOWIF_BW_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (low IF mode) in "ILS LOC" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ
 Bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Bandwidth \(IF BW/AF In BW\)](#)" on page 73

LLZ_BB_WIDE1F? <1F mode>

LLZ_BB_WIDE1F <1F mode>

Determines the type of LF input. Depending on the type of input, the available settings and results can vary.

Parameters:

<1F mode> **AF**
 Measures the AF signal at 0 Hz.
IF
 Measures the signal at a low intermediate frequency, for example from a test point at the transmitter.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[LF In Mode](#)" on page 71

LLZ_CARRIER_THRESHOLD_DB?

LLZ_CARRIER_THRESHOLD_DB <Threshold>

Gets or sets the carrier threshold in "ILS LOC" mode.

Parameters:

<Threshold> Carrier threshold
 Default unit: dB

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Carrier Thresh](#)" on page 67

LLZ_DEFAULT_FREQSTEP? <StepSize>

LLZ_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default RF frequency step size in "ILS LOC" mode.

Parameters:

<StepSize> 8.33_KHZ | 12.5_KHZ | 25_KHZ | 50_KHZ
 *RST: 50_KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Step Size"](#) on page 68

LLZ_DEM_ID_BW?

LLZ_DEM_ID_BW <Bandwidth>

Gets or sets the demodulator bandwidth for ID and distortion measurement in "ILS LOC" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["IF BW Dist/ID"](#) on page 70

LLZ_DEM_ID_WIDE_BW? <Bandwidth>

LLZ_DEM_ID_WIDE_BW <Bandwidth>

Gets or sets the WIDE demodulator bandwidth for ID and distortion analysis in "ILS LOC" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["IF BW Dist/ID"](#) on page 70

LLZ_DEM_WIDE_BW?

LLZ_DEM_WIDE_BW <Bandwidth>

Gets or sets the WIDE demodulator bandwidth in "ILS LOC" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["IF BW"](#) on page 70

LLZ_DEM_1F2F_BW?

LLZ_DEM_1F2F_BW <Bandwidth>

Gets or Sets the 1F2F demodulator bandwidth in "ILS LOC" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF BW"](#) on page 70

LLZ_DEMFREQS_OFFSET_1F?

LLZ_DEMFREQS_OFFSET_1F <Freq. Offset>

Gets or sets the demodulator 1F frequency offset in "ILS LOC" mode.

Parameters:

<Freq. Offset> Frequency offset
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["1F Offset"](#) on page 66

LLZ_DEMFREQS_OFFSET_AUTOMAN?

LLZ_DEMFREQS_OFFSET_AUTOMAN <Mode>

Gets or sets the mode of the demodulator frequency offset in "ILS LOC" mode.

Parameters:

<Mode> **AUTO_LOCK**
Sets the demodulator frequency offset automatically. Once a valid signal has been found, the carrier frequencies remain fixed until you perform a manual change.

AUTO_RETUNE

Sets the demodulator frequency offset automatically. If the carrier frequency changes, the R&S EVSF1000 starts a new search (retuning).

MANUAL

Sets the demodulator frequency offset manually.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["CRS/CLR Carr \(Autotune function\)"](#) on page 65

LLZ_DEMFREQS_OFFSET_LOWERFREQ?**LLZ_DEMFREQS_OFFSET_LOWERFREQ** <Freq. Offset>

Gets or Sets the demodulator lower frequency offset in "ILS LOC" mode.

Parameters:

<Freq. Offset> Lower frequency offset
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Clearance](#)" on page 66

LLZ_DEMFREQS_OFFSET_UPPERFREQ?**LLZ_DEMFREQS_OFFSET_UPPERFREQ** <Freq. Offset>

Gets or Sets the demodulator upper frequency offset in "ILS LOC" mode.

Parameters:

<Freq. Offset> Upper frequency offset
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[Course](#)" on page 66

LLZ_ID_STAT?**LLZ_ID_STAT** <State>

Enables or disables the ID statistics calculation in ILS Localizer measurements.

Parameters:

<State> **ON**
 The ID code is determined as the most probable code based on the previous decoding results.
 OFF
 The most recently decoded ID is used.

FILTER_LLZ_RESIDFM?**FILTER_LLZ_RESIDFM** <Bandwidth>

Defines or queries the filter type used to determine residual FM

Return values:

<Bandwidth> **ICAO**
 Filter according to ICAO specification

NARROW

Narrow filter; the DDM filters used to determine the 90 Hz/150 Hz modulation values are used to avoid interference between the signals

*RST: ICAO

Example:

`FILTER_LLZ_RESIDFM NARROW`

Manual operation:

See ["Res. FM Filt. \(ILS only\)"](#) on page 70

See ["Res. FM Filt."](#) on page 73

LLZ_RFLF_INPUT? <Input>

LLZ_RFLF_INPUT <Input>

Configures the input source for the receiver in "ILS LOC" mode.

Parameters:

<Input>

RX_IN

RF input from RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000

LF_IN

An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation:

See ["Input RF/LF"](#) on page 63

LLZ_START_FINDCARRIER

Starts to search for a carrier in "ILS LOC" mode.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation:

See ["Find Carrier"](#) on page 67

LLZ_TRIG_EDGE? <TrigEdge>

LLZ_TRIG_EDGE <TrigEdge>

Gets or sets whether triggering occurs when the signal rises to the trigger level or falls down to it in "ILS LOC" mode.

Parameters:

<TrigEdge>

POSITIVE | NEGATIVE

POSITIVE

Triggers when the signal rises to the trigger level

NEGATIVE

Triggers when the signal falls down to the trigger level

Return values:

<State>

READY.

The command was executed successfully.

LLZ_TRIG_SOURCE? <TrigSource>**LLZ_TRIG_SOURCE** <TrigSource>

Gets or sets the trigger source in "ILS LOC" mode.

Parameters:

<TrigSource>

OFF | TIME | EXT

OFF

Free run mode, no trigger used

TIME

time trigger

EXT

external trigger

Return values:

<State>

READY.

The command was executed successfully.

VIEW_GS?**VIEW_GS** <View type>Gets or sets the view in "ILS GP" mode. See [Chapter 4.1.3, "ILS localizer and glide-path measurements and results"](#), on page 44 for details.**Parameters:**

<View type>

MAIN

Main view

CRS|CLR

Course or clearance view

DIST

Distortion view

REC

Recording view

Return values:

<State>

READY.

The command was executed successfully.

VIEW_LLZ?**VIEW_LLZ** <View type>

Gets or sets the view in "ILS LOC" mode. See [Chapter 4.1.3, "ILS localizer and glidepath measurements and results"](#), on page 44 for details.

Parameters:

<View type>

MAIN

Main view

CRS|CLR

Course or clearance view

DIST

Distortion view

ID

ID Analysis view

REC

Recording view

Return values:

<State>

READY.

The command was executed successfully.

9.2.3 Configuring ILS glidepath measurements

The following commands are required to configure ILS GP measurements

DEMODE_GS?	271
DEMODE_GS	271
GS_BB_1F_OFFSETKHZ?	272
GS_BB_1F_OFFSETKHZ	272
GS_BB_AF_BW_IDDIST_KHZ?	272
GS_BB_AF_BW_IDDIST_KHZ	272
GS_BB_BW_KHZ?	272
GS_BB_BW_KHZ	272
GS_BB_LFIN_DCOFFSETV?	273
GS_BB_LFIN_DCOFFSETV	273
GS_BB_LOWIF_BW_IDDIST_KHZ?	273
GS_BB_LOWIF_BW_IDDIST_KHZ	273
GS_BB_LOWIF_BW_KHZ?	273
GS_BB_LOWIF_BW_KHZ	273
GS_BB_WIDE1F?	274
GS_BB_WIDE1F	274
GS_CARRIER_THRESHOLD_DB?	274
GS_CARRIER_THRESHOLD_DB	274
GS_DEFAULT_FREQSTEP?	274
GS_DEFAULT_FREQSTEP	274
GS_DEM_1F2F_BW?	275
GS_DEM_1F2F_BW	275
GS_DEM_ID_BW?	275
GS_DEM_ID_BW	275

GS_DEM_ID_WIDE_BW?	275
GS_DEM_ID_WIDE_BW	275
GS_DEM_WIDE_BW?	275
GS_DEM_WIDE_BW	275
GS_DEMFREQS_OFFSET_AUTOMAN?	276
GS_DEMFREQS_OFFSET_AUTOMAN	276
GS_DEMFREQS_OFFSET_1F?	276
GS_DEMFREQS_OFFSET_1F	276
GS_DEMFREQS_OFFSET_LOWERFREQ?	276
GS_DEMFREQS_OFFSET_LOWERFREQ	276
GS_DEMFREQS_OFFSET_UPPERFREQ?	277
GS_DEMFREQS_OFFSET_UPPERFREQ	277
GS_ID_STAT?	277
GS_ID_STAT	277
FILTER_GS_RESIDFM?	277
FILTER_GS_RESIDFM	277
GS_RFLF_INPUT?	278
GS_RFLF_INPUT	278
GS_START_FINDCARRIER	278
GS_TRIG_EDGE?	278
GS_TRIG_EDGE	278
GS_TRIG_SOURCE?	279
GS_TRIG_SOURCE	279

DEMODE_GS?**DEMODE_GS** <1F/2F mode>

Gets or sets the 1F/2F mode in "ILS GP" mode.

Parameters:

<1F/2F mode>

1F

ILS system with one carrier. The nominal frequency is the carrier frequency.

2F

ILS system with two carriers. The carrier frequencies (Course and Clearance) are above and below the nominal frequency (in a distance of a few kHz).

2F_CRS

Course of an ILS system (depending on the ILS system, it can be the upper or lower carrier frequency).

2F_CLR

Clearance of an ILS system (depending on the ILS system, it can be the upper or lower carrier frequency).

WIDE

In the wideband mode, 1-frequency and 2-frequency systems can be analyzed. Both carriers are inside one filter and can be demodulated together.

Note: In this mode, there is no configuration and display of the carrier offset.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["1F/2F"](#) on page 64

GS_BB_1F_OFFSETKHZ? <Offset>

GS_BB_1F_OFFSETKHZ <Offset>

This command gets or sets the offset of the AF signal for LF input in "ILS GS" mode.

Parameters:

<Offset> Offset of the AF signal from 0 Hz.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Low IF Offset"](#) on page 72

GS_BB_AF_BW_IDDIST_KHZ? <Bandwidth>

GS_BB_AF_BW_IDDIST_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (AF mode) for ID and distortion measurement in "ILS GP" mode.

Parameters:

<Bandwidth> 0_5KHZ | 1_5KHZ | 3KHZ | 5KHZ
Bandwidth
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF/AF Bandwidth \(Dist/ID\)"](#) on page 73

GS_BB_BW_KHZ? <Bandwidth>

GS_BB_BW_KHZ <Bandwidth>

This command gets or sets the bandwidth for LF input in "ILS GP" mode.

Parameters:

<Bandwidth> 0.5KHZ | 1.5KHZ | 3KHZ | 5KHZ | 9KHZ | 12.5KHZ | 18KHZ | 25KHZ
Bandwidth
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Bandwidth \(IF BW/AF In BW\)"](#) on page 73

GS_BB_LFIN_DCOFFSETV? <DCOffset>

GS_BB_LFIN_DCOFFSETV <DCOffset>

This command gets or sets the reference power for LF input (AF signals only) in "ILS GS" mode. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

Parameters:

<Power> Reference DC power of the AF signal.
 Default unit: V

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["DC Reference"](#) on page 72

GS_BB_LOWIF_BW_IDDIST_KHZ? <Bandwidth>

GS_BB_LOWIF_BW_IDDIST_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (low IF mode) for ID and distortion measurement in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ
 Bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["IF/AF Bandwidth \(Dist/ID\)"](#) on page 73

GS_BB_LOWIF_BW_KHZ? <Bandwidth>

GS_BB_LOWIF_BW_KHZ <Bandwidth>

This command gets or sets the demodulator bandwidth for LF input (low IF mode) in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
 50KHZ
 Bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Bandwidth \(IF BW/AF In BW\)"](#) on page 73

GS_BB_WIDE1F? <1F mode>

GS_BB_WIDE1F <1F mode>

Determines the type of LF input in "ILS GP" mode. Depending on the type of input, the available settings and results can vary.

Parameters:

<1F mode>

AF

Measures the AF signal at 0 Hz.

IF

Measures the signal at a low intermediate frequency, for example from a test point at the transmitter.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["LF In Mode"](#) on page 71

GS_CARRIER_THRESHOLD_DB?

GS_CARRIER_THRESHOLD_DB <Threshold>

Gets or sets the carrier threshold in "ILS GP" mode.

Parameters:

<Threshold>

Carrier threshold

Default unit: dB

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Carrier Thresh"](#) on page 67

GS_DEFAULT_FREQSTEP? <StepSize>

GS_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default RF frequency step size in "ILS GP" mode.

Parameters:

<StepSize>

8.33_KHZ | 12.5_KHZ | 25_KHZ | 50_KHZ

*RST: 50_KHZ

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Step Size"](#) on page 68

GS_DEM_1F2F_BW?**GS_DEM_1F2F_BW** <Bandwidth>

Gets or Sets the 1F2F demodulator bandwidth in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ
 Demodulator bandwidth

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "IF BW" on page 70**GS_DEM_ID_BW?****GS_DEM_ID_BW** <Bandwidth>

Gets or sets the ID demodulator Bandwidth in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "IF BW Dist/ID" on page 70**GS_DEM_ID_WIDE_BW? <Bandwidth>****GS_DEM_ID_WIDE_BW** <Bandwidth>

Gets or sets the WIDE demodulator bandwidth for ID and distortion analysis in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
 50KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "IF BW Dist/ID" on page 70**GS_DEM_WIDE_BW?****GS_DEM_WIDE_BW** <Bandwidth>

Gets or sets the WIDE demodulator bandwidth in "ILS GP" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
 50KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF BW"](#) on page 70

GS_DEMFREQS_OFFSET_AUTOMAN?

GS_DEMFREQS_OFFSET_AUTOMAN <Mode>

Gets or sets the mode of the demodulator frequency offset in "ILS GP" mode.

Parameters:

<Mode> **AUTO_LOCK**
Sets the demodulator frequency offset automatically. Once a valid signal has been found, the carrier frequencies remain fixed until you perform a manual change.

AUTO_RETUNE
Sets the demodulator frequency offset automatically. If the carrier frequency changes, the R&S EVSF1000 starts a new search (retuning).

MANUAL
Sets the demodulator frequency offset manually.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["CRS/CLR Carr \(Autotune function\)"](#) on page 65

GS_DEMFREQS_OFFSET_1F?

GS_DEMFREQS_OFFSET_1F <Freq. Offset>

Gets or sets the demodulator 1F frequency offset in "ILS GP" mode.

Parameters:

<Freq. Offset> Frequency offset
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["1F Offset"](#) on page 66

GS_DEMFREQS_OFFSET_LOWERFREQ?

GS_DEMFREQS_OFFSET_LOWERFREQ <Freq. Offset>

Gets or Sets the demodulator lower frequency offset in "ILS GP" mode.

Parameters:

<Freq. Offset> Lower frequency offset
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Clearance](#)" on page 66

GS_DEMFREQS_OFFSET_UPPERFREQ?

GS_DEMFREQS_OFFSET_UPPERFREQ <Freq. Offset>

Gets or Sets the demodulator upper frequency offset in "ILS GP" mode.

Parameters:

<Freq. Offset> Upper frequency offset
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Course](#)" on page 66

GS_ID_STAT?

GS_ID_STAT <State>

Enables or disables the ID statistics calculation for ILS glidepath measurements.

Parameters:

<State> **ON**
The ID code is determined as the most probable code based on the previous decoding results.
OFF
The most recently decoded ID is used.

FILTER_GS_RESIDFM?

FILTER_GS_RESIDFM <Bandwidth>

Defines or queries the filter type used to determine residual FM in "ILS GP" mode

Return values:

<Bandwidth> **ICAO**
Filter according to ICAO specification
NARROW
Narrow filter; the DDM filters used to determine the 90 Hz/ 150 Hz modulation values are used to avoid interference between the signals
*RST: ICAO

Example: FILTER_GS_RESIDFM NARROW

GS_RFLF_INPUT? <Input>

GS_RFLF_INPUT <Input>

Configures the input source for the receiver in "ILS GP" mode.

Parameters:

<Input>

RX_IN

RF input from RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000

LF_IN

An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Input RF/LF"](#) on page 63

GS_START_FINDCARRIER

Starts to search for a carrier in "ILS GP" mode.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Find Carrier"](#) on page 67

GS_TRIG_EDGE? <TrigEdge>

GS_TRIG_EDGE <TrigEdge>

Gets or sets whether triggering occurs when the signal rises to the trigger level or falls down to it in "ILS GP" mode.

Parameters:

<TrigEdge>

POSITIVE | NEGATIVE

POSITIVE

Triggers when the signal rises to the trigger level

NEGATIVE

Triggers when the signal falls down to the trigger level

Return values:

<State>

READY.

The command was executed successfully.

GS_TRIG_SOURCE? <TrigSource>

GS_TRIG_SOURCE <TrigSource>

Gets or sets the trigger source in "ILS GP" mode.

Parameters:

<TrigSource> OFF | TIME | EXT

OFF

Free run mode, no trigger used

TIME

Time trigger

EXT

External trigger

Return values:

<State>

READY.

The command was executed successfully.

9.2.4 Retrieving ILS loc and GP results

The following commands are required to retrieve results for ILS Loc or GP measurements

Useful commands for retrieving results described elsewhere:

- [GETDATADEF](#) on page 366
- [GETDATASET](#) on page 366
- [LA?](#) on page 231
- [RF](#) on page 231
- [FFT_GETSPECT](#) on page 354

Remote commands exclusive to ILS Loc and GP results:

AC8	280
AF2	280
AF3	280
AF8	281
AM2	281
AM2CLR	281
AM2CRS	281
AM3	281
AM3CLR	281
AM3CRS	282
AM8	282
AM9	282
AMMOD240	282
GS_BB_DC_V	282
GS_BB_LEV_V	282
GS_BB_LEV_V	283
DCLR	283

DCRS.....	283
DD0.....	283
DD1.....	283
FCLR.....	284
FCRS.....	284
FSINGLE.....	284
K2_150.....	284
K2_90.....	284
K3_150.....	284
K3_90.....	285
K4_90.....	285
K4_150.....	285
LCLR.....	285
LCRS.....	285
PH.....	285
PH_90_90.....	286
PH_150_150.....	286
RESIDFM_90.....	286
RESIDFM_150.....	286
SCLR.....	286
SCRS.....	286
SD0.....	287
SD1.....	287
THD_150.....	287
THD_90.....	287
LLZ_BB_DC_V.....	287
LLZ_BB_LEV_V.....	287
LLZ_BB_VMAXPP_V.....	288

AC8

This command queries the code of identifier, LLZ only.

Return values:

<[CODE]> AC8 value of the identifier

Manual operation: See "ID Code" on page 56

AF2

This command queries the AF frequency of 90 Hz signal.

Return values:

<[Hz]> AF2 value of the frequency

Manual operation: See "Freq 90 Hz" on page 56

AF3

This command queries the AF frequency of 150 Hz signal.

Return values:

<[Hz]> AF3 value of the frequency

Manual operation: See ["Freq 150 Hz"](#) on page 56

AF8

This command queries the AF frequency of the identifier, LLZ only.

Return values:

<[Hz]> AF8 value of the frequency

Manual operation: See ["ID Freq"](#) on page 61

AM2

This command shows the AM modulation depth of 90 Hz signal.

Return values:

<[%]> AM modulation depth value of 90 Hz

Manual operation: See ["AM 90 Hz"](#) on page 56

AM2CLR

This command shows the AM modulation depth of 90 Hz clearance signal.

Return values:

<[%]> AM modulation depth value of 90 Hz clearance signal

Manual operation: See ["AM 90 Hz"](#) on page 56

AM2CRS

This command shows the AM modulation depth of 90 Hz course signal.

Return values:

<[%]> AM modulation depth value of 90 Hz course signal

Manual operation: See ["AM 90 Hz"](#) on page 56

AM3

This command shows the AM modulation depth of 150 Hz signal.

Return values:

<[%]> AM modulation depth value of 150 Hz

Manual operation: See ["AM 150 Hz"](#) on page 56

AM3CLR

This command shows the AM modulation depth of 150 Hz clearance signal.

Return values:

<[%]> AM modulation depth value of 150 Hz clearance signal

Manual operation: See ["AM 150 Hz"](#) on page 56

AM3CRS

This command shows the AM modulation depth of 150 Hz course signal.

Return values:

<[%]> AM modulation depth value of 150 Hz course signal

Manual operation: See ["AM 150 Hz"](#) on page 56

AM8

This command queries the AM modulation of identifier, LLZ only.

Return values:

<[%]> AM8 value of the identifier

Manual operation: See ["ID AM"](#) on page 61

AM9

This command queries the AM modulation of voice, LLZ only.

Return values:

<[%]> AM9 value of voice

AMMOD240

This command queries the AM modulation depth of $90 + 150 = 240$ Hz signal.

Return values:

<[%]> AM modulation depth

Manual operation: See ["AM \(90+150\)"](#) on page 59

GS_BB_DC_V

This command queries the measured DC power level in Volt for LF input (AF mode) in "ILS GP" mode.

Return values:

<Power> Measured DC power of the AF signal

Default unit: V

GS_BB_LEV_V

This command queries the measured power level in Volt for LF input in "ILS GP" mode.

Return values:

<Power> Measured power of the LF input
Default unit: V

GS_BB_LEV_V

This command queries the maximum peak-to-peak power level in Volt for LF input in "ILS GP" mode.

Return values:

<Power> Maximum peak-to-peak power of the LF input
Default unit: V

DCLR

This command queries the current DDM Clearance value.

Return values:

DDM_CLR [1] DDM Clearance Value (dimensionless)

Manual operation: See ["DDM 90-150"](#) on page 55

DCRS

This command queries the current DDM Course value.

Return values:

DDM_CRS [1] DDM Course Value (dimensionless)

Manual operation: See ["DDM 90-150"](#) on page 55

DD0

This command queries the current DDM value.

Return values:

<DDM [1]> DDM value (dimensionless)

Manual operation: See ["DDM 90-150"](#) on page 55

DD1

This command queries the current DDM value.

Return values:

DDM [μA] DDM value (μA)

Manual operation: See ["DDM 90-150"](#) on page 55

FCLR

This command queries the current frequency Clearance value.

Return values:

<[Hz]> RF Clearance frequency in Hz.

Example:

F CRS
-8000.3Hz

FCRS

This command queries the current frequency Course value.

Return values:

<[Hz]> RF Course frequency in Hz.

Example:

F CRS
8000.2Hz

FSINGLE

This command queries the current frequency Single value.

Parameters:

<[Hz]> RF Single Frequency in Hz

Manual operation: See ["Low IF frequency"](#) on page 51

K2_150

This command queries the K2 distortion parameter of 150 Hz signal.

Return values:

<[%]> K2 distortion value of 150 Hz signal

Manual operation: See ["K2 150 Hz"](#) on page 58

K2_90

This command queries the K2 distortion parameter of 90 Hz signal.

Return values:

<[%]> K2 distortion value of 90 Hz signal

Manual operation: See ["K2 90 Hz"](#) on page 58

K3_150

This command queries the K3 distortion parameter of 150 Hz signal.

Return values:

<[%]> K3 distortion value of 150 Hz signal

Manual operation: See ["K3 150 Hz"](#) on page 59

K3_90

This command queries the K3 distortion parameter of 90 Hz signal.

Return values:

<[%]> K3 distortion value of 90 Hz signal

Manual operation: See ["K3 90 Hz"](#) on page 58

K4_90

This command queries the K4 distortion parameter of 90 Hz signal.

Return values:

<[%]> K4 distortion value of 90 Hz signal

Manual operation: See ["K4 90 Hz"](#) on page 58

K4_150

This command queries the K4 distortion parameter of 150 Hz signal.

Return values:

<[%]> K4 distortion value of 150 Hz signal

Manual operation: See ["K4 150 Hz"](#) on page 59

LCLR

This command queries the current Clearance Level value.

Return values:

<[dBm]> Clearance Level value in dBm

LCRS

This command queries the current Course Level value.

Return values:

<[dBm]> Course Level value in dBm

PH

Phase shift between 90 Hz/150 Hz.

Return values:

<[°]> Phase shift

Manual operation: See ["PHI 90/150"](#) on page 56

PH_90_90

Phase shift between 90 Hz/90 Hz.

Return values:

<[°]> Phase shift

PH_150_150

Phase shift between 150 Hz/150 Hz.

Return values:

<[°]> Phase shift

RESIDFM_90

This command queries the residual FM distortion parameter of 90 Hz signal.

Return values:

<[%]> Residual FM distortion value of 90 Hz signal

Manual operation: See "[Res. FM 90](#)" on page 58

RESIDFM_150

This command queries the residual FM distortion parameter of 150 Hz signal.

Return values:

<[%]> Residual FM distortion value of 150 Hz signal

Manual operation: See "[Res. FM 150](#)" on page 59

SCLR

This command queries the current SDM Clearance value.

Return values:

SDM_CLR [1] SDM Clearance Value (dimensionless)

Manual operation: See "[SDM 90,150](#)" on page 56

SCRS

This command queries the current SDM Course value.

Return values:

SDM_CRS [1] SDM Course Value (dimensionless)

Manual operation: See "[SDM 90,150](#)" on page 56

SD0

This command queries the current SDM value.

Return values:

SDM [1] SDM value (dimensionless)

Manual operation: See ["SDM 90,150"](#) on page 56

SD1

This command queries the current SDM value.

Return values:

SDM [μA] SDM value (μA)

Manual operation: See ["SDM 90,150"](#) on page 56

THD_150

This command queries the THD distortion parameter of 150 Hz signal.

Return values:

<[%]> THD distortion value of 150 Hz signal

Manual operation: See ["THD 150 Hz"](#) on page 59

THD_90

This command queries the THD distortion parameter of 90 Hz signal.

Return values:

<[%]> THD distortion value of 90 Hz signal

Manual operation: See ["THD 90 Hz"](#) on page 58

LLZ_BB_DC_V

This command queries the measured DC power level in Volt for LF input (AF mode) in "ILS LOC" mode.

Return values:

<Power> Measured DC power of the AF signal
Default unit: V

Manual operation: See ["DC"](#) on page 51

LLZ_BB_LEV_V

This command queries the measured power level in Volt for LF input in "ILS LOC" mode.

Return values:

<Power> Measured power of the LF input
Default unit: V

Manual operation: See "[Lev](#)" on page 51

LLZ_BB_VMAXPP_V

This command queries the maximum peak-to-peak power level in Volt for LF input in "ILS LOC" mode.

Return values:

<Power> Maximum peak-to-peak power of the LF input
Default unit: V

Manual operation: See "[Vmax\(pp\)](#)" on page 51

9.2.5 Retrieving ID results

The following commands are required to retrieve ILS Loc identifier results.

ID_DASH_LENGTH	288
ID_DOT_LENGTH	288
ID_DOTDASH_GAP	289
ID_LETTER_GAP	289
ID_PERIOD	289
LASTID_TIME	289

ID_DASH_LENGTH

Queries the length of time a dash is transmitted in the used Morse code in "ILS LOC" mode

Return values:

<Time> Dash time of ID signal
Default unit: ms

Manual operation: See "[Dash Length](#)" on page 61

ID_DOT_LENGTH

Queries the length of time a dot is transmitted in the used Morse code in "ILS LOC" mode

Return values:

<Time> Dot time of ID signal
Default unit: ms

Manual operation: See "[Dot Length](#)" on page 61

ID_DOTDASH_GAP

Queries the length of time that passes between a transmitted dot and a dash in the used Morse code in "ILS LOC" mode.

Return values:

<Time> Dot-Dash gap time of ID signal
 Default unit: ms

Manual operation: See ["Dot-Dash Gap"](#) on page 61

ID_LETTER_GAP

Queries the length of time that passes between two transmitted letters in the used Morse code in "ILS LOC" mode.

Return values:

<Time> Letter gap time of ID signal
 Default unit: ms

Manual operation: See ["Letter Gap"](#) on page 61

ID_PERIOD

Queries the periodic time between two measured ID pulses in "ILS LOC" mode.

Return values:

<Time> Periodic time between two ID pulses.
 Default unit: s

Manual operation: See ["ID Period"](#) on page 61

LASTID_TIME

Queries the time since last valid ID pulse was measured in "ILS LOC" mode.

Return values:

<Time> Time since last valid ID pulse
 Default unit: s

Manual operation: See ["Last ID"](#) on page 61

9.2.6 Deprecated commands

The following commands are maintained for compatibility with former Rohde & Schwarz analyzers only. For new remote control programs, use the commands described in [Chapter 9.2.1, "Configuring the ILS LOC and GP modes"](#), on page 260 and [Chapter 9.12, "Data management"](#), on page 360.

[MEASMODE?](#).....290
[MEASMODE](#)..... 290

LLZ.....	290
GS.....	291
FA0.....	291
FA1.....	291
FA2.....	291
FA3.....	292
FA4.....	292
FA5.....	292

MEASMODE?**MEASMODE** <Measurement mode>

This command sets the current LLZ or GS measurement mode and the associated threshold distortion values.

Parameters:

<Measurement mode>

CRS+CLR_MOD

Sets the Course and Clearance measurement mode.

COURSE_MOD

Sets the Course measurement mode.

CLEAR_MOD

Sets the Clearance measurement mode.

CRS|CLR_MOD

Sets Course or Clearance measurement mode.

SINGLE_MOD

Sets single frequency measurement mode.

WIDEBAND_MOD

Sets wideband frequency measurement mode.

CRS+CLR_THD

Sets the Course and Clearance THD distortion value.

COURSE_THD

Sets the Course THD distortion value.

CLEAR_THD

Sets the Clearance THD distortion value.

SINGLE_THD

Sets single frequency THD distortion value.

WIDEBAND_THD

Sets wideband frequency THD distortion value.

Return values:

<State>

READY.

The command was executed successfully.

LLZ

This command switches the mode to the "ILS LOC" mode. The LLZ command is identical to the `MODE_LOC` command.

Parameters:

<State>

READY.

The command was executed successfully.

GS

This command switches the mode to the "ILS GP" mode. The GS command is identical to the `MODE_GP` command.

Parameters:

<State>

READY.

The command was executed successfully.

FA0

This command stops the continuous output that was started with FA1, FA2, FA4, FA5, STREAM.

Return values:

<State>

READY.

The command was executed successfully.

FA1

This command activates the continuous output of DDM /level measurement results. The output rate is defined by the current measurement time. Values are separated by a TAB (ASC 09) DDM [1] RF level [dBm].

The command FA0 stops the output.

Return values:

<State>

READY.

The command was executed successfully.

FA2

This command activates the continuous repetition of a set of values. The output rate is defined by the current measurement time.

All values are transmitted as integer values, multiplied with a constant factor:

- DDM [1], Multiplier: 10000
- RF level [dBm], Multiplier: 10
- AM-Mod90 [%], Multiplier: 100
- AM-Mod150 [%], Multiplier: 100

The command FA0 stops the output.

Return values:

<State>

READY.

The command was executed successfully.

FA3

The same output format as [FA2](#) on page 291, but the values are only transmitted when triggered by another FA3 command. Note that this behavior is different from EVS200, where the trigger is an arbitrary ASCII character.

Return values:

<State> **READY.**
The command was executed successfully.

FA4

The same as [FA1](#) on page 291, but output is preceded by a timestamp.

Return values:

<State> **READY.**
The command was executed successfully.

FA5

The same as [FA1](#) on page 291, but output is preceded by the time in ms since the FA5 is started.

The command FA0 stops the output.

Return values:

<State> **READY.**
The command was executed successfully.

9.3 ILS marker beacon (MB) mode

The following commands are required to configure and perform measurements in the ILS Marker beacon mode.

- [Configuring ILS MB measurements](#).....292
- [Retrieving ILS MB results](#).....294
- [Retrieving ILS MB identifier results](#).....296
- [Deprecated commands](#).....298

9.3.1 Configuring ILS MB measurements

The following commands are required to configure ILS MB measurements.

MODE_MB	293
MB_DEFAULT_FREQSTEP?	293
MB_DEFAULT_FREQSTEP	293
MB_DEM_BW?	293
MB_DEM_BW	293
VIEW_MB?	293

MB_TRIG_EDGE?	293
MB_TRIG_EDGE	293
MB_TRIG_SOURCE?	294
MB_TRIG_SOURCE	294
VIEW_MB	294

MODE_MB

The `MODE_MB` command is identical to the `MB` command.

For description, see [MB](#) on page 259.

MB_DEFAULT_FREQSTEP? <StepSize>

MB_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default RF frequency step size in "ILS MB" mode.

Parameters:

<StepSize> 8.33_KHZ | 12.5_KHZ | 25_KHZ | 50_KHZ
 *RST: 50_KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

MB_DEM_BW?

MB_DEM_BW <Bandwidth>

Gets or sets the demodulator bandwidth in "ILS MB" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
 50KHZ
 Demodulator bandwidth

Return values:

<State> **READY.**
 The command was executed successfully.

VIEW_MB?

MB_TRIG_EDGE? <TrigEdge>

MB_TRIG_EDGE <TrigEdge>

Gets or sets whether triggering occurs when the signal rises to the trigger level or falls down to it in "ILS MB" mode.

Parameters:

<TrigEdge> POSITIVE | NEGATIVE
 POSITIVE
 Triggers when the signal rises to the trigger level

NEGATIVE

Triggers when the signal falls down to the trigger level

Return values:

<State>

READY.

The command was executed successfully.

MB_TRIG_SOURCE? <TrigSource>

MB_TRIG_SOURCE <TrigSource>

Gets or sets the trigger source in "ILS MB" mode.

Parameters:

<TrigSource> OFF | TIME | EXT

OFF

Free run mode, no trigger used

TIME

Time trigger

EXT

External trigger

Return values:

<State>

READY.

The command was executed successfully.

VIEW_MB <View type>

This command selects a view type for the MB mode.

Parameters:

<View type> MAIN | DIST | LOG

Available views for the MB mode.

Return values:

<State>

READY.

The command was executed successfully.

9.3.2 Retrieving ILS MB results

The following commands are required to retrieve results from ILS MB measurements.

Useful commands for retrieving results described elsewhere:

- [GETDATADEF](#) on page 366
- [GETDATASET](#) on page 366

Remote commands exclusive to ILS MB results:

FMEAS	295
AF4	295
AF5	295

AF6.....	295
AF7.....	295
AM4.....	295
AM5.....	296
AM6.....	296
AM7.....	296

FMEAS

This command queries the measured value of RF frequency.

Return values:

<kHz> Provides the value of measured RF frequency in kHz.

AF4

This command queries the AF frequency of 3000 Hz signal.

Return values:

<Hz> Provides the AF4 frequency in Hz.

Manual operation: See "[Freq 3000 Hz](#)" on page 80

AF5

This command queries the AF frequency of 1300 Hz signal.

Return values:

<Hz> Provides the AF5 frequency in Hz.

Manual operation: See "[Freq 1300 Hz](#)" on page 80

AF6

This command queries the AF frequency of 400 Hz signal.

Return values:

<Hz> Provides the AF6 frequency in Hz.

Manual operation: See "[Freq 400 Hz](#)" on page 79

AF7

This command queries the AF frequency of the identifier.

Return values:

<Hz> Provides the identifier's frequency in Hz.

AM4

This command queries the AM modulation of 3000 Hz signal.

Return values:

<%> Provides the AM4 modulation in %.

Manual operation: See "AM 3000 Hz" on page 80

AM5

This command queries the AM modulation of 1300 Hz signal.

Return values:

<%> Provides the AM5 modulation in %.

Manual operation: See "AM 1300 Hz" on page 79

AM6

This command queries the AM modulation of 400 Hz signal.

Return values:

<%> Provides the AM6 modulation in %.

Manual operation: See "AM 400 Hz" on page 79

AM7

This command queries the AM modulation of the identifier.

Return values:

<%> Provides the AM7 modulation in %.

9.3.3 Retrieving ILS MB identifier results

The following commands are required to retrieve identifier results from ILS MB measurements.

ID_F400_DASHLEN.....	296
ID_F1300_DASHLEN.....	297
ID_F1300_DOTLEN.....	297
ID_F3000_DOTLEN.....	297
ID_F400_GAP.....	297
ID_F1300_GAP.....	297
ID_F3000_GAP.....	298

ID_F400_DASHLEN

Queries the dash time of 400 Hz signal in "ILS" MB mode.

Return values:

<Time> Length of time a dash for the outer marker.
Default unit: ms

Manual operation: See "400 Hz Dash" on page 81

ID_F1300_DASHLEN

Queries the dash time of 1300 Hz signal in "ILS" MB mode.

Return values:

<Time> Length of time a dash is transmitted for the middle marker.
Default unit: ms

Manual operation: See ["1300 Hz Dash"](#) on page 81

ID_F1300_DOTLEN

Queries the dot time of 1300 Hz signal in "ILS" MB mode.

Return values:

<Time> Length of time a dot is transmitted for the middle marker.
Default unit: ms

Manual operation: See ["1300 Hz Dot"](#) on page 81

ID_F3000_DOTLEN

Queries the dot time of 3000 Hz signal in "ILS" MB mode.

Return values:

<Time> Length of time a dot is transmitted for the inner marker.
Default unit: ms

Manual operation: See ["3000 Hz Dot"](#) on page 81

ID_F400_GAP

Queries the dash-dash gap time of 400 Hz signal in "ILS MB" mode.

Return values:

<Time> Length of time that passes between two transmitted dashes for the outer marker.
Default unit: ms

Manual operation: See ["400 Hz Gap"](#) on page 81

ID_F1300_GAP

Queries the dash-dot gap time of 1300 Hz signal in "ILS MB" mode.

Return values:

<Time> Length of time that passes between a transmitted dot and a dash for the middle marker.
Default unit: ms

Manual operation: See ["1300 Hz Gap"](#) on page 81

ID_F3000_GAP

Queries the dot-dot gap time of 3000 Hz signal in "ILS MB" mode.

Return values:
 <Time> Length of time that passes between two transmitted dots for the inner marker.
 Default unit: ms
Manual operation: See "3000 Hz Gap" on page 81

9.3.4 Deprecated commands

The following commands are maintained for compatibility with former Rohde & Schwarz analyzers only. For new remote control programs, use the commands described in [Chapter 9.3.1, "Configuring ILS MB measurements"](#), on page 292 and [Chapter 9.12, "Data management"](#), on page 360.

FA0.....	298
FA2.....	298

FA0

This command stops the continuous output that was started with FA2.

Return values:
 <State> **READY.**
 The command was executed successfully.

FA2

This command activates the continuous repetition of a set of values. The output rate is defined by the current measurement time.

All values are transmitted as integer values, multiplied with a constant factor.

The following multipliers are applied:

- 10 for RF level [dBm]
- 100 for AM-Mod400 [%]
- 100 for AM-Mod1300 [%]
- 100 for AM-Mod3000 [%]
- 100 for AM-Mod ID [%]

The command FA0 stops the output.

Return values:
 <State> **READY.**
 The command was executed successfully.

9.4 VOR mode

The following commands are required to configure and perform measurements in the VOR mode. They are only available if the R&S EVSG-K2 VOR analysis option is installed.

- [Configuring VOR measurements](#)..... 299
- [Retrieving VOR results](#)..... 304
- [Deprecated commands](#)..... 308

9.4.1 Configuring VOR measurements

The following commands are required to configure VOR measurements.

Useful commands for VOR measurements described elsewhere:

- [RFCH](#) on page 231

Remote commands exclusive to VOR measurements:

MODE_VOR	300
VIEW_VOR?	300
VIEW_VOR	300
VOR_BB_BW_KHZ?	300
VOR_BB_BW_KHZ	300
VOR_BB_LFIN_DCOFFSETV?	300
VOR_BB_LFIN_DCOFFSETV	300
VOR_DEFAULT_FREQSTEP?	301
VOR_DEFAULT_FREQSTEP	301
VOR_DEM_AM_BW?	301
VOR_DEM_AM_BW	301
VOR_DEM_BEARFILTER?	301
VOR_DEM_BEARFILTER	301
VOR_DEM_BW?	301
VOR_DEM_BW	301
VOR_DEM_FM_BW?	302
VOR_DEM_FM_BW	302
VOR_DEMFREQS_OFFSET?	302
VOR_DEMFREQS_OFFSET	302
VOR_ID_STAT?	302
VOR_ID_STAT	302
VOR_RFLF_INPUT?	303
VOR_RFLF_INPUT	303
VOR_TRIG_EDGE?	303
VOR_TRIG_EDGE	303
VOR_TRIG_SOURCE?	303
VOR_TRIG_SOURCE	303

MODE_VOR

The `MODE_VOR` command is identical to the `MV` command.

For description, see [MV](#) on page 259.

VIEW_VOR?

VIEW_VOR <View type>

This command selects a view type for the VOR mode.

Parameters:

<View type>

MAIN | DIST | ID | LOG

Available views for VOR mode.

Return values:

<State>

READY.

The command was executed successfully.

VOR_BB_BW_KHZ? <Bandwidth>

VOR_BB_BW_KHZ <Bandwidth>

This command gets or sets the bandwidth for LF input in "VOR" mode.

Parameters:

<Bandwidth>

1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
50KHZ

Bandwidth

Default unit: kHz

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Bandwidth \(IF BW/AF In BW\)"](#) on page 73

VOR_BB_LFIN_DCOFFSETV? <DCOffset>

VOR_BB_LFIN_DCOFFSETV <DCOffset>

This command gets or sets the DC offset for LF input in "VOR" mode.

Parameters:

<DCOffset>

Power offset of the LF input at 0 Hz.

Default unit: V

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["DC Reference"](#) on page 72

VOR_DEFAULT_FREQSTEP? <StepSize>
VOR_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default RF frequency step size in "VOR" mode.

Parameters:

<StepSize> 8.33_KHZ | 12.5_KHZ | 25_KHZ | 50_KHZ
 *RST: 50_KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Step Size"](#) on page 68

VOR_DEM_AM_BW?
VOR_DEM_AM_BW <Bandwidth>

Gets or sets the demodulator bandwidth for the AM 30 Hz modulation in "VOR" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["AM30 BW"](#) on page 104

VOR_DEM_BEARFILTER? <Type>
VOR_DEM_BEARFILTER <Type>

Defines the filter type used to determine the bearing angle.

Parameters:

<Type> **NARROW**
 For small input levels
WIDE
 Faster; used in previous software releases
 *RST: WIDE

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Bear.Filt."](#) on page 104

VOR_DEM_BW?
VOR_DEM_BW <Bandwidth>

Gets or sets the demodulator Bandwidth in "VOR" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF BW"](#) on page 104

VOR_DEM_FM_BW?

VOR_DEM_FM_BW <Bandwidth>

Gets or sets the demodulator bandwidth for the FM 9960 Hz modulation in "VOR" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["FM BW"](#) on page 104

VOR_DEMFREQS_OFFSET? <Freq. Offset>

VOR_DEMFREQS_OFFSET <Freq. Offset>

Gets or sets a frequency offset of the carrier frequency in "VOR" mode.

Parameters:

<Freq. Offset> Frequency offset
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Freq Offset"](#) on page 102

VOR_ID_STAT?

VOR_ID_STAT <State>

Enables or disables the ID statistics calculation in VOR measurements.

Parameters:

<State> **ON**
The ID code is determined as the most probable code based on the previous decoding results.
OFF
The most recently decoded ID is used.

VOR_RFLF_INPUT? <Input>

VOR_RFLF_INPUT <Input>

Configures the input source for the receiver in "VOR" mode.

Parameters:

<Input>

RX_IN

RF input from RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000

LF_IN

An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Input RF/LF"](#) on page 63

VOR_TRIG_EDGE? <TrigEdge>

VOR_TRIG_EDGE <TrigEdge>

Gets or sets whether triggering occurs when the signal rises to the trigger level or falls down to it in "VOR" mode.

Parameters:

<TrigEdge>

POSITIVE | NEGATIVE

POSITIVE

Triggers when the signal rises to the trigger level

NEGATIVE

Triggers when the signal falls down to the trigger level

Return values:

<State>

READY.

The command was executed successfully.

VOR_TRIG_SOURCE? <TrigSource>

VOR_TRIG_SOURCE <TrigSource>

Gets or sets the trigger source in "VOR" mode.

Parameters:

<TrigSource>

OFF | TIME | EXT

OFF

Free run mode, no trigger used

TIME

time trigger

EXT

external trigger

Return values:

<State>

READY.

The command was executed successfully.

9.4.2 Retrieving VOR results

The following commands are required to retrieve results from VOR measurements.

Useful commands for retrieving results described elsewhere:

- [GETDATADEF](#) on page 366
- [GETDATASET](#) on page 366

Remote commands exclusive to VOR results:

AC8	304
AF0	304
AF1	305
AF2	305
AF8	305
AM0	305
AM1	305
AM8	305
AM9	306
BE?	306
BE_TO?	306
BE	306
DIST_9960	306
FM0	306
FM1	306
FMEAS	307
SUBCARR_AM1K44	307
SUBCARR_AM1K50	307
SUBCARR_AM60HZ	307
SUBCARR_K2	307
SUBCARR_K3	307
SUBCARR_K4	308
SUBCARR_K5	308

AC8

This command queries the CODE of an identifier.

Return values:

<CODE>

Code of an identifier

Manual operation: See ["ID Code"](#) on page 56

AF0

This command queries the AF frequency of the 30 Hz signal.

Return values:

<[Hz]> AF frequency of 30 Hz signal

Manual operation: See "[Freq 30 Hz](#)" on page 95

AF1

This command queries the AF frequency of the 9960 Hz signal.

Return values:

<[Hz]> AF frequency 9960 Hz signal

Manual operation: See "[Freq 9960 Hz](#)" on page 95

AF2

This command queries the AF frequency of the FM 30 Hz signal.

Return values:

<[Hz]> AF frequency of FM 30 Hz signal

Manual operation: See "[Freq FM30](#)" on page 95

AF8

This command queries the AF frequency of identifier.

Return values:

<[Hz]> Identifier AF frequency

Manual operation: See "[ID Freq](#)" on page 61

AM0

This command queries the modulation of the 30 Hz signal.

Return values:

<[%]> 30 Hz signal modulation

Manual operation: See "[AM 30 Hz](#)" on page 94

AM1

This command queries the modulation of the 9960 Hz signal.

Return values:

<[%]> 9960 Hz signal modulation

Manual operation: See "[AM 9960 Hz](#)" on page 94

AM8

This command queries the modulation of identifier.

Return values:

<[%]> Identifier modulation

Manual operation: See ["ID AM"](#) on page 61

AM9

This command queries the modulation of voice.

Return values:

<[%]> Voice modulation

Manual operation: See ["Voice AM"](#) on page 95

BE?**BE_TO?****BE**

This command queries the bearing angle.

Return values:

<[°]> Bearing angle in [°].

Manual operation: See ["Bearing \(from\)"](#) on page 94

DIST_9960

This command queries the AM distortion of the 9960 Hz signal.

Return values:

<[%]> AM distortion of 9960 Hz signal

FM0

This command queries the FM deviation.

Return values:

<[Hz]> FM deviation

Manual operation: See ["FM-Deviation"](#) on page 95

FM1

This command queries the FM index.

Return values:

<[1]> FM index (dimensionless)

Manual operation: See ["FM Index"](#) on page 95

FMEAS

This command queries the measured value of the RF frequency.

Return values:

<Hz> Measured RF frequency

SUBCARR_AM1K44

Queries the AM distortion at 1440 Hz (48 segments * 30 Hz) in "VOR" mode.

Return values:

<Distortion> Distortion
Default unit: %

Manual operation: See ["Subcarrier AM Distortion"](#) on page 96

SUBCARR_AM1K50

Queries the AM distortion at 1500 Hz (50 segments * 30 Hz) in "VOR" mode.

Return values:

<Distortion> Distortion
Default unit: %

Manual operation: See ["Subcarrier AM Distortion"](#) on page 96

SUBCARR_AM60HZ

Queries the AM distortion at a modulation frequency of 60 Hz in "VOR" mode.

Return values:

<Distortion> Distortion
Default unit: %

Manual operation: See ["Subcarrier AM Distortion"](#) on page 96

SUBCARR_K2

Queries K2 subcarrier harmonic of VOR signal in "VOR" mode.

Return values:

<Distortion> Distortion 2nd order
Default unit: dB

Manual operation: See ["Subcarrier Harmonics"](#) on page 96

SUBCARR_K3

Queries K3subcarrier harmonic of VOR signal in "VOR" mode.

Return values:

<Distortion> Distortion 3rd order
 Default unit: dB

Manual operation: See ["Subcarrier Harmonics"](#) on page 96

SUBCARR_K4

Queries K4 subcarrier harmonic of VOR signal in "VOR" mode.

Return values:

<Distortion> Distortion 4th order
 Default unit: dB

Manual operation: See ["Subcarrier Harmonics"](#) on page 96

SUBCARR_K5

Queries K5 subcarrier harmonic of VOR signal in "VOR" mode.

Return values:

<Distortion> Distortion 5th order
 Default unit: dB

Manual operation: See ["Subcarrier Harmonics"](#) on page 96

9.4.3 Deprecated commands

The following commands are maintained for compatibility with former Rohde & Schwarz analyzers only. For new remote control programs, use the commands described in [Chapter 9.4.1, "Configuring VOR measurements"](#), on page 299 and [Chapter 9.12, "Data management"](#), on page 360.

FA2	308
FA0	309

FA2

This command activates the continuous repetition of a set of values. The output rate is defined by the current measurement time.

All values are transmitted as integer values, multiplied with a constant factor.

The following multipliers are applied:

- 10 for RF level [dBm]
- 100 for Bearing [DEG]
- 100 for AM-Mod30 [%]
- 100 for AM-Mod9960 [%]
- 10 for FM-Deviation [Hz]
- 10 for FM-Index [1]

The command FA0 stops the output.

Return values:

<State> **READY.**
The command was executed successfully.

FA0

This command stops the continuous output that was started with FA2.

Return values:

<State> **READY.**
The command was executed successfully.

9.5 COM mode

The following commands are required to configure and perform measurements in the COM mode. They are only available if the R&S EVSG-K6 COM analysis option is installed.

- [Configuring COM measurements](#).....309
- [Retrieving COM results](#).....313

9.5.1 Configuring COM measurements

The following commands are required to configure COM measurements.

MODE_COM	310
VIEW_COM?	310
VIEW_COM	310
AMFREQ_OFFSET_TX1?	310
AMFREQ_OFFSET_TX1	310
AMFREQ_OFFSET_TX2?	310
AMFREQ_OFFSET_TX2	310
COM_1F2F_MEASMODE?	311
COM_1F2F_MEASMODE	311
COM_DEFAULT_FREQSTEP?	311
COM_DEFAULT_FREQSTEP	311
COM_DEMOD_BW_1F?	311
COM_DEMOD_BW_1F	311
COM_DEMOD_BW_2F?	311
COM_DEMOD_BW_2F	311
COM_TONEFREQ_1K01K2?	312
COM_TONEFREQ_1K01K2	312
COM_TRIG_EDGE?	312
COM_TRIG_EDGE	312
COM_TRIG_SOURCE?	312
COM_TRIG_SOURCE	312

RF_MHZ_5DECIMALS?	313
RF_MHZ_5DECIMALS	313

MODE_COM

This command switches the instrument to the "COM" mode.

Return values:

<State> **READY.**
The command was executed successfully.

VIEW_COM?

VIEW_COM

Gets or sets the view in "COM" mode.

Parameters:

<View type> **MAIN_1_0kHz | MAIN_1_2kHz | REC**
Available views for COM mode.

Return values:

<State> **READY.**
The command was executed successfully.

AMFREQ_OFFSET_TX1?

AMFREQ_OFFSET_TX1 <Freq>

Gets or sets the demodulator upper frequency offset in "COM" mode.

Parameters:

<Freq> Demodulator upper frequency offset.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["TX1 Offset/TX2 Offset"](#) on page 112

AMFREQ_OFFSET_TX2?

AMFREQ_OFFSET_TX2 <Freq>

Gets or Sets the demodulator lower frequency offset in "COM" mode.

Parameters:

<Freq> Demodulator lower frequency offset.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["TX1 Offset/TX2 Offset"](#) on page 112

COM_1F2F_MEASMODE? <Mode>
COM_1F2F_MEASMODE <Mode>

Selects the number of frequencies or channels to be measured.

Parameters:

<Mode>

1F

One frequency only is measured, namely the nominal frequency, which is also the center frequency.

2F

Two frequencies are measured at the same time. Which frequencies are measured is configured by the [AMFREQ_OFFSET_TX1](#) and [AMFREQ_OFFSET_TX2](#) commands.

Manual operation: See ["1F/2F"](#) on page 111

COM_DEFAULT_FREQSTEP? <StepSize>
COM_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default RF frequency step size in "COM" mode.

Parameters:

<StepSize>

8.33_KHZ | 12.5_KHZ | 25_KHZ | 50_KHZ

*RST: 50_KHZ

Return values:

<State>

READY.

The command was executed successfully.

COM_DEMOD_BW_1F?
COM_DEMOD_BW_1F <Bandwidth>

Gets or sets the 1F demodulator bandwidth in "COM" mode.

Parameters:

<Bandwidth>

1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["BW 1F BW 2F"](#) on page 114

COM_DEMOD_BW_2F?
COM_DEMOD_BW_2F <Bandwidth>

Gets or sets the 2F demodulator bandwidth in "COM" mode.

Parameters:

<Bandwidth>

1KHZ | 3KHZ | 6KHZ | 10KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["BW 1F BW 2F"](#) on page 114

COM_TONEFREQ_1K01K2? <Frequency>

COM_TONEFREQ_1K01K2 <Frequency>

Gets or sets the tone frequency to measure AM and distortion values in "COM" mode.

Parameters:

<Frequency> Tone frequency
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Tone Freq."](#) on page 112

COM_TRIG_EDGE? <TrigEdge>

COM_TRIG_EDGE <TrigEdge>

Gets or sets whether triggering occurs when the signal rises to the trigger level or falls down to it in "COM" mode.

Parameters:

<TrigEdge> POSITIVE | NEGATIVE

POSITIVE
Triggers when the signal rises to the trigger level
NEGATIVE
Triggers when the signal falls down to the trigger level

Return values:

<State> **READY.**
The command was executed successfully.

COM_TRIG_SOURCE? <TrigSource>

COM_TRIG_SOURCE <TrigSource>

Gets or sets the trigger source in "COM" mode.

Parameters:

<TrigSource> OFF | TIME | EXT

OFF
Free run mode, no trigger used
TIME
Time trigger
EXT
External trigger

Return values:

<State>

READY.

The command was executed successfully.

RF_MHZ_5DECIMALS?**RF_MHZ_5DECIMALS** <Frequency>

Gets or sets RF frequency in "COM" mode.

Parameters:

<Frequency>

RF frequency

Default unit: MHz

Return values:

<State>

READY.

The command was executed successfully.

9.5.2 Retrieving COM results

The following commands are required to retrieve results from COM measurements.

GET_K2_1K0.....	314
GET_K2_1K2.....	314
GET_K3_1K0.....	314
GET_K3_1K2.....	314
GET_K4_1K0.....	314
GET_K4_1K2.....	315
GET_MEASFREQ.....	315
GET_ONE_AMFREQ_1_0.....	315
GET_ONE_AMFREQ_1_2.....	315
GET_ONE_AMMOD_1_0.....	315
GET_ONE_AMMOD_1_2.....	315
GET_ONE_SINAD_1_0.....	316
GET_ONE_SINAD_1_2.....	316
GET_ONE_THD_1_0.....	316
GET_ONE_THD_1_2.....	316
GET_THD_1K0.....	316
GET_THD_1K2.....	317
GET_TX1_AMFREQ_1_0.....	317
GET_TX1_AMFREQ_1_2.....	317
GET_TX1_AMMOD_1_0.....	317
GET_TX1_AMMOD_1_2.....	317
GET_TX1_LEVEL.....	318
GET_TX1_MEASFREQ.....	318
GET_TX1_SINAD_1_0.....	318
GET_TX1_SINAD_1_2.....	318
GET_TX1_THD_1_0.....	318
GET_TX1_THD_1_2.....	318
GET_TX2_AMFREQ_1_0.....	319
GET_TX2_AMFREQ_1_2.....	319

GET_TX2_AMMOD_1_0.....	319
GET_TX2_AMMOD_1_2.....	319
GET_TX2_LEVEL.....	319
GET_TX2_MEASFREQ.....	320
GET_TX2_SINAD_1_0.....	320
GET_TX2_SINAD_1_2.....	320
GET_TX2_THD_1_0.....	320
GET_TX2_THD_1_2.....	320

GET_K2_1K0

This command queries the K2 distortion parameter of 1.0 kHz signal.

Return values:

<[%]> K2 distortion value of 1.0 kHz signal

Manual operation: See "[K2 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_K2_1K2

This command queries the K2 distortion parameter of 1.2 kHz signal.

Return values:

<[%]> K2 distortion value of 1.2 kHz signal

Manual operation: See "[K2 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_K3_1K0

This command queries the K3 distortion parameter of 1.0 kHz signal.

Return values:

<[%]> K3 distortion value of 1.0 kHz signal

Manual operation: See "[K3 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_K3_1K2

This command queries the K3 distortion parameter of 1.2 kHz signal.

Return values:

<[%]> K3 distortion value of 1.2 kHz signal

Manual operation: See "[K3 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_K4_1K0

This command queries the K4 distortion parameter of 1.0 kHz signal.

Return values:

<[%]> K4 distortion value of 1.0 kHz signal

Manual operation: See "[K4 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_K4_1K2

This command queries the K4 distortion parameter of 1.2 kHz signal.

Return values:

<[%]> K4 distortion value of 1.2 kHz signal

Manual operation: See "[K4 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_MEASFREQ

Query the measured value of delta RF carrier frequency to set RF frequency in "COM" mode.

Return values:

<freq> Delta between measured and set RF frequency.
Default unit: kHz

GET_ONE_AMFREQ_1_0

Query the AF frequency of 1F 1.0 kHz signal in "COM" mode.

Return values:

<Freq> AF frequency of 1F 1.0 kHz signal.
Default unit: Hz

Manual operation: See "[Freq 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_ONE_AMFREQ_1_2

Query the AF frequency of 1F 1.2 kHz signal in "COM" mode.

Return values:

<Freq> AF frequency of 1F 1.2 kHz signal.
Default unit: Hz

Manual operation: See "[Freq 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_ONE_AMMOD_1_0

Query the AM modulation depth of the 1.0 kHz signal in "COM" mode.

Return values:

<ModDepth> AM modulation depth
Default unit: %

Manual operation: See "[AM 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_ONE_AMMOD_1_2

Query the AM modulation depth of 1.2 kHz signal in "COM" mode.

Return values:

<ModDepth> AM modulation depth
Default unit: %

Manual operation: See ["AM 1.0 kHz/ 1.2 kHz"](#) on page 109

GET_ONE_SINAD_1_0

Query the SINAD frequency of 1F 1.0 kHz signal in "COM" mode.

Return values:

<Freq> SINAD frequency of 1F 1.0 kHz signal.
Default unit: Hz

GET_ONE_SINAD_1_2

Query the SINAD frequency of 1F 1.2 kHz signal in "COM" mode.

Return values:

<Freq> SINAD frequency of 1F 1.2 kHz signal.
Default unit: Hz

GET_ONE_THD_1_0

Query the THD value of 1F 1.0 kHz signal in "COM" mode.

Return values:

<Freq> THD value of 1F 1.0 kHz signal.
Default unit: Hz

GET_ONE_THD_1_2

Query the THD value of 1F 1.2 kHz signal in "COM" mode.

Return values:

<Freq> THD value of 1F 1.2 kHz signal.
Default unit: Hz

GET_THD_1K0

This command queries the THD distortion parameter of 1.0 kHz signal.

Return values:

<[%]> THD distortion value of 1.0 kHz signal

Manual operation: See ["THD 1.0 kHz/ 1.2 kHz"](#) on page 110

GET_THD_1K2

This command queries the THD distortion parameter of 1.2 kHz signal.

Return values:

<[%]> THD distortion value of 1.2 kHz signal

Manual operation: See ["THD 1.0 kHz/ 1.2 kHz"](#) on page 110

GET_TX1_AMFREQ_1_0

Query the AF upper frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> AF upper frequency of 2F 1.0 kHz signal.
Default unit: Hz

Manual operation: See ["Freq 1.0 kHz/ 1.2 kHz"](#) on page 109

GET_TX1_AMFREQ_1_2

Query the AF upper frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> AF upper frequency of 2F 1.2 kHz signal.
Default unit: Hz

Manual operation: See ["Freq 1.0 kHz/ 1.2 kHz"](#) on page 109

GET_TX1_AMMOD_1_0

Query the TX1 AM modulation depth of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<ModDepth> TX1 AM modulation depth of 2F 1.0 kHz signal.
Default unit: %

Manual operation: See ["AM 1.0 kHz/ 1.2 kHz"](#) on page 109

GET_TX1_AMMOD_1_2

Query the TX1 AM modulation depth of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<ModDepth> TX1 AM modulation depth of 2F 1.2 kHz signal.
Default unit: %

Manual operation: See ["AM 1.0 kHz/ 1.2 kHz"](#) on page 109

GET_TX1_LEVEL

Query TX1 RF signal level in "COM" mode.

Return values:

<level> RF signal level of TX1
Default unit: dBm

GET_TX1_MEASFREQ

Query the measured value of delta TX1 RF carrier frequency to set RF frequency in "COM" mode.

Return values:

<freq> Delta between measured TX1 frequency and set RF frequency.
Default unit: kHz

GET_TX1_SINAD_1_0

Query the SINAD of upper frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> SINAD of upper frequency of 2F 1.0 kHz signal.
Default unit: Hz

GET_TX1_SINAD_1_2

Query the SINAD of upper frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> SINAD of upper frequency of 2F 1.2 kHz signal.
Default unit: Hz

GET_TX1_THD_1_0

Query the THD of upper frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> THD of upper frequency of 2F 1.0 kHz signal.
Default unit: Hz

GET_TX1_THD_1_2

Query the THD of upper frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> THD of upper frequency of 2F 1.2 kHz signal.
Default unit: Hz

GET_TX2_AMFREQ_1_0

Query the AF lower frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> AF lower frequency of 2F 1.0 kHz signal.
Default unit: Hz

Manual operation: See "[Freq 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_TX2_AMFREQ_1_2

Query the AF lower frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> AF lower frequency of 2F 1.2 kHz signal.
Default unit: Hz

Manual operation: See "[Freq 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_TX2_AMMOD_1_0

Query the TX2 AM modulation depth of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<ModDepth> TX2 AM modulation depth of 2F 1.0 kHz signal.
Default unit: %

Manual operation: See "[AM 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_TX2_AMMOD_1_2

Query the TX2 AM modulation depth of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<ModDepth> TX2 AM modulation depth of 2F 1.2 kHz signal.
Default unit: %

Manual operation: See "[AM 1.0 kHz/ 1.2 kHz](#)" on page 109

GET_TX2_LEVEL

Query TX2 RF signal level in "COM" mode.

Return values:

<level> RF signal level of TX2
Default unit: dBm

GET_TX2_MEASFREQ

Query the measured value of delta TX2 RF carrier frequency to set RF frequency in "COM" mode.

Return values:

<freq> Delta between measured TX2 frequency and set RF frequency.
Default unit: kHz

GET_TX2_SINAD_1_0

Query the SINAD of lower frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> SINAD of lower frequency of 2F 1.0 kHz signal.
Default unit: Hz

GET_TX2_SINAD_1_2

Query the SINAD of lower frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> SINAD of lower frequency of 2F 1.2 kHz signal.
Default unit: Hz

GET_TX2_THD_1_0

Query the THD of lower frequency of 2F 1.0 kHz signal in "COM" mode.

Parameters:

<Freq> THD of lower frequency of 2F 1.0 kHz signal.
Default unit: Hz

GET_TX2_THD_1_2

Query the THD of lower frequency of 2F 1.2 kHz signal in "COM" mode.

Parameters:

<Freq> THD of lower frequency of 2F 1.2 kHz signal.
Default unit: Hz

9.6 GBAS/ SCAT-I mode

The following commands are required to configure and perform measurements in the GBAS/ SCAT-I mode. They are only available if the R&S EVSG-K4 GBAS analysis or R&S EVSG-K5 SCAT-I Analysis option is installed.

- [Configuring GBAS/ SCAT-I measurements](#).....321
- [Retrieving GBAS/ SCAT-I results](#).....325

9.6.1 Configuring GBAS/ SCAT-I measurements

The following commands are required to configure GBAS/ SCAT-I measurements.

Useful commands for configuring GBAS measurements described elsewhere:

- [MODE_GBAS](#) on page 324
- [GBAS:GETMEAS](#) on page 327

Remote commands exclusive to GBAS/ SCAT-I measurements

GBAS:ATTMODE?	321
GBAS:ATTMODE	321
GBAS:BUFFER_RUNPAUSE?	322
GBAS:BUFFER_RUNPAUSE	322
GBAS:EVM_ANGLE_NORM?	322
GBAS:EVM_ANGLE_NORM	322
GBAS:FMEAS?	323
GBAS:FREQRF?	323
GBAS:FREQRF	323
GBAS:LEV?	323
LA?	323
MODE_GBAS	324
GBAS:SCREENVIEW ?	324
GBAS:SCREENVIEW	324
GBAS:SEQN_SLOT?	324
GBAS:SEQN_SLOT	324
SETUP:GBAS_PPS_SOURCE?	324
SETUP:GBAS_PPS_SOURCE	324

GBAS:ATTMODE?

GBAS:ATTMODE <Mode>

Selects the attenuation of the "GBAS" mode.

Parameters:

<Mode>	AUTO Automatic attenuation
	LN Low noise attenuation

NORM

Normal attenuation

LD

Low distortion attenuation

<State>

READY.

The command was executed successfully.

Manual operation: See ["RF Mode"](#) on page 69
 See ["RF Att"](#) on page 176
 See ["RF Mode"](#) on page 176

GBAS:BUFFER_RUNPAUSE? <State>**GBAS:BUFFER_RUNPAUSE** <State>

This command determines whether the display is currently being updated.

Note that data recording and streaming continue regardless of the display update status.

Parameters:

<State>

RUN

Display is updated continuously.

PAUSE

Display is temporarily not updated.

Example:**Manual operation:** See ["Display Update Status \(Mode\)"](#) on page 161**GBAS:EVM_ANGLE_NORM?** <Mode>**GBAS:EVM_ANGLE_NORM** <Mode>

Determines the mode of EVM calculation for baseband input in "GBAS" mode.

Parameters:

<State>

READY.

The command was executed successfully.

Query parameters:

<Mode>

ANGLE | NORM

ANGLE

Only angle deviations are considered in EVM calculation.

NORM

Both angle and amplitude deviation are considered in EVM calculation.

Manual operation: See ["EVM RMS"](#) on page 166
 See ["EVM Mode"](#) on page 177

GBAS:FMEAS? <Slot>

This command queries the offset of the measured carrier frequency from the nominal frequency in "GBAS" mode.

Parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
Selects the slot for which results are queried.

Return values:

<Offset> Measured offset
Default unit: kHz

Usage: Query only

Manual operation: See "[Carrier frequency offset \(Offs. \[kHz\]\)](#)" on page 166

GBAS:FREQRF?**GBAS:FREQRF <Freq>**

Gets or sets the channel frequency that determines the carrier frequency at which the GBAS measurement is performed.

Parameters:

<Freq> RF frequency
The VHF data broadcast is defined for carrier frequencies within the range of 108.025 MHz to 117.950 MHz with a channel spacing of 25 kHz.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Frequency \(Freq\)](#)" on page 160

GBAS:LEV? <Slot>**LA? <Slot>**

Queries the arithmetic average of the burst power level measured over the period of the synchronization and ambiguity resolution field of the burst.

If no burst was detected, the arithmetic average of the noise power is returned.

Parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
Selects the slot for which results are queried.

Return values:

<Freq> Signal level
Default unit: dBm

Example: GBAS:LEV? 2

Usage: Query only

Manual operation: See "[Burst Level Average \(Av \[dBm\]\)](#)" on page 163

MODE_GBAS

This command starts GBAS mode.

Return values:

<State> **READY.**
Command was executed successfully.

GBAS:SCREENVIEW ? <View>

GBAS:SCREENVIEW <View>

This command sets or queries the displayed measurement view in "GBAS" mode.

Parameters:

<View> SEQUENCE | FRAME | BURST | CONSTELLATION |
MESSAGE | REC
*RST: SEQUENCE

<State> **READY.**
The command was executed successfully.

GBAS:SEQN_SLOT? <Slot>

GBAS:SEQN_SLOT <Slot>

Gets or sets the slot to be displayed in the power vs. time diagram and at the top of the results table in "GBAS" mode.

Parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
The slot for which results are determined.

Manual operation: See "[Slot](#)" on page 175

SETUP:GBAS_PPS_SOURCE?

SETUP:GBAS_PPS_SOURCE <Source>

Gets or sets the source of the PPS signal required as a time reference.

Parameters:

<Source> **PPS SMA**
Signal provided at the PPS In connector
PPS GPS
Signal provided at the RS232-GPS connector

9.6.2 Retrieving GBAS/ SCAT-I results

The following commands are required to retrieve results from GBAS/ SCAT-I measurements.

GBAS:EVM?	325
GBAS:FAILEDMSG?	325
GBAS:GBASBER?	326
GBAS:GBASID?	326
GBAS:GETMDEF	326
GBAS:GETMEAS	327
GBAS:GRAPH_TOLOGG?	329
GBAS:GRAPH_TOLOGG	329
GBAS:MSG_TOLOGG?	329
GBAS:MSG_TOLOGG	329
GBAS:LOGSLOTS	329
GBAS:PEAKLEV?	330
GBAS:PPSLOCKED?	330
GBAS:RESETBER	330
GBAS:STOPSTREAM	331
GBAS:STREAM	331
GBAS:VALIDMSG?	332

GBAS:EVM? <Slot>

Queries the error vector magnitude measured over the period of the burst.

If no burst was detected, the arithmetic average of the noise power is returned.

Query parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
Selects the slot for which results are queried.

Return values:

<Result> EVM
Default unit: %

Usage: Query only

Manual operation: See "EVM RMS" on page 166

GBAS:FAILEDMSG? <Slot>

Queries the number of failed GBAS messages within the period of the burst.

Query parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
Selects the slot for which results are queried.

Return values:

<Result> integer
 Number of failed messages
 Default unit: None.

Usage: Query only

GBAS:GBASBER? <Slot>

Queries the bit error rate (BER) before forward error correction (FEC).

Query parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
 Selects the slot for which results are queried.

Return values:

<Result> <bits_ok> / <bits_error>
 Default unit: None.

Usage: Query only

Manual operation: See ["Bit error rate \(BER\) before FEC"](#) on page 167

GBAS:GBASID? <Slot>

Queries the GBAS ID. If there is more than one message inside the burst, the first GBAS ID is displayed.

Query parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
 Selects the slot for which results are queried.

Return values:

<ID> 4-character identifier of the ground station broadcasting the message
 Default unit: None.

Usage: Query only

Manual operation: See ["GBAS ID"](#) on page 163

GBAS:GETMDEF <ParamSel>,<RX-board>

This command outputs the header columns for data delivered by [GBAS : GETMEAS](#).

Parameters:

<ParamSel> Determines which parameter selection is output.
FULL
 EVS300 compatibility mode

ALL

All values of the current measurement mode are sent as comma-separated text, using actual units.

MEDIUM

A fixed selection of parameters is exported.

SHORT

A short, fixed selection of parameters is exported.

RAW

Only the non-interpreted measurement values from the bit-stream in binary format are exported.

<RX-Board>

Selects the RX board for which results are exported.

1

RX board 1 selected

2

RX board 2 selected

1+2

Both RX boards selected

<Slot>

0 | 1 | 2 | 3 | 4 | 5 | 6 | 7

Selects the slot for which results are exported.

Return values:

<Results>

Comma-separated list of header data for the selected results.

<State>

READY.

The command was executed successfully.

GBAS:GETMEAS <ParamSel>, <RX-board>, <Slot>

This command outputs the current measurement result for one or both RX-boards.

For details on the parameters see [Chapter 6.4.3.2, "Slot results table"](#), on page 169.

Parameters:

<ParamSel>

Determines which parameter selection is output.

FULL

EVS300 compatibility mode

Channel, STIOCP, Index, Date, Slot, Time,
FREQ[MHz], Lev.Av[dBm], SSID, GBAS ID,
Train.FEC, App.Dat., App.FEC, GPS_lat.,
GPS_long., GPS_alt[m], GPS_speed[km/h],
GPS_date, GPS_time, GPS_Sat, GPS_Status,
GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C],
ATT.MODE, TrigCounter

ALL

All values of the current measurement mode are sent as comma-separated text, using actual units.

RX, STIOCP, Index, Date, Time, Slot, FREQ[MHz], C.Offset[kHz], Lev.Av[dBm], Lev.Pk[dBm], SSID, EVM[%], GBAS ID, Train.FEC, App.Dat., App.FEC, BER, Transm.Len, StartDelay[us], GuardInterv[us], RampUp[us], BurstDur[ms], RampDown[us], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], ATT.MODE, TrigCounter, RawData

MEDIUM

A fixed selection of parameters is exported.

RX, STIOCP, Index, Time, Slot, C.Offset[kHz], Lev.Av[dBm], GBAS ID, Train.FEC, App.Dat., App.FEC, GPS_lat., GPS_long., TrigCounter

SHORT

A short, fixed selection of parameters is exported.

RX, Index, Time, Slot, Lev.Av[dBm], GBAS ID, App.Dat., GPS_lat., GPS_long.

RAW

Only the non-interpreted measurement values from the bit-stream in binary format are exported.

<RX-Board>

Selects the RX board for which results are exported.

1

RX board 1 selected

2

RX board 2 selected

1+2

Both RX boards selected

<Slot>

0 | 1 | 2 | 3 | 4 | 5 | 6 | 7

Selects the slot for which results are exported.

Return values:

<Results>

Comma-separated list of selected results.

<State>

READY.

The command was executed successfully.

Example:

GETMEAS FULL, 1+2, 2

Returns all measurement results for slot 2 in all measurements on both receiver boards.

Manual operation: See "[Parameter](#)" on page 203

GBAS:GRAPH_TOLOGG? <Type>

GBAS:GRAPH_TOLOGG <State>

Defines whether graphical information is stored.

Parameters:

<State>

ON

Graphical information such as the time domain and constellation values are stored.

OFF

Graphical information is not stored.

Manual operation: See ["Graph Log"](#) on page 204

GBAS:MSG_TOLOGG? <Type>

GBAS:MSG_TOLOGG <Type>

This command defines which message information is stored for each slot.

Parameters:

<Type>

ALL

All message data (human-readable + bitstream) is stored (default).

TXT

Only the human-readable, interpreted message values are stored.

RAW

Only the decoded, non-interpreted message data from the bit-stream in binary format is stored.

NONE

Message data is not included in the slot data record.

*RST: ALL

Manual operation: See ["Msg Log"](#) on page 203

GBAS:LOGSLOTS <RX-board>,<Slot>

Selects the GBAS slot to be recorded with the data recorder.

Parameters:

<RX-board>

Selects the RX board for which results are exported.

1

RX board 1 selected

2

RX board 2 selected

1+2

Both RX boards selected

<Slot>

0 | 1 | 2 | 3 | 4 | 5 | 6 | 7

Selects the slot for which results are exported.

Return values:

<State> **READY**
 Command was executed successfully.

GBAS:PEAKLEV? <Slot>

Queries the peak burst power level measured over the period of the burst.
 If no burst was detected, the arithmetic average of the noise power is returned.

Query parameters:

<Slot> 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7
 Selects the slot for which results are queried.

Return values:

<Power> Signal level
 Default unit: dBm

Example: GBAS:PEAKLEV? 2

Usage: Query only

Manual operation: See "[Slot Level Peak \(Pk \[dBm\]\)](#)" on page 166

GBAS:PPSLOCKED? <Slot>

Queries the state of the PPS synchronization.

Return values:

<Result> **Unlocked**
 No valid PPS signal detected.
Burst Locked
 Valid burst detected.
PPS Locked
 Valid PPS signal detected

Usage: Query only

Manual operation: See "[Time reference status \(Time Ref.\)](#)" on page 161

GBAS:RESETBER

Resets the values for the following measurement results:

- "[Bit error rate \(BER\) before FEC](#)" on page 167
- "[Valid Bursts \(Valid B.\)](#)" on page 167
- "[Failed Bursts \(Failed B.\)](#)" on page 167

Parameters:

<State> **READY.**
 The command was executed successfully.

Usage: Event

Manual operation: See ["Reset BER"](#) on page 177

GBAS:STOPSTREAM

This command terminates the data stream for both RX Boards in GBAS mode.

Return values:

<State> **READY.**
The command was executed successfully.

GBAS:STREAM <ParamSel>, [+MSG,] <RX Board>, <Slots>

Starts data streaming. In streaming mode, a measured data set is automatically sent to the remote interface. One data set is provided per slot, that is: every 62.5 ms. Streaming can produce large quantities of output. It is mandatory to have a fast data connection and an application that is able to handle the data.

For details on the output see [Chapter 9.12.3.6, "GBAS mode"](#), on page 372

Parameters:

<ParamSel>	Determines which parameter selection is output. FULL EVS300 compatibility mode ALL All values of the current measurement mode are sent as comma-separated text, using actual units. MEDIUM A fixed selection of parameters is exported. SHORT A short, fixed selection of parameters is exported. RAW Only the non-interpreted measurement values from the bit-stream in binary format are exported.
+MSG	Optional: If specified, the message data is included in the data stream, surrounded by curly brackets { }.
<RX-Board>	Selects the RX board for which results are exported. 1 RX board 1 selected 2 RX board 2 selected 1+2 Both RX boards selected
<Slots>	0 1 2 3 4 5 6 7 Selects one or more slots for which results are exported. Multiple slots can be selected.

Return values:

<State>

READY.

The command was executed successfully.

Example:`GBAS:STREAM RAW,1+2,3`

Sends the data for slot 3 on both receiver boards as binary data to the USB output.

Example:`GBAS:STREAM ALL,1,01234567`

Outputs the evaluated data (without the message data) for all slots on receiver board 1.

Example:`GBAS:STREAM ALL+MSG,1,0`

Outputs all evaluated data, including message data, for slot 0 on receiver board 1.

GBAS:VALIDMSG? <Slot>

Queries the number of valid GBAS messages within the period of the burst.

Query parameters:

<Slot>

0 | 1 | 2 | 3 | 4 | 5 | 6 | 7

Selects the slot for which results are queried.

Return values:

<Result>

integer

Number of valid messages

Default unit: None.

Usage:

Query only

9.7 NDB mode

The following commands are required to configure and perform measurements in the NDB mode. They are only available if the R&S EVSG1-K7 LF-Analysis option is installed.

- [Configuring an NDB measurement](#).....332
- [Retrieving NDB measurement results](#).....335

9.7.1 Configuring an NDB measurement

The following commands are required to configure NDB measurements.

Useful commands for NDB measurements described elsewhere:

- [RFCH](#) on page 231
- [LA?](#) on page 231
- [MEASTIME](#) on page 231

- [SQUELCH](#) on page 239
- [SETATTMODE](#) on page 232
- [Chapter 9.2.5, "Retrieving ID results"](#), on page 288

Remote commands exclusive to NDB measurements:

MODE_NDB	333
NDB_DEFAULT_FREQSTEP?	333
NDB_DEFAULT_FREQSTEP	333
NDB_DEM_ID_BW?	333
NDB_DEM_ID_BW	333
NDB_DEM_DIST_BW?	334
NDB_DEM_DIST_BW	334
NDB_EXTERNALATT_LFIN?	334
NDB_EXTERNALATT_LFIN	334
NDB_LFIN_IMPEDENCE?	334
NDB_LFIN_IMPEDANCE	334
NDB_UNIT_LEVEL?	335
NDB_UNIT_LEVEL	335
VIEW_NDB?	335
VIEW_NDB	335

MODE_NDB

This command switches the instrument to the "NDB" mode.

Return values:

<State> **READY.**
The command was executed successfully.

NDB_DEFAULT_FREQSTEP? <StepSize>

NDB_DEFAULT_FREQSTEP <StepSize>

Gets or sets the default frequency step size in "NDB" mode.

Parameters:

<StepSize> 0.1_KHZ | 1.0_KHZ | 10_KHZ
 *RST: 1.0_KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Step Size"](#) on page 122

NDB_DEM_ID_BW? <Bandwidth>

NDB_DEM_ID_BW <Bandwidth>

Gets or sets the ID demodulator Bandwidth in "NDB" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF BW"](#) on page 124

NDB_DEM_DIST_BW? <Bandwidth>

NDB_DEM_DIST_BW <Bandwidth>

Gets or sets the distortion demodulator bandwidth in "NDB" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["IF BW Dist"](#) on page 124

NDB_EXTERNALATT_LFIN? <Attenuation>

NDB_EXTERNALATT_LFIN <Attenuation>

Gets or sets the external attenuation of the active receiver board for LF input in "NDB" mode.

Parameters:

<Attenuation> External attenuation
Default unit: dB

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Transducer Correction"](#) on page 123

NDB_LFIN_IMPEDENCE? <Impedance>

NDB_LFIN_IMPEDENCE <Impedance>

Gets or sets the impedance for the LF In input in "NDB" mode.

Parameters:

<Impedance> **50_OHM | 20_KOHM**
Sets the impedance.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["LF Imp."](#) on page 123

NDB_UNIT_LEVEL? <Unit>

NDB_UNIT_LEVEL <Unit>

This command sets the level unit in "NDB" mode.

Parameters:

<Unit> dBm | dBuV

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Level Unit"](#) on page 121

VIEW_NDB? <View type>

VIEW_NDB <View type>

Gets or sets the view in "NDB" mode. See [Chapter 4.5.2, "NDB measurement and results"](#), on page 115 for details.

Parameters:

<View type> **ID**
ID view
DIST
Distortion view
REC
Recording view

Return values:

<State> **READY.**
The command was executed successfully.

9.7.2 Retrieving NDB measurement results

The following commands are required to retrieve results from NDB measurements.

Useful commands for retrieving results described elsewhere:

- [GETDATADEF](#) on page 366
- [GETDATASET](#) on page 366
- [FMEAS](#) on page 295

Remote commands exclusive to NDB results:

NDB_AMFREQ	336
NDB_AMMOD	336
NDB_CARLEV_CHANGE	336
ID_CODE	336
NDB_IDFREQ_400_1020	336

NDB_K2_PCT.....	337
NDB_K3_PCT.....	337
NDB_K4_PCT.....	337
NDB_POWSUPPL_FC.....	337
NDB_THD_PCT.....	337

NDB_AMFREQ

This command queries the AM modulation frequency of the ID in "NDB" mode.

Return values:

<[Hz]> AM modulation frequency of the ID

Manual operation: See "ID Freq" on page 118

NDB_AMMOD

This command queries the AM modulation of the identifier in "NDB" mode.

Return values:

<[%]> Modulation depth of the identifier

Manual operation: See "ID AM" on page 118
 See "AM 400/1020 Hz" on page 119

NDB_CARLEV_CHANGE

Queries the variance in power level during ID transmission in "NDB" mode.

Return values:

<PowerVariance> Peak-to-peak power level difference during ID transmission.
 Default unit: dB

Manual operation: See "Carr Lev Change" on page 117

ID_CODE <ID>

This command queries the ID of the signal in "NDB" mode.

Parameters:

<ID> three or four characters

Manual operation: See "ID Code" on page 118

NDB_IDFREQ_400_1020 <Freq>

This command gets or sets the frequency of the ID in "NDB" mode.

Parameters:

<Freq> 400HZ | 1020HZ

Manual operation: See "ID Freq" on page 122

NDB_K2_PCT

This command queries the K2 distortion parameter of an NDB signal.

Return values:

<[%]> K2 distortion value of an NDB signal

Manual operation: See ["K2 400/1020 Hz"](#) on page 119

NDB_K3_PCT

This command queries the K3 distortion parameter of an NDB signal.

Return values:

<[%]> K3 distortion value of an NDB signal

Manual operation: See ["K3 400/1020 Hz"](#) on page 119

NDB_K4_PCT

This command queries the K4 distortion parameter of an NDB signal.

Return values:

<[%]> K4 distortion value of an NDB signal

Manual operation: See ["K4 400/1020 Hz"](#) on page 120

NDB_POWSUPPL_FC

Queries the distortion of the power supply frequency component in "NDB" mode.

Parameters:

<Power> Distortion caused by the power supply frequency component
Default unit: percent

Manual operation: See ["Unwanted AM 30 to 120 Hz"](#) on page 120

NDB_THD_PCT

This command queries the THD distortion parameter of an NDB signal.

Return values:

<[%]> THD distortion value of an NDB signal

Manual operation: See ["THD 400/1020 Hz"](#) on page 120

9.8 RF spectrum mode

The following commands are required to configure and perform measurements in the RF Spectrum mode. They are only available if the R&S EVSG-K10 RF spectrum analysis option is installed.

- [Configuring RF spectrum measurements](#)..... 338
- [Retrieving RF spectrum results](#).....342

9.8.1 Configuring RF spectrum measurements

The following commands are required to configure RF Spectrum measurements.

MODE_FSCAN	338
FSCAN_ATTMODE?	339
FSCAN_ATTMODE	339
FSCAN_FREQCENTER?	339
FSCAN_FREQCENTER	339
FSCAN_FREQSPAN?	339
FSCAN_FREQSPAN	339
FSCAN_FREQSTART?	340
FSCAN_FREQSTART	340
FSCAN_FREQSTOP?	340
FSCAN_FREQSTOP	340
FSCAN_GRID_YRANGE_DB?	340
FSCAN_GRID_YRANGE_DB	340
FSCAN_REFLEVEL?	340
FSCAN_REFLEVEL	340
FSCAN_RESBW_AUTO?	341
FSCAN_RESBW_AUTO	341
FSCAN_RES_BW?	341
FSCAN_RES_BW	341
FSCAN_TRACE_MODE?	341
FSCAN_TRACE_MODE	341
FSCAN_TRACE_AVRGCOUNT?	342
FSCAN_TRACE_AVRGCOUNT	342

MODE_FSCAN

This command switches the instrument to the "RF Spectrum" mode.

Return values:

<State>

READY.

The command was executed successfully.

FSCAN_ATTMODE?**FSCAN_ATTMODE** <Attenuation mode>

This command gets or selects the attenuation mode in the "RF Spectrum" mode.

Parameters:

<Attenuation mode> **COUPLED**
 Coupled attenuation
 LN
 Low noise attenuation
 NORM
 Normal attenuation (0 dB attenuation)
 LD
 Low distance attenuation

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "RF Mode" on page 69

FSCAN_FREQCENTER?**FSCAN_FREQCENTER** <Frequency>

This command gets or sets the center frequency in "RF Spectrum" mode.

Parameters:

<Frequency> FSCAN CENTER frequency
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "Center" on page 127

FSCAN_FREQSPAN?**FSCAN_FREQSPAN** <Frequency>

This command gets or sets the span frequency in "RF Spectrum" mode.

Parameters:

<Frequency> FSCAN SPAN frequency
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "Span" on page 127

FSCAN_FREQSTART?**FSCAN_FREQSTART** <Frequency>

This command gets or sets the start frequency in "RF Spectrum" mode.

Parameters:

<Frequency> FSCAN START frequency
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Start"](#) on page 127

FSCAN_FREQSTOP?**FSCAN_FREQSTOP** <Frequency>

This command gets or sets the stop frequency in "RF Spectrum" mode.

Parameters:

<Frequency> FSCAN STOP frequency
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Stop"](#) on page 127

FSCAN_GRID_YRANGE_DB? <Range>**FSCAN_GRID_YRANGE_DB** <Range>

Gets or selects the range of the y-axis in "RF Spectrum" mode.

Parameters:

<Range> 10_DB | 20_DB | 30_DB | 40_DB | 50_DB | 60_DB | 80_DB |
100_DB | 120_DB

Return values:

<State> **READY.**
The command was executed successfully.

FSCAN_REFLEVEL?**FSCAN_REFLEVEL** <Level>

This command gets or sets the reference level in "RF Spectrum" mode.

Parameters:

<Level> FSCAN Reference Level
Default unit: dBm

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Ref Level"](#) on page 128

FSCAN_RESBW_AUTO?

FSCAN_RESBW_AUTO <Mode>

This command gets or sets the mode of specifying the resolution bandwidth in "RF Spectrum" mode.

Parameters:

<Mode> **AUTO**
Set resolution bandwidth automatically.

MANUAL
Set resolution bandwidth manually.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Resolution Bandwidth \(RBW Mode/Res BW\)"](#) on page 127

FSCAN_RES_BW?

FSCAN_RES_BW <Bandwidth>

This command gets or sets the resolution bandwidth in "RF Spectrum" mode.

Parameters:

<Bandwidth> 15K | 7K5 | 3K75 | 1K87 | 937 | 468 | 234 | 117 | 12K | 6K | 3K |
1K5 | 750 | 375 | 187 | 94 | 47 | 23.4 | 11.7 | 1K2 | 600 | 300 |
150 | 75 | 37.4 | 18.7 | 9.4 | 4.7 | 2.3
FSCAN resolution bandwidth
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Resolution Bandwidth \(RBW Mode/Res BW\)"](#) on page 127

FSCAN_TRACE_MODE?

FSCAN_TRACE_MODE <Trace mode>

Gets or selects the trace mode of the "RF Spectrum" mode.

Parameters:

<Trace Mode> **CLWR**
Overwrite mode (default): the trace is overwritten by each sweep

AVRG

The average is determined over several sweeps
The number of averaging procedures is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

MAXHOLD

The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

RMS

The RMS value for each trace point over several sweeps is determined and displayed.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Trace mode"](#) on page 129

FSCAN_TRACE_AVRGCOUNT?**FSCAN_TRACE_AVRGCOUNT** <trace average count>

Gets or sets the trace average count of the "RF Spectrum" mode.

Parameters:

<Trace average count> Range: 0 to 100

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Average Count"](#) on page 129

9.8.2 Retrieving RF spectrum results

The following commands are required to retrieve results from RF Spectrum measurements.

[FSCAN_GETSPECT](#)..... 342

FSCAN_GETSPECT

All measurement values are returned as one comma-separated string in "RF Spectrum" mode.

Parameters:

<Trace Data> Measurement values
 Default unit: dBm

<State>

READY.

The command was executed successfully.

9.9 IF spectrum mode

The following commands are required to configure and perform measurements in the IF Spectrum mode. They are only available if the R&S EVSG-K10 RF spectrum analysis option is installed.

- [Configuring IF spectrum measurements](#)..... 343
- [Retrieving IF spectrum results](#)..... 347

9.9.1 Configuring IF spectrum measurements

The following commands are required to configure IF Spectrum measurements.

MODE_IFSPECT	343
IFSPECT_ATTMODE	344
IFSPECT_FREQRF?	344
IFSPECT_FREQRF	344
IFSPECT_FREQ_SPAN?	344
IFSPECT_FREQ_SPAN	344
IFSPECT_GRID_YRANGE_DB?	344
IFSPECT_GRID_YRANGE_DB	344
IFSPECT_REFLEVEL?	345
IFSPECT_REFLEVEL	345
IFSPECT_RES_BW?	345
IFSPECT_RES_BW	345
IFSPECT_RESBW_AUTO?	345
IFSPECT_RESBW_AUTO	345
IFSPECT_TRACE_MODE?	346
IFSPECT_TRACE_MODE	346
IFSPECT_TRACE_AVRGCOUNT?	346
IFSPECT_TRACE_AVRGCOUNT	346

MODE_IFSPECT

This command switches the instrument to the "IF Spectrum" mode.

Return values:

<State>

READY.

The command was executed successfully.

IFSPECT_ATTMODE <Mode>

Selects the attenuation of the "IF Spectrum" mode.

Parameters:

<Mode>	AUTO Automatic attenuation
	LN Low noise attenuation
	NORM Normal attenuation
	LD Low distortion attenuation

<State> **READY.**
The command was executed successfully.

Manual operation: See "RF Att" on page 68
See "RF Mode" on page 69

IFSPECT_FREQRF?**IFSPECT_FREQRF <Freq>**

Gets or sets the RF frequency in "IF Spectrum" mode.

Parameters:

<Freq>	RF frequency Default unit: kHz
--------	-----------------------------------

<State> **READY.**
The command was executed successfully.

Manual operation: See "RF Freq" on page 131

IFSPECT_FREQ_SPAN?**IFSPECT_FREQ_SPAN <Freq>**

Gets or sets the span frequency in "IF Spectrum" mode.

Parameters:

<Freq>	Span frequency Default unit: kHz
--------	-------------------------------------

<State> **READY.**
The command was executed successfully.

Manual operation: See "Span" on page 131

IFSPECT_GRID_YRANGE_DB? <Range>**IFSPECT_GRID_YRANGE_DB <Range>**

Gets or selects the range of the y-axis in "IF Spectrum" mode.

Parameters:

<Range> 10_DB | 20_DB | 30_DB | 40_DB | 50_DB | 60_DB | 80_DB |
100_DB | 120_DB

Return values:

<State> **READY.**
The command was executed successfully.

IFSPECT_REFLEVEL?

IFSPECT_REFLEVEL <Frequency>

Gets or sets the reference level of the "IF Spectrum" mode.

Parameters:

<Freq> Ref Level
Default unit: dBm

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Ref Level"](#) on page 132

IFSPECT_RES_BW?

IFSPECT_RES_BW <Bandwidth>

Gets or sets the resolution bandwidth for "IF Spectrum" mode.

Parameters:

<Bandwidth> 200K | 100K | 50K | 25K | 12K5 | 6K2 | 3K1 | 1K6 | 800 | 240K |
120K | 60K | 30K | 15K | 7K5 | 3K75 | 1K87 | 937 | 468 | 234 |
117 | 12K | 6K | 3K | 1K5 | 750 | 375 | 187 | 94 | 47 | 23.4 | 11.7 |
1K2 | 600 | 300 | 150 | 75 | 37.4 | 18.7 | 9.4 | 4.7 | 2.3 | 120.0 |
60.0 | 30.0 | 15.0 | 7.5 | 3.7 | 1.9 | 0.9 | 0.5

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["RBW"](#) on page 132

IFSPECT_RESBW_AUTO?

IFSPECT_RESBW_AUTO <Mode>

This command gets or sets the mode of specifying the resolution bandwidth in "IF Spectrum" mode.

Parameters:

<Mode> **AUTO**
Set resolution bandwidth automatically.
MANUAL
Set resolution bandwidth manually.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["RBW"](#) on page 132

IFSPECT_TRACE_MODE?

IFSPECT_TRACE_MODE <Trace mode>

Gets or selects the trace mode of the "IF Spectrum" mode.

Parameters:

<Trace Mode> **CLWR**
Overwrite mode (default): the trace is overwritten by each sweep

AVRG
The average is determined over several sweeps
The number of averaging procedures is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

MAXHOLD
The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

RMS
The RMS value for each trace point over several sweeps is determined and displayed.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Trace mode"](#) on page 129

IFSPECT_TRACE_AVRGCOUNT?

IFSPECT_TRACE_AVRGCOUNT <trace average count>

Gets or sets the trace average count of the "IF Spectrum" mode.

Parameters:

<Trace average count> Range: 0 to 100

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Average Count"](#) on page 129

9.9.2 Retrieving IF spectrum results

The following commands are required to retrieve results from IF Spectrum measurements.

IFSPECT_GETSPECT	347
--	-----

IFSPECT_GETSPECT

All measurement values are returned as one comma-separated string in "IF Spectrum" mode.

Parameters:

<Trace Data>	Measurement values Default unit: dBm
<State>	READY. The command was executed successfully.

9.10 AF spectrum mode

The following commands are required to configure and perform measurements in the AF Spectrum mode. They are only available if the R&S EVSG-K11 AF spectrum analysis option is installed.

• Configuring AF spectrum measurements	347
• Retrieving AF spectrum results	354

9.10.1 Configuring AF spectrum measurements

The following commands are required to configure AF Spectrum measurements.

MODE_FFT	348
FFT_ATTMODE?	348
FFT_ATTMODE	348
FFT_BB_AF_BW_KHZ?	349
FFT_BB_AF_BW_KHZ	349
FFT_BB_IF_BW_KHZ?	349
FFT_BB_IF_BW_KHZ	349
FFT_BB_LFIN_DCOFFSETV?	349
FFT_BB_LFIN_DCOFFSETV	349
FFT_FREQ_CENTER?	350
FFT_FREQ_CENTER	350
FFT_FREQ_SPAN?	350
FFT_FREQ_SPAN	350
FFT_FREQ_START?	350
FFT_FREQ_START	350
FFT_FREQSTOP?	350
FFT_FREQSTOP	350

FFT_FREQRF?	351
FFT_FREQRF	351
FFT_GRID_YRANGE_DB?	351
FFT_GRID_YRANGE_DB	351
FFT_GRID_YRANGE_V?	351
FFT_GRID_YRANGE_V	351
FFT_IF_BW_KHZ?	352
FFT_IF_BW_KHZ	352
FFT_RESBW_AUTO?	352
FFT_RESBW_AUTO	352
FFT_RESBW_FIX_KHZ?	352
FFT_RESBW_FIX_KHZ	352
FFT_RFLF_INPUT?	353
FFT_RFLF_INPUT	353
FFT_TRACE_MODE?	353
FFT_TRACEMODE	353
FFT_TRACE_AVRGCOUNT?	354
FFT_TRACE_AVRGCOUNT	354

MODE_FFT

This command switches the instrument to the "AF Spectrum" mode.

Return values:

<State> **READY.**
The command was executed successfully.

FFT_ATTMODE?

FFT_ATTMODE <Mode>

This command selects the attenuation mode of the "AF Spectrum" mode.

Parameters:

<Mode> **COUPLED**
Coupled attenuation

LN
Low noise attenuation

NORM
Normal attenuation (0 dB attenuation)

LD
Low distance attenuation

Return values:

<State> **READY.**
The command was executed successfully.

Example: FFT_ATTMODE LD

Manual operation: See "RF Att" on page 68
 See "RF Mode" on page 69

FFT_BB_AF_BW_KHZ? <Bandwidth>
FFT_BB_AF_BW_KHZ <Bandwidth>

This command gets or sets the bandwidth for LF input (AF mode) in "AF Spectrum" mode.

Parameters:

<Bandwidth> 0.5KHZ | 1.5KHZ | 3KHZ | 5KHZ | 9KHZ | 12.5KHZ | 18KHZ | 25KHZ

IF bandwidth

Default unit: kHz

Return values:

<State> **READY.**

The command was executed successfully.

Manual operation: See ["AF In BW"](#) on page 139

FFT_BB_IF_BW_KHZ? <Bandwidth>
FFT_BB_IF_BW_KHZ <Bandwidth>

This command gets or sets the IF demodulation bandwidth for AM input in "AF Spectrum" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ

If bandwidth

Default unit: kHz

Return values:

<State> **READY.**

The command was executed successfully.

Manual operation: See ["IF BW AM"](#) on page 140

FFT_BB_LFIN_DCOFFSETV? <Power>
FFT_BB_LFIN_DCOFFSETV <Power>

This command gets or sets the reference power for LF input in "AF Spectrum" mode. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

Parameters:

<Power> Reference DC power of the AF signal

Default unit: V

Return values:

<State> **READY.**

The command was executed successfully.

Manual operation: See ["DC Reference"](#) on page 72

FFT_FREQ_CENTER?**FFT_FREQ_CENTER** <Frequency>

Gets or sets the FFT center frequency in "AF Spectrum" mode.

Parameters:

<Frequency> Value of the FFT center frequency.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["AF Center"](#) on page 138

FFT_FREQ_SPAN?**FFT_FREQ_SPAN** <Frequency>

Gets or sets the FFT span frequency in "AF Spectrum" mode.

Parameters:

<Frequency> Value of the FFT span frequency.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["AF Span"](#) on page 138

FFT_FREQ_START?**FFT_FREQ_START** <Frequency>

Gets or sets the FFT start frequency in "AF Spectrum" mode.

Parameters:

<Frequency> Value of the FFT start frequency.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["AF Start"](#) on page 139

FFT_FREQSTOP?**FFT_FREQSTOP** <Frequency>

Gets or sets the FFT stop frequency in "AF Spectrum" mode.

Parameters:

<Frequency> Value of the FFT Stop frequency.
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[AF Stop](#)" on page 139

FFT_FREQRF?

FFT_FREQRF <Freq>

Gets or Sets RF frequency in "AF Spectrum" mode.

Parameters:

<Freq> FFT RF frequency
Default unit: <kHz>

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[RF Freq](#)" on page 138

FFT_GRID_YRANGE_DB? <Range>

FFT_GRID_YRANGE_DB <Range>

Gets or selects the range of the y-axis in "AF Spectrum" mode.

Parameters:

<Range> 10_DB | 20_DB | 50_DB | 100_DB

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Y-Range](#)" on page 140

FFT_GRID_YRANGE_V? <Range>

FFT_GRID_YRANGE_V <Range>

Gets or selects the range of the y-axis in V for LF input in "AF Spectrum" mode.

Parameters:

<Range> 100_mV | 200_mV | 500_mV | 1_V | 2_V | 5_V

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "[Y Range](#)" on page 142

FFT_IF_BW_KHZ? <Bandwidth>
FFT_IF_BW_KHZ <Bandwidth>

This command gets or sets the IF demodulation bandwidth for RX input in "AF Spectrum" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ
 RX bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "IF BW" on page 139

FFT_RESBW_AUTO? <Mode>
FFT_RESBW_AUTO <Mode>

This command gets or sets the mode of specifying the resolution bandwidth in "aF Spectrum" mode.

Parameters:

<Mode> **AUTO**
 Set resolution bandwidth automatically.
 MANUAL
 Set resolution bandwidth manually.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "RBW" on page 139

FFT_RESBW_FIX_KHZ? <Bandwidth>
FFT_RESBW_FIX_KHZ <Bandwidth>

This command gets or sets the resolution bandwidth for RX input in "AF Spectrum" mode.

Parameters:

<Bandwidth> 100K | 50K | 25K | 12K5 | 6K2 | 3K1 | 1K6 | 800 | 240K | 120K | 60K | 30K | 15K | 7K5 | 3K75 | 1K87 | 937 | 468 | 234 | 117 | 12K | 6K | 3K | 1K5 | 750 | 375 | 187 | 94 | 47 | 23.4 | 11.7 | 1K2 | 600 | 300 | 150 | 75 | 37.4 | 18.7 | 9.4 | 4.7 | 2.3 | 120.0 | 60.0 | 30.0 | 15.0 | 7.5 | 3.7 | 1.9 | 0.9 | 0.5
 RX input resolution bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["RBW"](#) on page 139

FFT_RFLF_INPUT? <Type>

FFT_RFLF_INPUT <Type>

Gets or sets the type of input for the "AF Spectrum" mode.

Parameters:

<Type> **RX_IN**
RX input

LF_IN
Baseband input

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Input RF/LF"](#) on page 63

FFT_TRACE_MODE?

FFT_TRACEMODE <Trace Mode>

Gets or sets the trace mode of the "AF Spectrum" mode.

Parameters:

<Trace Mode> **CLWR**
Overwrite mode (default): the trace is overwritten by each sweep

AVRG
The average is determined over several sweeps
The number of averaging procedures is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

MAXHOLD
The maximum value is determined over several sweeps and displayed. The R&S EVSF1000 saves each trace point in the trace memory only if the new value is greater than the previous one.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

RMS
The RMS value for each trace point over several sweeps is determined and displayed.
The number of evaluated sweeps is defined by
[FFT_TRACE_AVRGCOUNT](#) on page 354.

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See ["Trace mode"](#) on page 129

FFT_TRACE_AVRGCOUNT?**FFT_TRACE_AVRGCOUNT** <trace average count>

Gets or sets the trace average count of the "AF Spectrum" mode.

Parameters:

<Trace average count> Range: 0 to 100

Return values:<State> **READY.**
The command was executed successfully.**Manual operation:** See "Average Count" on page 129

9.10.2 Retrieving AF spectrum results

The following commands are required to retrieve results from AF Spectrum measurements.

[FFT_GETSPECT](#)..... 354**FFT_GETSPECT**

All measurement values in dBm are returned as one comma-separated string.

Return values:

All values Shows all spectrum values.

Manual operation: See "IF spectrum preview" on page 52

9.11 AF time domain mode

The following commands are required to configure and perform measurements in the AF Time domain mode. They are only available if the R&S EVSG-K11 AF spectrum analysis option is installed.

- [Configuring AF time domain measurements](#).....354
- [Retrieving RF spectrum results](#).....360

9.11.1 Configuring AF time domain measurements

The following commands are required to configure AF Time Domain measurements.

[MODE_SCOPE](#)..... 355

[SCOPE_ATTMODE](#).....355

[SCOPE_BB_AF_BW_KHZ?](#).....356

[SCOPE_BB_AF_BW_KHZ](#).....356

[SCOPE_BB_IF_BW_KHZ?](#).....356

[SCOPE_BB_IF_BW_KHZ](#).....356

SCOPE_BB_LFIN_DCOFFSETV?	356
SCOPE_BB_LFIN_DCOFFSETV	356
SCOPE_FREQRF?	357
SCOPE_FREQRF	357
SCOPE_IF_BW_KHZ?	357
SCOPE_IF_BW_KHZ	357
SCOPE_REFLEVEL?	357
SCOPE_REFLEVEL	357
SCOPE_RESBW_FIX_KHZ?	357
SCOPE_RESBW_FIX_KHZ	357
SCOPE_RFLF_INPUT?	358
SCOPE_RFLF_INPUT	358
SCOPE_TIMEDIV_RF?	358
SCOPE_TIMEDIV_RF	358
SCOPE_TRIGLEVEL_RFPCT?	359
SCOPE_TRIGLEVEL_RFPCT	359
SCOPE_TRIGSLOPE?	359
SCOPE_TRIGSLOPE	359

MODE_SCOPE

This command switches the instrument to the "AF Time Domain" mode.

Return values:

<State> **READY.**
The command was executed successfully.

SCOPE_ATTMODE <Mode>

This command selects the attenuation mode of the "AF Time Domain" mode.

Parameters:

<Mode> **COUPLED**
Coupled attenuation

LN
Low noise attenuation

NORM
Normal attenuation (0 dB attenuation)

LD
Low distance attenuation

Return values:

<State> **READY.**
The command was executed successfully.

Example: SCOPE_ATTMODE LD

Manual operation: See "RF Att" on page 68
 See "RF Mode" on page 69

SCOPE_BB_AF_BW_KHZ? <Bandwidth>

SCOPE_BB_AF_BW_KHZ <Bandwidth>

This command gets or sets the bandwidth for LF input in "AF Time Domain" mode.

Parameters:

<Bandwidth> 0.5KHZ | 1.5KHZ | 3KHZ | 5KHZ | 9KHZ | 12.5KHZ | 18KHZ | 25KHZ
 IF bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[AF In BW](#)" on page 139

SCOPE_BB_IF_BW_KHZ? <Bandwidth>

SCOPE_BB_IF_BW_KHZ <Bandwidth>

This command gets or sets the IF demodulation bandwidth for LF input in "AF Time Domain" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ | 50KHZ
 RX bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[IF BW](#)" on page 147

SCOPE_BB_LFIN_DCOFFSETV? <Power>

SCOPE_BB_LFIN_DCOFFSETV <Power>

This command gets or sets the reference power for LF input in "AF Time Domain" mode. This value is used to determine the modulation depth and corresponds to the DC power of the AF signal.

Parameters:

<Power> Reference DC power of the AF signal
 Default unit: V

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See "[DC Reference](#)" on page 72

SCOPE_FREQRF?**SCOPE_FREQRF** <Freq>

This command gets or sets the RF frequency in "AF Time Domain".

Parameters:

<Freq> RF frequency
Default unit: <kHz>

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "RF Freq" on page 147

SCOPE_IF_BW_KHZ? <Bandwidth>**SCOPE_IF_BW_KHZ** <Bandwidth>

This command gets or sets the bandwidth for RX input in "AF Time Domain" mode.

Parameters:

<Bandwidth> 1KHZ | 3KHZ | 6KHZ | 10KHZ | 18KHZ | 25KHZ | 36KHZ |
50KHZ
RX bandwidth
Default unit: kHz

Return values:

<State> **READY.**
The command was executed successfully.

Manual operation: See "IF BW" on page 147

SCOPE_REFLEVEL?**SCOPE_REFLEVEL** <RefLev>

This command gets or sets the reference level of the "AF Time Domain" mode.

Parameters:

<RefLev> Set the reference level.
Default unit: <dBm>

Return values:

<State> **READY.**
The command was executed successfully.

SCOPE_RESBW_FIX_KHZ? <Bandwidth>**SCOPE_RESBW_FIX_KHZ** <Bandwidth>

This command gets or sets the resolution bandwidth for RX input in "AF Time Domain" mode.

Parameters:

<Bandwidth> 200K | 100K | 50K | 25K | 12K5 | 6K2 | 3K1 | 1K6 | 800 | 240K | 120K | 60K | 30K | 15K | 7K5 | 3K75 | 1K87 | 937 | 468 | 234 | 117 | 12K | 6K | 3K | 1K5 | 750 | 375 | 187 | 94 | 47 | 23.4 | 11.7 | 1K2 | 600 | 300 | 150 | 75 | 37.4 | 18.7 | 9.4 | 4.7 | 2.3 | 120.0 | 60.0 | 30.0 | 15.0 | 7.5 | 3.7 | 1.9 | 0.9 | 0.5
 RX input resolution bandwidth
 Default unit: kHz

Return values:

<State> **READY.**
 The command was executed successfully.

SCOPE_RFLF_INPUT? <Input>**SCOPE_RFLF_INPUT <Input>**

Configures the input source for the receiver in "Scope" mode.

Parameters:

<Input> **RX_IN**
 RF input from RX 1 In/RX 2 In connectors on the front of the R&S EVSF1000
LF_IN
 An AF or low frequency signal is provided at the LF In input connector on the rear side of the R&S EVSF1000.

Return values:

<State> **READY.**
 The command was executed successfully.

Manual operation: See ["Input RF/LF"](#) on page 63

SCOPE_TIMEDIV_RF?**SCOPE_TIMEDIV_RF <time/div>**

This command gets or sets the Time/Div for RF input in "AF Time Domain" mode.

Parameters:

<time/div> Set value for the Time/Div for RF input.
100_MS
 Sets the value to 100 ms.
50_MS
 Sets the value to 50 ms.
20_MS
 Sets the value to 20 ms.
10_MS
 Sets the value to 10 ms.
5_MS
 Sets the value to 5 ms.

2_MS

Sets the value to 2 ms.

1_MS

Sets the value to 1 ms.

500_US

Sets the value to 0.5 ms.

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Time/Div"](#) on page 150**SCOPE_TRIGLEVEL_RFPCT?****SCOPE_TRIGLEVEL_RFPCT** <Trig level>

This command gets or sets the trigger level for RF Input of the "AF Time Domain" mode.

Parameters:

<Trig level>

Set trigger level.

Range: -100 to 100

Default unit: <%>

Return values:

<State>

READY.

The command was executed successfully.

Manual operation: See ["Trigger Level"](#) on page 151**SCOPE_TRIGSLOPE?****SCOPE_TRIGSLOPE** <Trigger edge>

This command gets or selects the trigger edge for RF Input of the "AF Time Domain" mode.

Parameters:

<Trigger edge>

POSITIVE

Sets positive SCOPE trigger slope.

NEGATIVE

Sets negative SCOPE trigger slope.

BOTH

Sets positive and negative SCOPE trigger slope.

<State>

READY.

The command was executed successfully.

Manual operation: See ["Trigger Edge"](#) on page 151

9.11.2 Retrieving RF spectrum results

The following commands are required to retrieve results from AF Time Domain measurements.

SCOPE_GETMEAS	360
-------------------------------------	-----

SCOPE_GETMEAS

All measurement values in % (RF Input) or in mV (BB Input) are returned as one comma-separated string.

Return values:

All values Shows all measured values.

9.12 Data management

The following commands are required to configure data streaming and recording.

• Data recording	360
• Data streaming	365
• Results for data streaming	367

9.12.1 Data recording

The following commands are required for data recording.

CLEARACTIVELIST	361
DL_START	361
DL_STOP	361
GETACTIVELIST	361
GETDATA_FROM_ACTIVELIST	362
GETDLTIME?	362
GETFREEMEMORY	362
GETLISTDATA	362
GETLISTSIZE	363
CLEARALLLISTS	363
SETUP:GBAS_PPS_SOURCE?	363
PPSSMA_TRIG_SOURCE	363
RECIQ	363
SAVEACTIVELIST2USB	364
SELECTLISTPARAM	364
SETACTIVELIST	365
SETDLTIME	365

CLEARACTIVELIST

This command clears the currently active list. All entries are deleted.

Return values:

<EventResult>

READY

Command was executed successfully

ERROR

An error occurred; command was not successful

Example:

SETACTIVELIST 2

Defines list 2 as the active list.

CLEARACTIVELIST

Clears list 2.

Manual operation: See ["Clear List"](#) on page 202

DL_START

Starts logging data for the active RX board and the currently selected parameters until the [DL_STOP](#) command is executed. The data received from the active RX board is stored internally.

To reduce the amount of logged data, restrict it to specific parameters.

Return values:

<EventResult>

READY.

The command was executed successfully.

ERROR

An error occurred; command was not successful.

DL_STOP

Stops logging data.

Return values:

<EventResult>

READY

Command was executed successfully

ERROR

An error occurred; command was not successful

Usage:

Event

GETACTIVELIST

This command returns the number of the currently active data logger list.

Return values:

<ListNo>

integer

List number

Range: 1 to 999

Example:

```
SETACTIVELIST 2
Sets list 2 as the active list.
GETACTIVELIST
Queries the number of the active list.
Result:
2
```

Manual operation: See ["List"](#) on page 202

GETDATA_FROM_ACTIVELIST <start index>,<stop index>

Exports the selected data lines of the active data logger list.

Parameters:

<Start index> Specifies the data line of the data logger list to start with.

<Stop index> Specifies the data line of the data logger list to stop with. A stop parameter of -1 exports the data logger list to the end.

GETDLTIME?

Gets the data logger time for the current mode: "ILS LOC", "ILS GP", "ILS MB", "VOR", or "COM".

Parameters:

<Time> Data logger time
Default unit: ms

Usage: Query only

GETFREEMEMORY

This command queries the amount of free storage space on the internal flash memory.

Return values:

<FreeMemSize> Default unit: MByte

GETLISTDATA <ListNo>

This command queries the contents of the selected list.

Setting parameters:

<ListNo> List number
Range: 1 to 9999

Return values:

<ListData> Contents of the list.

<EventResult> **READY.**
The command was executed successfully.

ERROR
An error occurred; command was not successful.

GETLISTSIZE

This command queries the size of the active list.

Return values:

<NoEntries> integer
 Number of entries in the active list.
 Range: 0 to 1 000 000

CLEARALLLISTS

This command clears all 999 lists. All entries are deleted in all lists.

Return values:

<EventResult> **READY**
 Command was executed successfully
 ERROR
 An error occurred; command was not successful

Manual operation: See "[Clear All Lists](#)" on page 204

SETUP:GBAS_PPS_SOURCE?

PPSSMA_TRIG_SOURCE <Source>

Determines which input triggers data storage for ILS LOC, ILS GP, ILS MB, VOR and COM modes.

Parameters:

<Source> **PPS SMA**
 SMA input of the GNSS connector
 PPS GPS
 PPS input of the GNSS connector

RECIQ <State>

If enabled, the raw, unprocessed I/Q data is also recorded when you execute [DL_START](#). This feature requires the R&S EVSG1-K25 I/Q data streaming option. I/Q data is available in ILS, VOR, MB, COM, and GBAS mode.

I/Q data is stored as a separate file with the same file name as the data list, but the extension `.iq`.

For details see [Chapter 7.2.2, "I/Q data recording and streaming"](#), on page 201.

Parameters:

<State> ON | OFF

Return values:

<EventResult> **READY.**
 The command was executed successfully.

ERROR

An error occurred; command was not successful.

Manual operation: See ["Rec IQ"](#) on page 204

SAVEACTIVELIST2USB <Filename>

This command copies the active list to a connected USB storage device as a `.csv` file. The file name is set automatically (e.g `llz_rx1_list9.csv`).

Note that this command is time-consuming for long lists (max. 1 000 000 entries).

To reduce the amount of logged data, restrict it to specific parameters.

Parameters:

<Filename>

string

Path, file name and extension of the file on the USB device to which the data is stored: Note that a specified path must already exist on the USB device, otherwise an error occurs.

Return values:

<EventResult>

READY.

The command was executed successfully.

ERROR

An error occurred; command was not successful.

Example:

```
SETACTIVELIST 2
//Defines list 2 as the active list.
SAVEACTIVELIST2USB
```

Manual operation: See ["Export List to USB"](#) on page 204

SELECTLISTPARAM <Params>

This command selects the parameters to be logged.

Parameters:

<Params>

Set of parameters to be included in data log.

ALL

All parameters are selected for logging.

FULL

The selected parameters are compatible to EVS300.

MEDIUM

A reduced set of parameters is selected.

SHORT

A minimum set of parameters is selected.

Example:

```
//Select all parameters for logging
SELECTLISTPARAM ALL
```

Manual operation: See ["Data selection \(Sel, not GBAS/SCAT-I mode\)"](#) on page 203

SETACTIVELIST <ListNo>

This command selects the active data logger list (to save measurement results).

Setting parameters:

<ListNo> integer
 List number
 Range: 1 to 999

Return values:

<EventResult> **READY**
 Command was executed successfully.
 ERROR
 An error occurred; command was not successful.

Example: SETACTIVELIST 2

Usage: Setting only

Manual operation: See "[List](#)" on page 202

SETDLTIME <Time>

Sets the data logger time for the current mode: "ILS LOC", "ILS GP", "ILS MB", "VOR", or "COM".

Parameters:

<Time> Data logger time
 Default unit: ms

Return values:

<State> **READY.**
 The command was executed successfully.

9.12.2 Data streaming

The following commands are required for data streaming.

Useful commands for streaming described elsewhere:

- [GBAS : STREAM](#) on page 331
- [GBAS : STOPSTREAM](#) on page 331

Remote commands exclusive to data streaming:

GETDATADEF	366
GETDATASET	366
STREAM	366
STOPSTREAM	367
MARKSTREAM	367

GETDATADEF

This command defines the data delivered by [GETDATASET](#) on page 366.

GETDATASET

This command creates the output of the current streaming measurement results for the active board.

Return values:

<ActBoard>	CH:1 CH:2 The currently active receiver board for which the results are returned.
<Data>	Data for the active board as described by GETDATADEF on page 366.
<State>	READY. The command was executed successfully.

STREAM <ParamSelection>, <RX Board>

Starts data streaming. In streaming mode, a measured data set is automatically sent to the remote interface. The Meastime (see [MEASTIME](#) on page 231) defines how often the data sets are produced. Every data set is preceded by the channel number. Streaming can produce large quantities of output. It is mandatory to have a fast data connection and an application that is able to handle the data.

For details on the output see [Chapter 9.12.3, "Results for data streaming"](#), on page 367

Parameters:

<ParamSelection>	ALL All values of the current measurement are send as comma-separated text, using current units. FULL Compatible to R&S EVS300. MEDIUM A fixed selection of parameters is exported. SHORT A short, fixed selection of parameters is exported.
<RX Board>	1 Data streaming is started for RX board 1. 2 Data streaming is started for RX board 2. 1+2 Data streaming is started for both RX boards.

Return values:

<State>

READY.

The command was executed successfully.

STOPSTREAM

This command terminates the data stream for both RX Boards.

Return values:

<State>

READY.

The command was executed successfully.

MARKSTREAMThis command sets the *s* flag in the running stream output.**Return values:**

<State>

READY.

The command was executed successfully.

9.12.3 Results for data streaming

Which parameters and results are returned during streaming depends on the measurement mode and the parameter selection.

The individual measurement results are described in the result views.

**Status flags**

The "STIOCPMV" value contains status flags, if applicable:

- **S**: Start (started manually)
- **T**: Triggered (externally)
- **I**: Invalid
- **O**: Overload (RF input signal too high)
- **C**: Corrected (includes RF input correction factor)
- **P**: PPS-synced
- **M**: Morse ID available
- **V**: Valid signal (ILS LOC/GP and VOR only)



For compatibility reasons, the streaming results contain placeholders for all R&S EVSx variants and options, regardless of whether the particular instrument supports or provides those results. If not applicable, the result remains empty.

• ILS LOC mode	368
• ILS GP mode	369
• ILS MB mode	370
• VOR mode	371

• COM mode.....	371
• GBAS mode.....	372
• NDB mode.....	373

9.12.3.1 ILS LOC mode

All parameters

RX, STIOCPM, Index , Date, Time, FREQ[MHz], SINGLE[kHz], CRS_UF, CLR_LF[kHz], LEVEL[dBm], AM-MOD./90Hz[%], AM-MOD./150Hz[%], FREQ_90[Hz], FREQ_150[Hz], DDM(90-150)[1], SDM[%], PHI-90/150[°], VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz], ID-CODE, ID-Per.[s], Last_ID[s], DotLen[ms], DashLen[ms], DotDashGap[ms], Lettergap[ms], LEV_CLR_LF[dBm], LEV_CRS_UF[dBm], AM-MOD_CLR_LF/90Hz[%], AM-MOD_CLR_LF/150Hz[%], FREQ_90_CLR_LF[Hz], FREQ_150_CLR_LF[Hz], DDM_CLR_LF(90-150)[1], SDM_CLR_LF[%], PHI-90/150_CLR_LF[°], AM-MOD_CRS_UF/90Hz[%], AM-MOD_CRS_UF/150Hz[%], FREQ_90_CRS_UF[Hz], FREQ_150_CRS_UF[Hz], DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%], PHI-90/150_CRS_UF[°], PHI-90/90[°], PHI-150/150[°], ResFM90[Hz], ResFM150[Hz], K2/90Hz[%], K2/150Hz[%], K3/90Hz[%], K3/150Hz[%], K4/90Hz[%], K4/150Hz[%], THD/90Hz[%], THD/150Hz[%], AM240[%], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, GPS_Und.[m], Temp[°C], MeasTime[ms], MeasMode, LOC_GP, ATT.MODE, DemodOffset_1F, DemodOffset_CRS, DemodOffset_CLR, Autotune_1F, Autotune_CRS, Autotune_CLR, IFBW_Man_WIDE, IFBW_Man_UCLC, TrigCounter, IQPosition, IQSamples

Full parameters

Channel, STIOCPM, Index , Date, Time, FREQ[MHz], CRS_UF/SINGLE[kHz], CLR_LF[kHz], LEVEL[dBm], AM-MOD./90Hz[%], AM-MOD./150Hz[%], FREQ_90[Hz], FREQ_150[Hz], DDM(90-150)[1], SDM[%], PHI-90/150[°], VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz], ID-CODE, LEV_CLR_LF[dBm], LEV_CRS_UF[dBm], AM-MOD_CLR_LF/90Hz[%], AM-MOD_CLR_LF/150Hz[%], DDM_CLR_LF(90-150)[1], SDM_CLR_LF[%], AM-MOD_CRS_UF/90Hz[%], AM-MOD_CRS_UF/150Hz[%], DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%], PHI-90/90[°], PHI-150/150[°], K2/90Hz[%], K2/150Hz[%], K3/90Hz[%], K3/150Hz[%], THD/90Hz[%], THD/150Hz[%], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], MeasTime[ms], MeasMode, LOC_GP, ATT.MODE, TrigCounter

Medium parameters

RX, STIOCPM, Index , Date, Time, LEVEL[dBm], DDM(90-150)[1], SDM[%], LEV_CLR_LF[dBm], LEV_CRS_UF[dBm], DDM_CLR_LF(90-150)[1],

SDM_CLR_LF[%], DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%], GPS_lat.,
GPS_long., MeasMode, LOC_GP, ATT.MODE, TrigCounter

Short parameters

RX, Time, LEVEL[dBm], LEV_CRS_UF[dBm], LEV_CLR_LF[dBm],
DDM(90-150)[1], DDM_CRS_UF(90-150)[1], DDM_CLR_LF(90-150)[1],
SDM[%], SDM_CRS_UF[%], SDM_CLR_LF[%], GPS_lat., GPS_long.

9.12.3.2 ILS GP mode

All parameters

RX, STIOCPM, Index, Date, Time, FREQ[MHz], SINGLE[kHz], CRS_UF,
CLR_LF[kHz], LEVEL[dBm], AM-MOD./90Hz[%], AM-MOD./150Hz[%],
FREQ_90[Hz], FREQ_150[Hz], DDM(90-150)[1], SDM[%],
PHI-90/150[°], VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz], ID-CODE,
ID-Per.[s], Last_ID[s], DotLen[ms], DashLen[ms], DotDashGap[ms],
Lettergap[ms], LEV_CLR_LF[dBm], LEV_CRS_UF[dBm],
AM-MOD_CLR_LF/90Hz[%], AM-MOD_CLR_LF/150Hz[%],
FREQ_90_CLR_LF[Hz], FREQ_150_CLR_LF[Hz], DDM_CLR_LF(90-150)[1],
SDM_CLR_LF[%], PHI-90/150_CLR_LF[°], AM-MOD_CRS_UF/90Hz[%],
AM-MOD_CRS_UF/150Hz[%], FREQ_90_CRS_UF[Hz], FREQ_150_CRS_UF[Hz],
DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%], PHI-90/150_CRS_UF[°],
PHI-90/90[°], PHI-150/150[°], ResFM90[Hz], ResFM150[Hz],
K2/90Hz[%], K2/150Hz[%], K3/90Hz[%], K3/150Hz[%], K4/90Hz[%],
K4/150Hz[%], THD/90Hz[%], THD/150Hz[%], AM240[%], GPS_lat.,
GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time,
GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, GPS_Und.[m],
Temp[°C], MeasTime[ms], MeasMode, LOC_GP, ATT.MODE,
DemodOffset_1F, DemodOffset_CRS, DemodOffset_CLR, Autotune_1F,
Autotune_CRS, Autotune_CLR, IFBW_Man_WIDE, IFBW_Man_UCLC,
TrigCounter, IQPosition, IQSamples

Full parameters

Channel, STIOCPM, Index, Date, Time, FREQ[MHz],
CRS_UF/SINGLE[kHz], CLR_LF[kHz], LEVEL[dBm], AM-MOD./90Hz[%],
AM-MOD./150Hz[%], FREQ_90[Hz], FREQ_150[Hz], DDM(90-150)[1],
SDM[%], PHI-90/150[°], VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz],
ID-CODE, LEV_CLR_LF[dBm], LEV_CRS_UF[dBm],
AM-MOD_CLR_LF/90Hz[%], AM-MOD_CLR_LF/150Hz[%],
DDM_CLR_LF(90-150)[1], SDM_CLR_LF[%], AM-MOD_CRS_UF/90Hz[%],
AM-MOD_CRS_UF/150Hz[%], DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%],
PHI-90/90[°], PHI-150/150[°], K2/90Hz[%], K2/150Hz[%],
K3/90Hz[%], K3/150Hz[%], THD/90Hz[%], THD/150Hz[%], GPS_lat.,
GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time,
GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C],
MeasTime[ms], MeasMode, LOC_GP, ATT.MODE, TrigCounter

Medium parameters

RX, STIOCPM, Index , Date, Time, LEVEL[dBm], DDM(90-150)[1],
SDM[%], LEV_CLR_LF[dBm], LEV_CRS_UF[dBm], DDM_CLR_LF(90-150)[1],
SDM_CLR_LF[%], DDM_CRS_UF(90-150)[1], SDM_CRS_UF[%], GPS_lat.,
GPS_long., MeasMode, LOC_GP, ATT.MODE, TrigCounter

Short parameters

RX, Time, LEVEL[dBm], LEV_CRS_UF[dBm], LEV_CLR_LF[dBm],
DDM(90-150)[1], DDM_CRS_UF(90-150)[1], DDM_CLR_LF(90-150)[1],
SDM[%], SDM_CRS_UF[%], SDM_CLR_LF[%], GPS_lat., GPS_long.

9.12.3.3 ILS MB mode**All parameters**

RX, STIOCP, Index , Date, Time, FREQ[MHz], MEAS.F[kHz],
LEVEL[dBm], AM-MOD./3000Hz[%], AM-MOD./1300Hz[%],
AM-MOD./400Hz[%], FREQ_3000[Hz], FREQ_1300[Hz], FREQ_400[Hz],
ID-MOD.[%], ID-F.[Hz], GPS_lat., GPS_long., GPS_alt[m],
GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status,
GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], IFBW Manual,
MeasTime[ms], ATT.MODE, TrigCounter

Full parameters

Channel, STIOCP, Index , Date, Time, FREQ[MHz], MEAS.F[MHz],
LEVEL[dBm], AM-MOD./3000Hz[%], AM-MOD./1300Hz[%],
AM-MOD./400Hz[%], FREQ_3000[Hz], FREQ_1300[Hz], FREQ_400[Hz],
ID-MOD.[%], ID-F.[Hz], GPS_lat., GPS_long., GPS_alt[m],
GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status,
GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], MeasTime[ms], ATT.MODE,
TrigCounter

Medium parameters

RX, STIOCP, Index , Date, Time, LEVEL[dBm], AM-MOD./3000Hz[%],
AM-MOD./1300Hz[%], AM-MOD./400Hz[%], FREQ_3000[Hz],
FREQ_1300[Hz], FREQ_400[Hz], GPS_lat., GPS_long., TrigCounter

Short parameters

RX, Time, LEVEL[dBm], AM-MOD./400Hz[%], AM-MOD./1300Hz[%],
AM-MOD./3000Hz[%], GPS_lat., GPS_long.

9.12.3.4 VOR mode

All parameters

RX, STIOCPMV, Index , Date, Time, FREQ[MHz], MEAS.F[kHz], LEVEL[dBm], AM-MOD./30Hz[%], AM-MOD./9960Hz[%], FREQ_30[Hz], FREQ_9960[Hz], FREQ_FM30[Hz], BEARING(from)[°], FM-DEV.[Hz], FM-INDEX, VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz], ID-CODE, ID-Per.[s], Last_ID[s], DotLen[ms], DashLen[ms], DotDashGap[ms], Lettergap[ms], SubCarr_K2[dB], SubCarr_K3[dB], SubCarr_K4[dB], SubCarr_K5[dB], AM60Hz[%], AM1k44[%], AM1k50[%], No.Of Segm, GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, GPS_Und.[m], Temp[°C], IFBW Manual, MeasTime[ms], ATT.MODE, TrigCounter, I/Q_Position, I/Q_Samples

Full parameters

Channel, STIOCPM, Index , Date, Time, FREQ[MHz], MEAS.F[MHz], LEVEL[dBm], AM-MOD./30Hz[%], AM-MOD./9960Hz[%], AM-DIST./9960[%], FREQ_30[Hz], FREQ_9960[Hz], FREQ_FM30[Hz], BEARING(from)[°], FM-DEV.[Hz], FM-INDEX, VOICE-MOD.[%], ID-MOD.[%], ID-F.[Hz], ID-CODE, GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], MeasTime[ms], ATT.MODE, TrigCounter

Medium parameters

RX, STIOCPM, Index , Date, Time, LEVEL[dBm], BEARING(from)[°], GPS_lat., GPS_long., GPS_alt[m], TrigCounter

Short parameters

RX, Time, LEVEL[dBm], BEARING(from)[°], AM-MOD./30Hz[%], AM-MOD./9960Hz[%], FM-DEV.[Hz], GPS_lat., GPS_long.

9.12.3.5 COM mode

All parameters

RX, STIOCP, Index , Date, Time, FREQ[MHz], MEAS.F[MHz], MEAS.F_TX1[MHz], MEAS.F_TX2[MHz], LEVEL[dBm], LEVEL_TX1[dBm], LEVEL_TX2[dBm], AM-MOD[%], AM-MOD_TX1[%], AM-MOD_TX2[%], AMFREQ[Hz], AMFREQ_TX1[Hz], AMFREQ_TX2[Hz], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], IFBW Manual 1F, IFBW Manual 2F, MeasTime[ms], ATT.MODE, TrigCounter

Full parameters

Channel, STIOCP, Index , Date, Time, FREQ[MHz], MEAS.F_TX1[MHz], MEAS.F_TX2[MHz], LEVEL[dBm], LEVEL_TX1[dBm], LEVEL_TX2[dBm], AM-MOD[%], AM-MOD_TX1[%], AM-MOD_TX2[%], AMFREQ[Hz], AMFREQ_TX1[Hz], AMFREQ_TX2[Hz], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], MeasTime[ms], ATT.MODE, TrigCounter

Medium parameters

RX, STIOCP, Index , Date, Time, MEAS.F[MHz], MEAS.F_TX1[MHz], MEAS.F_TX2[MHz], LEVEL[dBm], LEVEL_TX1[dBm], LEVEL_TX2[dBm], AM-MOD[%], AM-MOD_TX1[%], AM-MOD_TX2[%], GPS_lat., GPS_long., TrigCounter

Short parameters

RX, Time, LEVEL[dBm], AM-MOD[%], AM-MOD_TX1[%], AM-MOD_TX2[%], GPS_lat., GPS_long.

9.12.3.6 GBAS mode**All parameters**

RX, STIOCP, Index , Date, Time, Slot, FREQ[MHz], C.Offset[kHz], Lev.Av[dBm], Lev.Pk[dBm], SSID, EVM[%], GBAS ID, Train.FEC, App.Dat., App.FEC, BER, BER Recv. Bursts, BER Missed Bursts, Transm.Len, StartDelay[us], Sync. Seq.[us], GuardInterv[ms], GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], ATT.MODE, TrigCounter, GraphData, IQPosition, IQSamples, RawData

Full parameters

Channel, STIOCP, Index , Date, Slot, Time, FREQ[MHz], Lev.Av[dBm], SSID, GBAS ID, Train.FEC, App.Dat., App.FEC, GPS_lat., GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat, GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, Temp[°C], ATT.MODE, TrigCounter

Medium parameters

RX, STIOCP, Index , Time, Slot, C.Offset[kHz], Lev.Av[dBm], GBAS ID, Train.FEC, App.Dat., App.FEC, GPS_lat., GPS_long., TrigCounter

Short parameters

RX, Index, Time, Slot, Lev.Av[dBm], GBAS ID, App.Dat.,
GPS_lat., GPS_long.

9.12.3.7 NDB mode**All parameters**

RX, STIOCP,
Index, Date, Time, FREQ[kHz], IDFREQ[Hz], MEAS.F[kHz], LEVEL[dB ∇ V],
IMP[Ohm], CarLevChange[dB], AM-MOD/[%], AM-FREQ[Hz], ID-CODE,
ID-Per.[s], Last_ID[s], DotLen[ms], DashLen[ms], DotDashGap[ms],
Lettergap[ms], K2[%], K3[%], K4[%], THD[%], PSFC[%], GPS_lat.,
GPS_long., GPS_alt[m], GPS_speed[km/h], GPS_date, GPS_time, GPS_Sat,
GPS_Status, GPS_Fix, GPS_HDOP, GPS_VDOP, GPS_Und.[m], IF-BW[kHz],
MeasTime[ms], ATT.MODE, TrigCounter, I/Q_Position, I/Q_Samples

Medium parameters

RX, STIOCP,
Index, Date, Time, FREQ[kHz], IDFREQ[Hz], MEAS.F[kHz], LEVEL[dB ∇ V],
IMP[Ohm], AM-MOD/[%], AM-FREQ[Hz], ID-CODE, K2[%], K3[%], K4[%],
THD[%], PSFC[%], GPS_lat., GPS_long., MeasTime[ms], ATT.MODE

Short parameters

RX, STIOCP,
Index, FREQ[kHz], IDFREQ[Hz], MEAS.F[kHz], LEVEL[dB ∇ V], AM-MOD/[%],
AM-FREQ[Hz], ID-CODE

9.13 Information on commands**HELP?**

Returns a list of all remote commands available for the R&S EVSF1000, including a short description.

Return values:

<CommandList> List of commands, consisting of the command syntax and a short description.

Usage: Query only

10 Maintenance, storage and disposal

The product does not require regular maintenance. It only requires occasional cleaning. It is however advisable to check the nominal data from time to time.

Cleaning

Do not use any liquids for cleaning. Cleaning agents, solvents, acids and bases can damage the front panel labeling, plastic parts and display.

Storage

Protect the product against dust. Ensure that the environmental conditions, e.g. temperature range and climatic load, meet the values specified in the data sheet.

10.1 Disposal

Rohde & Schwarz is committed to making careful, ecologically sound use of natural resources and minimizing the environmental footprint of our products. Help us by disposing of waste in a way that causes minimum environmental impact.

Disposing electrical and electronic equipment

A product that is labeled as follows cannot be disposed of in normal household waste after it has come to the end of its service life. Even disposal via the municipal collection points for waste electrical and electronic equipment is not permitted.



Figure 10-1: Labeling in line with EU directive WEEE

Rohde & Schwarz has developed a disposal concept for the eco-friendly disposal or recycling of waste material. As a manufacturer, Rohde & Schwarz completely fulfills its obligation to take back and dispose of electrical and electronic waste. Contact your local service representative to dispose of the product.

11 Transporting

Lifting and carrying

See:

- [Chapter 1.4.2, "Lifting and carrying"](#), on page 10.

Packing

Use the original packaging material. It consists of antistatic wrap for electrostatic protection and packing material designed for the product.

If you do not have the original packaging, use similar materials that provide the same level of protection. You can also contact your local Rohde & Schwarz service center for advice.

Securing

When moving the product in a vehicle or using transporting equipment, make sure that the product is properly secured. Only use items intended for securing objects.

To secure the R&S EVSF1000 in a flight inspection aircraft, use the optional installation tray (R&S EVSF1-Z1) for rackmounting or another rackmounting adapter. See [Chapter 1.4.3.1, "Mounting the R&S EVSF1000 in a rack"](#), on page 10.

Transport altitude

The maximum transport altitude without pressure compensation is specified in the data sheet.

12 Contacting customer support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

Contact information

Contact our customer support center at www.rohde-schwarz.com/support, or follow this QR code:



Figure 12-1: QR code to the Rohde & Schwarz support page

Annex

A ILS channel frequency list

The following table indicates the frequencies for the signals for specific ILS channels as defined by the International Civil Aviation Organization (ICAO).

Table A-1: ILS LOC and ILS GP - channel and frequency

ICAO Channel	Localizer mode Frequency (MHz)	Glidepath mode Frequency (MHz)
18X	108.10	334.70
18Y	108.15	334.55
20X	108.30	334.10
20Y	108.35	333.95
22X	108.50	329.90
22Y	108.55	329.75
24X	108.70	330.50
24Y	108.75	330.35
26X	108.90	329.30
26Y	108.95	329.15
28X	109.10	331.40
28Y	109.15	331.25
30X	109.30	332.00
30Y	109.35	331.85
32X	109.50	332.60
32Y	109.55	332.45
34X	109.70	333.20
34Y	109.75	333.05
36X	109.90	333.80
36Y	109.95	333.65
38X	110.10	334.40
38Y	110.15	334.25
40X	110.30	335.00
40Y	110.35	334.85
42X	110.50	329.60
42Y	110.55	329.45

ICAO Channel	Localizer mode Frequency (MHz)	Glidepath mode Frequency (MHz)
44X	110.70	330.20
44Y	110.75	330.05
46X	110.90	330.80
46Y	110.95	330.65
48X	111.10	331.70
48Y	111.15	331.55
50X	111.30	332.30
50Y	111.35	332.15
52X	111.50	332.90
52Y	111.55	332.75
54X	111.70	333.50
54Y	111.75	333.35
56X	111.90	331.10
56Y	111.95	330.95

B VOR channel frequency list

The following table indicates the frequencies for the signals for specific VOR channels as defined by the International Civil Aviation Organization (ICAO).

Table B-1: VOR - channel and frequency list

ICAO Channel	VOR Frequency (MHz)		ICAO Channel	VOR Frequency (MHz)		ICAO Channel	VOR Frequency (MHz)
17X	108.00		75X	112.80		103X	115.60
17Y	108.05		75Y	112.85		103Y	115.65
19X	108.20		76X	112.90		104X	115.70
19Y	108.25		76Y	112.95		104Y	115.75
21X	108.40		77X	113.00		105X	115.80
21Y	108.45		77Y	113.05		105Y	115.85
23X	108.60		78X	113.10		106X	115.90
23Y	108.65		78Y	113.15		106Y	115.95
25X	108.80		79X	113.20		107X	116.00
25Y	108.85		79Y	113.25		107Y	116.05
27X	109.00		80X	113.30		108X	116.10
27Y	109.05		80Y	113.35		108Y	116.15
29X	109.20		81X	113.40		109X	116.20
29Y	109.25		81Y	113.45		109Y	116.25
31X	109.40		82X	113.50		110X	116.30
31Y	109.45		82Y	113.55		110Y	116.35
33X	109.60		83X	113.60		111X	116.40
33Y	109.65		83Y	113.65		111Y	116.45
35X	109.80		84X	113.70		112X	116.50
35Y	109.85		84Y	113.75		112Y	116.55
37X	110.00		85X	113.80		113X	116.60
37Y	110.05		85Y	113.85		113Y	116.65
39X	110.20		86X	113.90		114X	116.70
39Y	110.25		86Y	113.95		114Y	116.75
41X	110.40		87X	114.00		115X	116.80
41Y	110.45		87Y	114.05		115Y	116.85
43X	110.60		88X	114.10		116X	116.90

ICAO Channel	VOR Frequency (MHz)		ICAO Channel	VOR Frequency (MHz)		ICAO Channel	VOR Frequency (MHz)
43Y	110.65		88Y	114.15		116Y	116.95
45X	110.80		89X	114.20		117X	117.00
45Y	110.85		89Y	114.25		117Y	117.05
47X	111.00		90X	114.30		118X	117.10
47Y	111.05		90Y	114.35		118Y	117.15
49X	111.20		91X	114.40		119X	117.20
49Y	111.25		91Y	114.45		119Y	117.25
51X	111.40		92X	114.50		120X	117.30
51Y	111.45		92Y	114.55		120Y	117.35
53Y	111.65		93Y	114.65		121X	117.40
55X	111.80		94X	114.70		121Y	117.45
55Y	111.85		94Y	114.75		122X	117.50
57X	112.00		95X	114.80		122Y	117.55
57Y	112.05		95Y	114.85		123X	117.60
53X	111.60		93X	114.60		123Y	117.65
58X	112.10		96X	114.90		124X	117.70
58Y	112.15		96Y	114.95		124Y	117.75
59X	112.20		97X	115.00		125X	117.80
59Y	112.25		97Y	115.05		125Y	117.85
70X	112.30		98X	115.10		126X	117.90
70Y	112.35		98Y	115.15		126Y	117.95
71X	112.40		99X	115.20			
71Y	112.45		99Y	115.25			
72X	112.50		100X	115.30			
72Y	112.55		100Y	115.35			
73X	112.60		101X	115.40			
73Y	112.65		101Y	115.45			
74X	112.70		102X	115.50			
74Y	112.75		102Y	115.55			

C References

- [1] RTCA DO-246, GNSS-Based Precision Approach Local Area Augmentation System (LAAS) Signal-in-Space Interface Control Document (ICD), July 2017
- [2] RTCA DO-217, Minimum aviation system performance standards DGNSS instrument approach system: Special Category I (SCAT-I), August 1996
- [3] ICAO AN10 Vol1, ICAO Annex 10, Aeronautical Telecommunications, Volume 1, July 2018

D Format description of GBAS and SCAT-I data

The Data Recorder records and manages the data captured during one or a series of measurements. Up to 999 lists with a maximum of 1 000 000 data lines each can be recorded. One line corresponds to the captured data at the receive frequency for the GBAS/SCAT-I signal in one time slot.

Similarly, a data stream consists of lines of measurement results, where one line corresponds to the captured data at the receive frequency for the GBAS/SCAT-I signal in one time slot.

You can also query a single measurement result, which corresponds to one row in the Data Recorder list.

In all three cases, the available parameters and their format are identical.



Which parameters are recorded is user-definable and can be defined individually for each list. The following overview describes all available parameters (full list) in their default order.

The format of the data for each slot is identical, regardless whether a parameter contains data or not. Thus, you can create a table from the exported comma-separated list. If a slot is empty, only the general data is stored in the list entry; the message-specific parameters are cropped.

When a list is stored to a file, a header line is automatically included that describes the provided parameters.

General Information

The following general information is always included, regardless whether the slot contains data or not, and whether the signal is GBAS or SCAT type.

Table D-1: General information for the individual slot

No.	Column	Description
	Channel	RF board 1 or 2
1	STIOCP	Status Flags: • S: Start (started manually) • T: Triggered (externally) • I: Invalid (power level not permitted or too low) • O: Overload (RF input signal too high) • C: Corrected (includes RF input correction factor) • P: PPS-synced (triggered by external PPS)
2	Index	Counts each measurement
3	Date	Date of measurement
4	Time	Time of measurement
5	Temp[°C]	Temperature on R&S EVSF1000 mainboard
6	SLOT	Time slot (A B C D E F G H)

No.	Column	Description
7	FREQ[MHz]	Receiving frequency
8	F_DEV[kHz]	Frequency deviation
9	LEVEL[dBm]	Level measured over the "Synchronization and Ambiguity Resolution" period of the GBAS/SCAT signal
10	SSID	Received Station ID, equivalent to GBAS ID or SCAT ID
11	Len[bit]	Length of the entire message block
12	Train.FEC	FEC of the training sequence
13	Applic.FEC	FEC of the data content
14	MBI	Message block identifier
15	MT 1	Message type 1 available (YES NO)
16	MT 4	Message type 4 available (YES NO)
17	GPS_lat.	Received GPS data
18	GPS_long.	
19	GPS_alt[m]	
20	GPS_speed[km/h]	
21	GPS_date	
22	GPS_time	
23	GPS_Sat	
24	GPS_Status	
25	GPS_Fix	
26	GPS_HDOP	
27	GPS_VDOP	
28	GPS_Dist[m]	Distance between GPS reference point and current GPS position
29	GPS_Angle[°]	Angle between GPS reference point and current GPS position
30	ATT.MODE	Attenuator mode during slot measurement (LN NORM LD) In AUTO mode: the used hardware setting

GBAS Signal - MT1

After the general information, if the slot contains a message type 1, the following burst data is provided for each of the up to 32 satellites (in "full" list only):

Table D-2: Decoded message type 1 data for the individual slot and each satellite (GBAS)

Column	Description
MT1 GBAS	Section label (separator in list)
MB CRC	

Column	Description
MB ID	Message block ID: 1010 1010: normal LAAS message (GBAS) 1111 1111: test LAAS message (GBAS)
Stat ID	Received Station ID, equivalent to GBAS ID or SCAT ID
MsgLen[byte]	
Z-Cnt[m:s]	
Add.Msg.Flag	
NrOfMeasn	
MeasnType	
EphDecorPar[m/m]	
EphemCrcMSB	
EphemCrcLSB	
SrcAvailDur[sec]	
SatID	
IOD	
PRC[m]	
RRCor[m/s]	
S_pr_gnd[m]	
DiffnprcB1[m]	
DiffnprcB2[m]	
DiffnprcB3[m]	
DiffnprcB4[m]	

For details on the correction data parameters, refer to the GBAS specification [1].

MT4

If the slot contains a message type 4, the following decoded message data is provided for each of the up to 15 FASDBs (in "full" list only):

Table D-3: Decoded message type 4 data for the individual slot and each FASDB (GBAS)

Column	Description
MT4 GBAS	Section label (separator in list)
MB CRC	
MB ID	Message block ID: 1010 1010: normal LAAS message (GBAS) 1111 1111: test LAAS message (GBAS)
Stat ID	Received Station ID, equivalent to GBAS ID or SCAT ID
MsgLen[byte]	

Column	Description
DataSetLen	
OpType	
SbasServProv	
AirportID	
RunwayNo	
RunwayLtr	
ApproachPerfDesig	
RouteInd	
RPDS	
RefPathID	
LTP_FTP_Lat[°]	
LTP_FTP_Long[°]	
LTP_FTP_Height[m]	
DeltaFPAP_Lat[°]	
DeltaFPAP_Long[°]	
TCH	
UnitTCH	
GPA[°]	
CourseWidth[m]	
DeltaLenOffset[m]	
VertAlertLim[m]	
LatrAlertLim[m]	
FASCRC	

SCAT-I Signal - MT1

After the general information, if the slot contains a message type 1, the following burst data is provided for each of the up to 32 satellites (in "full" list only):

Table D-4: Decoded message type 1 data for the individual slot and each satellite (SCAT-I)

Column	Description
MT1 SCAT	Section label (separator in list)
MB CRC	
MB ID	Message block ID: 1001 1001: SCAT-I
Stat ID	Received Station ID, equivalent to GBAS ID or SCAT ID
MsgLen[byte]	

Column	Description
Z-Cnt[m:s]	
Acc.Err.Bnd.[m/s*s]	
K_md_gnd	
SatID	
PRC[m]	
IOD	
RRCor[m/s]	
S_pr_gnd[m]	
B_pr_gnd[m]	
S_fail_gnd[m]	
B_fail_gnd[m]	
PRC[m]	

For details on the correction data parameters, refer to the SCAT-I specification [2].

MT4

If the slot contains a message type 4, the following decoded message data is provided for each of the up to 15 FASDBs (in "full" list only):

Table D-5: Decoded message type 4 data for the individual slot and each FASDB (SCAT-I)

Column	Description
MT4 DATA	Section label (separator in list)
MB CRC	
MB ID	Message block ID: 1001 1001: SCAT-I
Stat ID	Received Station ID, equivalent to GBAS ID or SCAT ID
MsgLen[byte]	
OpType	
AirportID	
RunwayNo	
RunwayLtr	
RouteInd	
ValInd	
RPDS	
RefPathID	
ThDP_Lat[°]	

Column	Description
ThDP_Long[°]	
ThDP_Height[m]	
DERP_LAT[°]	
DERP_Long[°]	
TCH[ft]	
GPA[°]	
FASCRC	

List of commands

*IDN?	255
AC8	280
AC8	304
AF0	304
AF1	305
AF2	280
AF2	305
AF3	280
AF4	295
AF5	295
AF6	295
AF7	295
AF8	281
AF8	305
AM0	305
AM1	305
AM2	281
AM2CLR	281
AM2CRS	281
AM3	281
AM3CLR	281
AM3CRS	282
AM4	295
AM5	296
AM6	296
AM7	296
AM8	282
AM8	305
AM9	282
AM9	306
AMFREQ_OFFSET_TX1	310
AMFREQ_OFFSET_TX1?	310
AMFREQ_OFFSET_TX2	310
AMFREQ_OFFSET_TX2?	310
AMMOD240	282
AUTOKALSTATUS	257
AUTOKALSTATUS_EXTENDED	257
BE	306
BE_TO?	306
BE?	306
BI?	255
CH	234
CH?	234
CLEARACTIVELIST	361
CLEARALLLISTS	363
CLEARERRORLOG	255
COM_1F2F_MEASMODE	311

COM_1F2F_MEASMODE?	311
COM_DEFAULT_FREQSTEP	311
COM_DEFAULT_FREQSTEP?	311
COM_DEMOD_BW_1F	311
COM_DEMOD_BW_1F?	311
COM_DEMOD_BW_2F	311
COM_DEMOD_BW_2F?	311
COM_TONEFREQ_1K01K2	312
COM_TONEFREQ_1K01K2?	312
COM_TRIG_EDGE	312
COM_TRIG_EDGE?	312
COM_TRIG_SOURCE	312
COM_TRIG_SOURCE?	312
DCLR	283
DCRS	283
DD0	283
DD1	283
DEMODE_GS	271
DEMODE_GS?	271
DEMODE_LLZ	261
DEMODE_LLZ?	261
DIST_9960	306
DL_START	361
DL_STOP	361
FA0	291
FA0	298
FA0	309
FA1	291
FA2	291
FA2	298
FA2	308
FA3	292
FA4	292
FA5	292
FACTORY_PRESET	250
FCLR	284
FCRS	284
FFT_ATTMODE	348
FFT_ATTMODE?	348
FFT_BB_AF_BW_KHZ	349
FFT_BB_AF_BW_KHZ?	349
FFT_BB_IF_BW_KHZ	349
FFT_BB_IF_BW_KHZ?	349
FFT_BB_LFIN_DCOFFSETV	349
FFT_BB_LFIN_DCOFFSETV?	349
FFT_FREQ_CENTER	350
FFT_FREQ_CENTER?	350
FFT_FREQ_SPAN	350
FFT_FREQ_SPAN?	350
FFT_FREQ_START	350

FFT_FREQ_START?	350
FFT_FREQRF	351
FFT_FREQRF?	351
FFT_FREQSTOP	350
FFT_FREQSTOP?	350
FFT_GETSPECT	354
FFT_GRID_YRANGE_DB	351
FFT_GRID_YRANGE_DB?	351
FFT_GRID_YRANGE_V	351
FFT_GRID_YRANGE_V?	351
FFT_IF_BW_KHZ	352
FFT_IF_BW_KHZ?	352
FFT_RESBW_AUTO	352
FFT_RESBW_AUTO?	352
FFT_RESBW_FIX_KHZ	352
FFT_RESBW_FIX_KHZ?	352
FFT_RFLF_INPUT	353
FFT_RFLF_INPUT?	353
FFT_TRACE_AVRGCOUNT	354
FFT_TRACE_AVRGCOUNT?	354
FFT_TRACE_MODE?	353
FFT_TRACEMODE	353
FILTER_GS_RESIDFM	277
FILTER_GS_RESIDFM?	277
FILTER_LLZ_RESIDFM	267
FILTER_LLZ_RESIDFM?	267
FM0	306
FM1	306
FMEAS	295
FMEAS	307
FSCAN_ATTMODE	339
FSCAN_ATTMODE?	339
FSCAN_FREQCENTER	339
FSCAN_FREQCENTER?	339
FSCAN_FREQSPAN	339
FSCAN_FREQSPAN?	339
FSCAN_FREQSTART	340
FSCAN_FREQSTART?	340
FSCAN_FREQSTOP	340
FSCAN_FREQSTOP?	340
FSCAN_GETSPECT	342
FSCAN_GRID_YRANGE_DB	340
FSCAN_GRID_YRANGE_DB?	340
FSCAN_REFLEVEL	340
FSCAN_REFLEVEL?	340
FSCAN_RES_BW	341
FSCAN_RES_BW?	341
FSCAN_RESBW_AUTO	341
FSCAN_RESBW_AUTO?	341
FSCAN_TRACE_AVRGCOUNT	342

FSCAN_TRACE_AVRGCOUNT?	342
FSCAN_TRACE_MODE	341
FSCAN_TRACE_MODE?	341
FSINGLE	284
GBAS:ATTMODE	321
GBAS:ATTMODE?	321
GBAS:BUFFER_RUNPAUSE	322
GBAS:BUFFER_RUNPAUSE?	322
GBAS:EVM_ANGLE_NORM	322
GBAS:EVM_ANGLE_NORM?	322
GBAS:EVM?	325
GBAS:FAILEDMSG?	325
GBAS:FMEAS?	323
GBAS:FREQRF	323
GBAS:FREQRF?	323
GBAS:GBASBER?	326
GBAS:GBASID?	326
GBAS:GETMDEF	326
GBAS:GETMEAS	327
GBAS:GRAPH_TOLOGG	329
GBAS:GRAPH_TOLOGG?	329
GBAS:LEV?	323
GBAS:LOGSLOTS	329
GBAS:MSG_TOLOGG	329
GBAS:MSG_TOLOGG?	329
GBAS:PEAKLEV?	330
GBAS:PPSLOCKED?	330
GBAS:RESETBER	330
GBAS:SCREENVIEW	324
GBAS:SCREENVIEW ?	324
GBAS:SEQN_SLOT	324
GBAS:SEQN_SLOT?	324
GBAS:STOPSTREAM	331
GBAS:STREAM	331
GBAS:VALIDMSG?	332
GET_K2_1K0	314
GET_K2_1K2	314
GET_K3_1K0	314
GET_K3_1K2	314
GET_K4_1K0	314
GET_K4_1K2	315
GET_MEASFREQ	315
GET_ONE_AMFREQ_1_0	315
GET_ONE_AMFREQ_1_2	315
GET_ONE_AMMOD_1_0	315
GET_ONE_AMMOD_1_2	315
GET_ONE_SINAD_1_0	316
GET_ONE_SINAD_1_2	316
GET_ONE_THD_1_0	316
GET_ONE_THD_1_2	316

GET_THD_1K0.....	316
GET_THD_1K2.....	317
GET_TX1_AMFREQ_1_0.....	317
GET_TX1_AMFREQ_1_2.....	317
GET_TX1_AMMOD_1_0.....	317
GET_TX1_AMMOD_1_2.....	317
GET_TX1_LEVEL.....	318
GET_TX1_MEASFREQ.....	318
GET_TX1_SINAD_1_0.....	318
GET_TX1_SINAD_1_2.....	318
GET_TX1_THD_1_0.....	318
GET_TX1_THD_1_2.....	318
GET_TX2_AMFREQ_1_0.....	319
GET_TX2_AMFREQ_1_2.....	319
GET_TX2_AMMOD_1_0.....	319
GET_TX2_AMMOD_1_2.....	319
GET_TX2_LEVEL.....	319
GET_TX2_MEASFREQ.....	320
GET_TX2_SINAD_1_0.....	320
GET_TX2_SINAD_1_2.....	320
GET_TX2_THD_1_0.....	320
GET_TX2_THD_1_2.....	320
GETACTIVELIST.....	361
GETDATA_FROM_ACTIVELIST.....	362
GETDATADEF.....	366
GETDATASET.....	366
GETDLTIME?.....	362
GETERRORLOG.....	255
GETFREEMEMORY.....	362
GETGPSGPBOD.....	240
GETGPSGPGGA.....	240
GETGPSGPGLL.....	240
GETGPSGPGSA.....	240
GETGPSGPGSV.....	240
GETGPSGPHDT.....	240
GETGPSGPRMC.....	240
GETGPSGPTRF.....	241
GETGPSGPVBW.....	241
GETGPSGPVTG.....	241
GETGPSGPXTE.....	241
GETGPSGPZDA.....	241
GETGPSUNDULATION.....	242
GETHOSTNAME.....	245
GETKALSTATUS.....	257
GETLISTDATA.....	362
GETLISTSIZE.....	363
GETMDEF.....	230
GETMEAS.....	229
GETNRPPOW.....	234
GETNRPTYPE.....	234

GETOPTIONS.....	255
GETTEMP.....	255
GETUNCAL.....	230
GS.....	291
GS_BB_1F_OFFSETKHZ.....	272
GS_BB_1F_OFFSETKHZ?.....	272
GS_BB_AF_BW_IDDIST_KHZ.....	272
GS_BB_AF_BW_IDDIST_KHZ?.....	272
GS_BB_BW_KHZ.....	272
GS_BB_BW_KHZ?.....	272
GS_BB_DC_V.....	282
GS_BB_LEV_V.....	282
GS_BB_LEV_V.....	283
GS_BB_LFIN_DCOFFSETV.....	273
GS_BB_LFIN_DCOFFSETV?.....	273
GS_BB_LOWIF_BW_IDDIST_KHZ.....	273
GS_BB_LOWIF_BW_IDDIST_KHZ?.....	273
GS_BB_LOWIF_BW_KHZ.....	273
GS_BB_LOWIF_BW_KHZ?.....	273
GS_BB_WIDE1F.....	274
GS_BB_WIDE1F?.....	274
GS_CARRIER_THRESHOLD_DB.....	274
GS_CARRIER_THRESHOLD_DB?.....	274
GS_DEFAULT_FREQSTEP.....	274
GS_DEFAULT_FREQSTEP?.....	274
GS_DEM_1F2F_BW.....	275
GS_DEM_1F2F_BW?.....	275
GS_DEM_ID_BW.....	275
GS_DEM_ID_BW?.....	275
GS_DEM_ID_WIDE_BW.....	275
GS_DEM_ID_WIDE_BW?.....	275
GS_DEM_WIDE_BW.....	275
GS_DEM_WIDE_BW?.....	275
GS_DEMFREQS_OFFSET_1F.....	276
GS_DEMFREQS_OFFSET_1F?.....	276
GS_DEMFREQS_OFFSET_AUTOMAN.....	276
GS_DEMFREQS_OFFSET_AUTOMAN?.....	276
GS_DEMFREQS_OFFSET_LOWERFREQ.....	276
GS_DEMFREQS_OFFSET_LOWERFREQ?.....	276
GS_DEMFREQS_OFFSET_UPPERFREQ.....	277
GS_DEMFREQS_OFFSET_UPPERFREQ?.....	277
GS_ID_STAT.....	277
GS_ID_STAT?.....	277
GS_RFLF_INPUT.....	278
GS_RFLF_INPUT?.....	278
GS_START_FINDCARRIER.....	278
GS_TRIG_EDGE.....	278
GS_TRIG_EDGE?.....	278
GS_TRIG_SOURCE.....	279
GS_TRIG_SOURCE?.....	279

HELP?	373
ID_CODE	336
ID_DASH_LENGTH	288
ID_DOT_LENGTH	288
ID_DOTDASH_GAP	289
ID_F400_DASHLEN	296
ID_F400_GAP	297
ID_F1300_DASHLEN	297
ID_F1300_DOTLEN	297
ID_F1300_GAP	297
ID_F3000_DOTLEN	297
ID_F3000_GAP	298
ID_LETTER_GAP	289
ID_PERIOD	289
IFSPECT_ATTMODE	344
IFSPECT_FREQ_SPAN	344
IFSPECT_FREQ_SPAN?	344
IFSPECT_FREQRF	344
IFSPECT_FREQRF?	344
IFSPECT_GETSPECT	347
IFSPECT_GRID_YRANGE_DB	344
IFSPECT_GRID_YRANGE_DB?	344
IFSPECT_REFLEVEL	345
IFSPECT_REFLEVEL?	345
IFSPECT_RES_BW	345
IFSPECT_RES_BW?	345
IFSPECT_RESBW_AUTO	345
IFSPECT_RESBW_AUTO?	345
IFSPECT_TRACE_AVRGCOUNT	346
IFSPECT_TRACE_AVRGCOUNT?	346
IFSPECT_TRACE_MODE	346
IFSPECT_TRACE_MODE?	346
INV?	256
K2_90	284
K2_150	284
K3_90	285
K3_150	284
K4_90	285
K4_150	285
KALSCREEN	257
LA?	231
LA?	323
LASTID_TIME	289
LCLR	285
LCRS	285
LLZ	290
LLZ_BB_1F_OFFSETKHZ	262
LLZ_BB_1F_OFFSETKHZ?	262
LLZ_BB_AF_BW_IDDIST_KHZ	262
LLZ_BB_AF_BW_IDDIST_KHZ?	262

LLZ_BB_BW_KHZ.....	262
LLZ_BB_BW_KHZ?.....	262
LLZ_BB_DC_V.....	287
LLZ_BB_LEV_V.....	287
LLZ_BB_LFIN_DCOFFSETV.....	263
LLZ_BB_LFIN_DCOFFSETV?.....	263
LLZ_BB_LOWIF_BW_IDDIST_KHZ.....	263
LLZ_BB_LOWIF_BW_IDDIST_KHZ?.....	263
LLZ_BB_LOWIF_BW_KHZ.....	263
LLZ_BB_LOWIF_BW_KHZ?.....	263
LLZ_BB_VMAXPP_V.....	288
LLZ_BB_WIDE1F.....	264
LLZ_BB_WIDE1F?.....	264
LLZ_CARRIER_THRESHOLD_DB.....	264
LLZ_CARRIER_THRESHOLD_DB?.....	264
LLZ_DEFAULT_FREQSTEP.....	264
LLZ_DEFAULT_FREQSTEP?.....	264
LLZ_DEM_1F2F_BW.....	266
LLZ_DEM_1F2F_BW?.....	266
LLZ_DEM_ID_BW.....	265
LLZ_DEM_ID_BW?.....	265
LLZ_DEM_ID_WIDE_BW.....	265
LLZ_DEM_ID_WIDE_BW?.....	265
LLZ_DEM_WIDE_BW.....	265
LLZ_DEM_WIDE_BW?.....	265
LLZ_DEMFREQS_OFFSET_1F.....	266
LLZ_DEMFREQS_OFFSET_1F?.....	266
LLZ_DEMFREQS_OFFSET_AUTOMAN.....	266
LLZ_DEMFREQS_OFFSET_AUTOMAN?.....	266
LLZ_DEMFREQS_OFFSET_LOWERFREQ.....	267
LLZ_DEMFREQS_OFFSET_LOWERFREQ?.....	267
LLZ_DEMFREQS_OFFSET_UPPERFREQ.....	267
LLZ_DEMFREQS_OFFSET_UPPERFREQ?.....	267
LLZ_ID_STAT.....	267
LLZ_ID_STAT?.....	267
LLZ_RFLF_INPUT.....	268
LLZ_RFLF_INPUT?.....	268
LLZ_START_FINDCARRIER.....	268
LLZ_TRIG_EDGE.....	268
LLZ_TRIG_EDGE?.....	268
LLZ_TRIG_SOURCE.....	269
LLZ_TRIG_SOURCE?.....	269
LO.....	245
M?.....	258
MARKSTREAM.....	367
MB.....	259
MB_DEFAULT_FREQSTEP.....	293
MB_DEFAULT_FREQSTEP?.....	293
MB_DEM_BW.....	293
MB_DEM_BW?.....	293

MB_TRIG_EDGE.....	293
MB_TRIG_EDGE?.....	293
MB_TRIG_SOURCE.....	294
MB_TRIG_SOURCE?.....	294
MEASMODE.....	290
MEASMODE?.....	290
MEASTIME.....	231
MEASTIME?.....	231
MI.....	259
MLOC.....	245
MODE_COM.....	310
MODE_FFT.....	348
MODE_FSCAN.....	338
MODE_GBAS.....	324
MODE_GP.....	260
MODE_IFSPECT.....	343
MODE_LOC.....	260
MODE_MB.....	293
MODE_NDB.....	333
MODE_SCOPE.....	355
MODE_VOR.....	300
MV.....	259
NDB_AMFREQ.....	336
NDB_AMMOD.....	336
NDB_CARLEV_CHANGE.....	336
NDB_DEFAULT_FREQSTEP.....	333
NDB_DEFAULT_FREQSTEP?.....	333
NDB_DEM_DIST_BW.....	334
NDB_DEM_DIST_BW?.....	334
NDB_DEM_ID_BW.....	333
NDB_DEM_ID_BW?.....	333
NDB_EXTERNALATT_LFIN.....	334
NDB_EXTERNALATT_LFIN?.....	334
NDB_IDFREQ_400_1020.....	336
NDB_K2_PCT.....	337
NDB_K3_PCT.....	337
NDB_K4_PCT.....	337
NDB_LFIN_IMPEDANCE.....	334
NDB_LFIN_IMPEDENCE?.....	334
NDB_POWSUPPL_FC.....	337
NDB_THD_PCT.....	337
NDB_UNIT_LEVEL.....	335
NDB_UNIT_LEVEL?.....	335
OPTIONGETCHECKED.....	256
PH.....	285
PH_90_90.....	286
PH_150_150.....	286
PPSSMA_TRIG_SOURCE.....	363
PPSSMA_TRIG_SOURCE?.....	235
RECIQ.....	363

REMOTELOCK.....	246
RESIDFM_90.....	286
RESIDFM_150.....	286
RF.....	231
RF_MHZ_5DECIMALS.....	313
RF_MHZ_5DECIMALS?.....	313
RF?.....	231
RFCH.....	231
RLC.....	246
SAVEACTIVELIST2USB.....	364
SAVEDATA.....	256
SCLR.....	286
SCOPE_ATTMODE.....	355
SCOPE_BB_AF_BW_KHZ.....	356
SCOPE_BB_AF_BW_KHZ?.....	356
SCOPE_BB_IF_BW_KHZ.....	356
SCOPE_BB_IF_BW_KHZ?.....	356
SCOPE_BB_LFIN_DCOFFSETV.....	356
SCOPE_BB_LFIN_DCOFFSETV?.....	356
SCOPE_FREQRF.....	357
SCOPE_FREQRF?.....	357
SCOPE_GETMEAS.....	360
SCOPE_IF_BW_KHZ.....	357
SCOPE_IF_BW_KHZ?.....	357
SCOPE_REFLEVEL.....	357
SCOPE_REFLEVEL?.....	357
SCOPE_RESBW_FIX_KHZ.....	357
SCOPE_RESBW_FIX_KHZ?.....	357
SCOPE_RFLF_INPUT.....	358
SCOPE_RFLF_INPUT?.....	358
SCOPE_TIMEDIV_RF.....	358
SCOPE_TIMEDIV_RF?.....	358
SCOPE_TRIGLEVEL_RFPCT.....	359
SCOPE_TRIGLEVEL_RFPCT?.....	359
SCOPE_TRIGSLOPE.....	359
SCOPE_TRIGSLOPE?.....	359
SCRS.....	286
SD0.....	287
SD1.....	287
SELECTLISTPARAM.....	364
SETACTIVELIST.....	365
SETATTMODE.....	232
SETDLTIME.....	365
SETUP:AUDIOBW.....	237
SETUP:BB_IN_COUPL.....	236
SETUP:BB_IN_COUPL?.....	236
SETUP:BB_IN_FACTOR.....	236
SETUP:BB_IN_FACTOR?.....	236
SETUP:BB_IN_RANGE.....	236
SETUP:BB_IN_RANGE?.....	236

SETUP:BOOTONPOWERUP.....	250
SETUP:DATE.....	251
SETUP:DDM_RANGE_GS.....	238
SETUP:DDM_RANGE_LLZ.....	237
SETUP:DEMOD_OUT_AGC.....	233
SETUP:DEMOD_OUT_COUPLING.....	233
SETUP:DEMODAMFM.....	232
SETUP:EXTERNALATT_RX1.....	233
SETUP:EXTERNALATT_RX1?.....	233
SETUP:EXTERNALATT_RX2.....	233
SETUP:EXTERNALATT_RX2?.....	233
SETUP:GBAS_PPS_SOURCE.....	324
SETUP:GBAS_PPS_SOURCE?.....	324
SETUP:GBAS_PPS_SOURCE?.....	363
SETUP:GETERRORLOG.....	255
SETUP:GPS_BAUDRATE.....	242
SETUP:GPS_BAUDRATE?.....	242
SETUP:GPS_IP_AD.....	242
SETUP:GPS_IP_PORT.....	242
SETUP:GPSREF.....	244
SETUP:INPUT.....	234
SETUP:INPUT?.....	234
SETUP:NTPSERVER.....	246
SETUP:NTPSERVER?.....	246
SETUP:PPS_SYNC.....	243
SETUP:PPS_SYNC?.....	243
SETUP:REFLAT.....	244
SETUP:REFLAT?.....	244
SETUP:REFLONG.....	244
SETUP:REFLONG?.....	244
SETUP:SETGPSDELAY.....	243
SETUP:SETGPSINTERFACE.....	241
SETUP:SPEAKER.....	238
SETUP:TIME.....	251
SETUP:TIMESYNC.....	244
SETUP:TIMESYNC?.....	244
SETUP:UNIT:BARGRAPH.....	252
SETUP:UNIT:BARGRAPH?.....	252
SETUP:UNIT:DDM.....	252
SETUP:UNIT:DDM?.....	252
SETUP:UNIT:ILSPHASE.....	253
SETUP:UNIT:ILSPHASE?.....	253
SETUP:UNIT:POLARITYDDM.....	253
SETUP:UNIT:POLARITYDDM?.....	253
SETUP:UNIT:SDM.....	253
SETUP:UNIT:SDM?.....	253
SETUP:UNIT:UPPERFREQ.....	254
SETUP:UNIT:UPPERFREQ?.....	254
SETUP:UNIT:VORDIRECTION.....	254
SETUP:UNIT:VORDIRECTION?.....	254

SETUP:VOLUME.....	238
SQUELCH.....	239
SQUELCH?.....	239
STARTKAL.....	257
STOPSTREAM.....	367
STREAM.....	366
SUBCARR_AM1K44.....	307
SUBCARR_AM1K50.....	307
SUBCARR_AM60HZ.....	307
SUBCARR_K2.....	307
SUBCARR_K3.....	307
SUBCARR_K4.....	308
SUBCARR_K5.....	308
THD_90.....	287
THD_150.....	287
VER?.....	256
VIEW_COM.....	310
VIEW_COM?.....	310
VIEW_GS.....	269
VIEW_GS?.....	269
VIEW_LLZ.....	270
VIEW_LLZ?.....	270
VIEW_MB.....	294
VIEW_MB?.....	293
VIEW_NDB.....	335
VIEW_NDB?.....	335
VIEW_VOR.....	300
VIEW_VOR?.....	300
VOR_BB_BW_KHZ.....	300
VOR_BB_BW_KHZ?.....	300
VOR_BB_LFIN_DCOFFSETV.....	300
VOR_BB_LFIN_DCOFFSETV?.....	300
VOR_DEFAULT_FREQSTEP.....	301
VOR_DEFAULT_FREQSTEP?.....	301
VOR_DEM_AM_BW.....	301
VOR_DEM_AM_BW?.....	301
VOR_DEM_BEARFILTER.....	301
VOR_DEM_BEARFILTER?.....	301
VOR_DEM_BW.....	301
VOR_DEM_BW?.....	301
VOR_DEM_FM_BW.....	302
VOR_DEM_FM_BW?.....	302
VOR_DEMFREQS_OFFSET.....	302
VOR_DEMFREQS_OFFSET?.....	302
VOR_ID_STAT.....	302
VOR_ID_STAT?.....	302
VOR_RFLF_INPUT.....	303
VOR_RFLF_INPUT?.....	303
VOR_TRIG_EDGE.....	303
VOR_TRIG_EDGE?.....	303

VOR_TRIG_SOURCE.....	303
VOR_TRIG_SOURCE?.....	303
WAIT4EXE.....	251
WIFI:CHANNEL.....	248
WIFI:CHANNEL?.....	248
WIFI:COUNTRY.....	249
WIFI:COUNTRY?.....	249
WIFI:GATEWAY.....	248
WIFI:IP.....	247
WIFI:NETMASK.....	247
WIFI:ONOFF.....	248
WIFI:ONOFF?.....	248
WIFI:SPEED.....	249
WIFI:SPEED?.....	249
WIFI:SSID.....	247
WIFI:STATUS.....	250
WIFI:WPAPSK.....	247

Index

A

Accessories	27
AF Out	20
Allocating the VDB to the time domain	
Principle	157
Auto-calibration	220

B

Beacon	115
Brochures	8

C

Channel addressing	228
Common Settings	
Amplification	68, 83, 103, 113, 122
Audio	209
Bandwidth	69, 104, 114
BW	69, 104, 114
CH FREQ	67, 83, 102, 112, 122
Display	210
Measurement Time	74, 84, 104, 114, 124
MTime	74, 84, 104, 114, 124
Customer support	376

D

Data Recorder	
Format description	382
Data sheets	8
DDM 90-150	55, 60
Default	
Restoring settings	199, 200
Direct Addressing	228

E

Error Log	221
-----------------	-----

F

Factory defaults	200
Fictitious Threshold Point (FTP)	157
Final Approach Segment (FAS) data	
Diagram	157
see also FAS DB	157
Flight Path Alignment Point (FPAP)	157
Front panel	18

G

GBAS	
Basics	155
Broadcast timing structure	157
Components	155
Correction message	156
Data format	382
FAS data	157
Frequencies	156
Message type 1 data	383
Message type 4 data	384
Message xml interface	178

Mode	154
Recording data	202
Specification	381
Getting started	8
Glide Path Angle (GPA)	157
GPS	
RS-232	23

H

Help	8
HW Status	222

I

ID Analysis	
Dash Length	61, 98, 118
Dot Length	61, 98, 118
Dot-Dash Gap	61, 98, 118
ID AM	61, 98, 118
ID Frequency	61, 99, 118
ID Period	61, 98, 118
Last ID	61, 98, 117
Letter Gap	61, 98, 118
ILS Mode	
Localizer	42, 75
Marker Beacon	75
Initial configuration	199, 200
Inventory	224

K

Keypad	
Key layout	35
Keys	
PRESET	199, 200

L

Landing Threshold Point (LTP)	157
LOC	42, 75
Localizer	42, 75
LVD-M safety information MAN signal_words TEMPLATE . 7	

M

Marker Beacon	75
400 Hz Dash	81
400 Hz Gap	81
1300 Hz Dash	81
1300 Hz Dot	81
1300 Hz Gap	81
3000 Hz Dot	81
3000 Hz Gap	81
MB	75
Message type 1	
GBAS data	383
SCAT-I data	385
Message type 4	
GBAS data	384
SCAT-I data	386

N

NDB Mode 115

O

Open source acknowledgment (OSA) 9
Options 223

P

Power Supply 22
PPS
 Basics 158
 Duration 158
 Triggering 158
PPS In 23
Preset
 Key 199, 200
Presettings 198

R

Rear panel 21
Release notes 9
RS-232 23

S

Safety instructions 5, 8
SCAT-I
 Data format 382
 Message type 1 data 385
 Message type 4 data 386
 Specification 381
SCAT-I mode 154
SDM 90, 150 56
Service manual 8
Settings
 Factory defaults 200
Signal In
 Correction 40
 LF In Coupling 72, 142, 149
 LF In Range 72, 142, 149
 Source 63, 71, 101, 137, 146
Status
 Recorded data 382
Storing
 Measurement settings 198
Synchronization
 PPS 158

T

TCP/IP
 DHCP 213
 Gateway 214, 218
 IP Address 214, 217
 Netmask 214, 218
TDMA timing structure 157
Terminal Area Path (TAP) 157
Threshold Crossing Height (TCH) 157
Time domain allocation
 Principle 157
Time slots
 Synchronization 158

Timing

 GBAS 157
Trigger to PPS 159
Triggering
 PPS 158

U

USB connector 20
User manual 8
UserPresets 198

V

VNC Viewer 29
VOR
 Mode 85